ALLIMITY TP7 TP7187R

ALLIMITY TP7 TP7187R Replacement Remote Control Instruction Manual

For GRUNDIG TV Models

Introduction

The ALLIMITY TP7 TP7187R is a replacement remote control designed for various GRUNDIG television models. This manual provides essential information for the setup, operation, and maintenance of your remote control, ensuring seamless interaction with your compatible television.

Product Overview

The ALLIMITY TP7 TP7187R remote control features an ergonomic design with a standard button layout for intuitive navigation and control of your GRUNDIG TV.



Image: Front view of the ALLIMITY TP7 TP7187R remote control, showcasing its button layout and ergonomic shape.

Compatible GRUNDIG TV Models

This remote control is compatible with a wide range of GRUNDIG TV models. Please verify your TV model against the list below:

- 26VLE7200BH, 26VLE7201BH, 26VLE8200BL, 26VLE8200SL, 26VLE8200WL, 26VLE8300BP
- 32VLE6220BH, 32VLE7139BR, 32VLE7230BH, 32VLE7230BR, 32VLE7230WR, 32VLE7239BR, 32VLE7239WR, 32VLE812S, 32VLE8130BH, 32VLE8130BL, 32VLE8130BP, 32VLE8130CP, 32VLE8130SL, 32VLE8130WL, 32VLE8221BL, 32VLE8230BL, 32VLE8230SL, 32VLE8230WL, 32VLE823S, 32VLE830BL, 32VLE9230BH, 32VLE9270BH, 32VLE9270BL, 32VLE9270BP, 32VLE9270SL, 32VLE9270WL, 32VLE9271BL, 32VLE9370BL, 32VLE971BL, 32VLE973BL
- 37CLE975BL, 37VLE9230BL, 37VLE9270BH, 37VLE9270BL, 37VLE9270BP, 37VLE9270SL, 37VLE9270WL, 37VLE9271BL, 37VLE9271WL, 37VLE971BL, 37VLE973BL
- 40CLE7239BR, 40VLE6220BH, 40VLE630BH, 40VLE6339BR, 40VLE7003BL, 40VLE7139BR, 40VLE7230BH, 40VLE7230BR, 40VLE7230WR, 40VLE7239BR, 40VLE7239WR, 40VLE7320BH, 40VLE7320BL, 40VLE7321BH, 40VLE7330BR, 40VLE8003BL, 40VLE812S, 40VLE8160BH, 40VLE8160BL, 40VLE8160BP, 40VLE8160CP, 40VLE8160SL, 40VLE8160WL, 40VLE8221BL, 40VLE8230BP, 40VLE8270BH, 40VLE8270BP, 40VLE8270CP, 40VLE8270WP, 40VLE830BL, 40VLE8360BH
- 42VLE8370BP, 42VLE9050BL, 42VLE9270BH, 42VLE9270BL, 42VLE9270SL, 42VLE9270WL, 42VLE9271BL, 42VLE9271WL, 42VLE9275BP, 42VLE9275WP, 42VLE9279BP, 42VLE9279WP, 42VLE9372BL, 42VLE971BL, 42VLE973BL
- 46VLE630BH, 46VLE7139BR, 46VLE7230BH

Setup Instructions

1. Battery Installation

The ALLIMITY TP7 TP7187R remote control operates on two AAA alkaline batteries (not included).

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover off in the direction indicated by the arrow.
3. Insert two new AAA alkaline batteries, ensuring the correct polarity (+ and -) as indicated inside the compartment.
4. Replace the battery compartment cover, sliding it back until it clicks into place.

2. Initial Use

No programming or complex setup is required. Once the batteries are correctly installed, the remote control is ready for immediate use with compatible GRUNDIG TV models.

Operating Instructions

Basic Operation

Point the remote control directly towards your GRUNDIG TV's infrared (IR) receiver. Ensure there are no physical obstructions between the remote and the TV that could block the signal.

Key Functions

- **Power Button:** Located at the top right, turns the TV on or off.
- **Number Buttons (0-9):** For direct channel selection.
- **Volume Up/Down (+/-):** Adjusts the sound volume.
- **Channel Up/Down (P+/P-):** Changes TV channels sequentially.
- **Mute Button:** Silences or restores the TV sound.
- **Menu Button:** Accesses the TV's main menu for settings and options.
- **Navigation Buttons (Up, Down, Left, Right):** Used to move through menus and options.
- **OK Button:** Confirms selections within menus.
- **Source/Input Button:** Selects different input sources (e.g., HDMI, AV).
- **TXT Button:** Accesses Teletext services.
- **Guide Button:** Displays the electronic program guide (EPG).
- **Colored Buttons (Red, Green, Yellow, Blue):** Functions vary depending on the TV model and the current screen content (e.g., interactive services, teletext sub-pages).
- **Media Playback Controls (Play, Pause, Stop, Rewind, Fast Forward):** Controls media playback on compatible devices or TV functions.

Maintenance

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Avoid using liquid cleaners, solvents, or abrasive materials, as these can damage the surface or internal components.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones of the same type.
- **Storage:** Store the remote control in a cool, dry place, away from direct sunlight, high humidity, and extreme temperatures. Remove batteries if the remote will not be used for an extended period to prevent leakage.

Troubleshooting

Problem	Possible Cause	Solution
Remote control is not working.	• Dead or low batteries. • Incorrect battery polarity. • Obstruction between remote and TV. • Remote out of range. • TV's IR receiver is blocked or faulty.	• Replace batteries with new AAA alkaline batteries. • Check battery orientation (+/-). • Ensure a clear line of sight to the TV. • Move closer to the TV. • Ensure nothing is blocking the TV's IR sensor.
Some buttons are unresponsive.	• Dirty button contacts. • Remote control malfunction.	• Try cleaning the remote surface. • If problem persists after battery replacement, the remote may need replacement.

Specifications

- **Brand:** ALLIMITY
- **Model:** TP7 TP7187R
- **Connectivity Technology:** Infrared
- **Special Feature:** Ergonomic design
- **Maximum Range:** 10 Meters
- **Battery Description:** Alkaline (AAA, 2 required)
- **Compatible Devices:** GRUNDIG Televisions (specific models listed above)

Warranty Information

Specific warranty details for this replacement remote control are not provided in the product information. Please refer to the seller's or manufacturer's policy at the time of purchase for warranty coverage and terms.

Support

For further assistance, technical support, or inquiries regarding your ALLIMITY TP7 TP7187R remote control, please contact the seller directly through your purchase platform or refer to the ALLIMITY official support channels if available.