Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY SHW-RMC-0103

ALLIMITY SHW-RMC-0103 Remote Control User Manual

Model: SHW-RMC-0103 | Brand: ALLIMITY

1. Introduction

This manual provides comprehensive instructions for the ALLIMITY SHW-RMC-0103 replacement remote control. This remote is designed to function with various Sharp Aquos Smart TV models, offering a direct replacement experience without complex setup procedures.

Compatible TV Models:

- LC22CFE4000ES, LC-22CFE4000ES, LC22CFE4012E, LC-22CFE4012E, LC22CFE4012ES, LC-22CFE4012ES, LC22CFF4011E, LC-22CFF4011E, LC22CFF4011ES, LC-22CLCLCFF4011ES, LC22CFF4012E, LC-22CFF4012E, LC22CFF4012ES, LC-22CFF4012ES, LC22DFE4011K, LC-22DFE4011K, LC22DFF4011E, LC-22DFF4011E, LC22DFF4011ES, LC-22DFF4011ES
- LC24CHE4000E, LC-24CHE4000E, LC24CHE4000ES, LC-24CHE4000ES, LC24CHE4012E, LC-24CHE4012E, LC24CHE4012ES, LC-24CHE4012ES, LC24CHF4011E, LC-24CHF4011E, LC24CHF4011ES, LC-24CHF4011ES, LC24CHF4011K, LC-24CHF4011K, LC24CHF4012E, LC-24CHF4012E, LC24CHF4012ES, LC-24CHF4012ES, LC24DHE4011K, LC-24DHE4011K, LC24DHF4011E, LC-24DHF4011E, LC24DHF4011ES, LC-24DHF4011ES, LC24DHF4011K, LC-24DHF4011K
- LC32CHE4041K, LC-32CHE4041K, LC32CHF4041K, LC-32CHF4041K, LC32DHE4041K, LC-32DHE4041K, LC32DHF4041K, LC-32DHF4041K, LC32HG3141K, LC-32HG3141K, LC32HG3241K, LC-32HG3241K, LC32HG3341K, LC-32HG3341K
- LC40CFE4040E, LC-40CFE4040E, LC40CFE4041E, LC-40CFE4041E, LC40CFE4041K, LC-40CFE4041K, LC40CFE4042E, LC-40CFE4042E, LC40CFF4041K, LC-40CFF4041K, LC40FG3141K, LC-40FG3141K, LC40FG3241K, LC-40FG3241K, LC40FG3341K, LC-40FG3341K
- LC43CFE4140E, LC-43CFE4140E, LC43CFE4141E, LC-43CFE4141E, LC43CFE4142E, LC-43CFE4142E
- LC48CFE4041E, LC-48CFE4041E, LC48CFE4041K, LC-48CFE4041K, LC48CFE4042E, LC-48CFE4042E, LC48CFE4042K, LC-48CFE4042K
- LC49CFE4041E, LC-49CFE4041E, LC49CFE4042E, LC-49CFE4042E

This remote control is designed to function immediately after battery installation, requiring no additional programming for the listed compatible Sharp Aquos Smart TV models.

2. Setup

2.1 Battery Installation

To begin using your ALLIMITY SHW-RMC-0103 remote control, follow these simple steps to install the batteries:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or press the latch and lift to open.
3. Insert two AAA alkaline batteries (not included), ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.

The remote control is ready for use immediately after battery installation. No programming or pairing is required for compatible Sharp Aquos Smart TV models.



Figure 1: Front view of the ALLIMITY SHW-RMC-0103 remote control, showing the button layout. The battery compartment is located on the reverse side.

3. Operating Instructions

This section outlines the basic functions and operation of your ALLIMITY SHW-RMC-0103 remote control.

3.1 General Operation

Point the remote control directly towards your Sharp Aquos Smart TV's infrared receiver. Ensure there are no obstructions between the remote and the TV.

3.2 Button Functions

Button	Function
Power (Red Button)	Turns the TV on or off.
DTV / RADIO / USB / DVD	Selects different input sources or modes.
Number Buttons (0-9)	Direct channel selection.
TV GUIDE	Accesses the electronic program guide.
VOL +/-	Adjusts the volume level.
CH +/-	Changes the TV channel.
Mute	Mutes or unmutes the TV audio.
MENU	Opens the TV's main menu.
OK / Navigation Arrows	Navigates through menus and confirms selections.
EXIT	Exits the current menu or function.
SOURCE	Selects the input source (HDMI, AV, etc.).
INFO	Displays information about the current program or input.
P.MODE / S.MODE / FAV	Picture Mode, Sound Mode, and Favorite channels access.
Media Control Buttons	Play, Pause, Stop, Fast Forward, Rewind, Skip for media playback (e.g., USB, DVD).
Color Buttons (Red, Green, Yellow, Blue)	Context-sensitive functions within menus or smart TV applications.

4. Maintenance

4.1 Cleaning

To maintain the remote control's functionality and appearance:

- Wipe the surface with a soft, dry cloth.
- For stubborn dirt, lightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid excessive moisture.
- Do not use harsh chemicals, solvents, or abrasive cleaning pads, as these can damage the remote's finish or internal components.

4.2 Battery Care

- Replace batteries when the remote's response becomes sluggish or inconsistent.
- If the remote control will not be used for an extended period (e.g., one month or more), remove the batteries to prevent leakage and potential damage.
- Dispose of used batteries according to local regulations.

5. Troubleshooting

If you encounter issues with your remote control, refer to the following common troubleshooting steps:

- **Remote Not Responding:**
  - Ensure the batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new AAA alkaline batteries.
  - Check for any obstructions between the remote control and the TV's infrared sensor.
  - Ensure you are within the effective operating range (typically up to 10 meters).
- **Specific Buttons Not Working:**
  - This may indicate a faulty button or low battery power. Try replacing the batteries.
  - Clean around the button with a soft, dry cloth to remove any debris.
- **Remote Control Range is Reduced:**
  - Replace the batteries.
  - Ensure there are no strong light sources (e.g., direct sunlight, fluorescent lights) interfering with the infrared signal.

If these steps do not resolve the issue, please refer to the support information in Section 7.

6. Specifications

Feature	Detail
Brand	ALLIMITY
Model	SHW-RMC-0103
Compatible Devices	Sharp Aquos Smart Televisions (specific models listed in Introduction)
Connectivity Technology	Infrared (IR)
Controller Type	Button Control
Maximum Range	10 Meters (approx. 33 feet)
Battery Type	AAA Alkaline (2 required, not included)
Product Dimensions	6 x 0.5 x 17 cm (approx. 2.36 x 0.2 x 6.69 inches)
Item Weight	70 g (approx. 0.15 lbs)
Manufacturer	MaxControlFactory

7. Warranty and Support

This ALLIMITY remote control is designed for reliable performance. For specific warranty details or technical support, please refer to the retailer where the product was purchased or contact ALLIMITY customer service directly. Keep your purchase receipt as proof of purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0857FC754

More documents and user manuals: **https://manuals.plus/**