LG LMQ720

LG Stylo 5 LMQ720 Smartphone User Manual

Model: LMQ720

Introduction

This manual provides essential instructions for setting up, operating, and maintaining your LG Stylo 5 LMQ720 Android Smartphone. Please read this guide thoroughly to ensure proper use and to maximize the device's features.

Product Overview

The LG Stylo 5 LMQ720 is an Android smartphone featuring a 6.2-inch FHD+ FullVision Display and an integrated stylus for enhanced interaction. It is equipped with a 16 MP rear camera and a 5 MP front camera, a rear-mounted fingerprint sensor, and a 3500 mAh battery with fast charging capabilities.

Device Components





Figure 1: Front View with Stylus Inserted. This image displays the front of the LG Stylo 5 smartphone, highlighting its large display and the stylus securely housed within the device.



Figure 2: Front View with Stylus Removed. This image shows the LG Stylo 5 from the front, with the stylus detached and positioned

alongside the device, illustrating its accessibility.

Key Features

- **Display:** 6.2-inch FHD+ FullVision Display for clear visuals.
- **Camera System:** 16 MP rear camera with PDAF (Phase Detection Autofocus) and a 5 MP front camera.
- **Security:** Rear-mounted fingerprint sensor for secure access.
- **Battery:** 3500 mAh battery with fast charging support, offering up to 24 hours of talk time.
- **Stylus:** Integrated stylus for note-taking and precise navigation.
- **Audio:** DTS: X Surround Sound for an immersive audio experience.
- **Operating System:** Android OS.
- **Storage:** 32 GB internal memory.

Setup Guide

1. Insert SIM Card

1. Locate the SIM card tray on the side of your device.
2. Use the provided SIM ejector tool (or a small paperclip) to open the tray.
3. Place your T-Mobile compatible Nano-SIM card into the tray with the gold contacts facing down.
4. Carefully reinsert the tray into the phone.

2. Charge the Battery

- Connect the USB cable to the charging port at the bottom of the phone.
- Plug the other end of the USB cable into the power adapter, then into a wall outlet.
- Allow the phone to charge completely before initial use. The battery indicator will show charging status.

3. Power On and Initial Setup

- Press and hold the Power/Lock button (usually on the right side) until the LG logo appears.
- Follow the on-screen prompts to select your language, connect to Wi-Fi, set up your Google account, and configure security features like the fingerprint sensor.

Operating Instructions

Basic Navigation

- **Touchscreen:** Tap to select, swipe to scroll, pinch to zoom.
- **Stylus:** Use the integrated stylus for precise input, drawing, and note-taking. Removing the stylus may activate specific stylus-related apps or shortcuts.
- **Home Screen:** Access apps, widgets, and notifications. Swipe down from the top for quick settings and notifications.

Camera Usage

- Open the Camera app from your home screen or app drawer.
- Tap the shutter button to take a photo.
- Switch between front and rear cameras using the camera toggle icon.
- Explore modes like Portrait Mode for enhanced photography.

Fingerprint Sensor

- To set up, go to **Settings > Security & Lock screen > Fingerprints**.

- Follow the on-screen instructions to register your fingerprint.
- Use the rear-mounted sensor to unlock your phone or authorize purchases.

Connectivity

- **Wi-Fi:** Go to **Settings > Network & internet > Wi-Fi** to connect to available networks.
- **Mobile Data:** Ensure your T-Mobile SIM card is active. Manage mobile data settings under **Settings > Network & internet > Mobile network**.

Maintenance

Cleaning Your Device

- Use a soft, lint-free cloth to clean the screen and body of the phone.
- Avoid using harsh chemicals or abrasive materials.
- For stubborn smudges, slightly dampen the cloth with water or a screen cleaner designed for electronics.

Battery Care

- Avoid extreme temperatures, as they can degrade battery life.
- Charge your phone regularly, but avoid leaving it plugged in for extended periods after it's fully charged.
- If the phone will not be used for a long time, charge it to about 50% before storing.

Software Updates

- Regularly check for software updates to ensure optimal performance and security.
- Go to **Settings > System > System update** to check for and install available updates.

Troubleshooting

Common Issues and Solutions

- **Device Not Powering On:** Ensure the battery is charged. Connect to a charger and wait a few minutes before attempting to power on again.
- **Apps Crashing/Freezing:** Close and reopen the app. If the issue persists, clear the app's cache (**Settings > Apps & notifications > [App Name] > Storage & cache > Clear cache**).
- **Poor Connectivity (Wi-Fi/Cellular):** Restart your phone. Check your Wi-Fi router or contact your T-Mobile service provider if cellular issues persist.
- **Slow Performance:** Close unused apps, clear cache, or free up storage space.
- **Stylus Not Responding:** Ensure the stylus is properly inserted and removed. Restart the device.

Factory Reset (Last Resort)

If severe issues persist, a factory reset may be necessary. This will erase all data on your phone. Back up important data before proceeding. Go to **Settings > System > Reset options > Erase all data (factory reset)**.

Specifications

Feature	Specification
Model Number	LMQ720
Operating System	Android

Feature	Specification
Display Size	6.2 Inches
Resolution	1512 x 756
Rear Camera	16 MP, PDAF
Front Camera	5 MP
Battery Capacity	3500 mAh
Memory Storage	32 GB
Dimensions (L x W x H)	6.3 x 3.06 x 0.33 inches
Item Weight	6 ounces
Wireless Carrier	T-Mobile (compatible)
Connectivity	Wi-Fi, 2G, 3G, 4G Cellular

Warranty and Support

For warranty information and technical support, please refer to the documentation provided with your device or visit the official LG support website. As this is a renewed product, specific warranty terms may vary; consult your retailer for details regarding the Amazon Renewed Guarantee.
Online Support: www.lg.com/us/support

© 2024 LG Electronics. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question