ZdalaMit RM-AAU013

ZdalaMit RM-AAU013 Replacement Remote Control User Manual

For Sony Home Theater Systems HT-DDW790, STR-DG510, HT-DDW795, HT-DDW685

Introduction

This manual provides instructions for the ZdalaMit RM-AAU013 replacement remote control. This remote is designed to function with various Sony Home Theater Systems, including models HT-DDW790, STR-DG510, HT-DDW795, and HT-DDW685. It offers direct functionality without the need for programming or pairing.

Setup

Battery Installation

The RM-AAU013 remote control requires two (2) 1.5V AA alkaline batteries for operation. Batteries are not included with the remote control.

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or press the latch and lift to open.
3. Insert two AA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the indicators inside the compartment.
4. Replace the battery compartment cover until it clicks securely into place.

Once batteries are installed, the remote control is ready for immediate use. No programming or pairing is required.



Image: Angled view of the ZdalaMit RM-AAU013 remote control. The battery compartment is located on the reverse side of the remote.

Operating Instructions

This remote control provides full functionality for your compatible Sony Home Theater System. Familiarize yourself with the button layout for optimal use.



Image: Front view of the ZdalaMit RM-AAU013 remote control, displaying all buttons and their labels.

Key Functions

- **Power (I/O)**: Turns the home theater system and connected TV (if applicable) on or off.
- **TV INPUT** / **AV I/O**: Selects the input source for the television.
- **SYSTEM STANDBY** / **DVD**: Puts the system into standby mode or controls DVD functions.
- **VIDEO 1, VIDEO 2, VIDEO 3**: Selects corresponding video input sources.
- **SAT, TV, SA-CD/CD, TUNER**: Selects audio input sources.
- **2CH, A.F.D., MOVIE, MUSIC**: Selects sound field modes.
- **Numeric Keypad (1-9, 0/10, >10/-.-)**: Used for direct channel selection, track selection, or entering numbers.
- **AMP MENU**: Accesses the amplifier's menu.
- **FM MODE**: Changes FM tuner modes.
- **D.TUNING**: Direct tuning for radio frequencies.
- **MEMORY** / **ENTER**: Stores radio presets or confirms selections.
- **D.SKIP** / **DVD MENU**: Skips DVD chapters or accesses the DVD menu.
- **CLEAR** / **DISPLAY**: Clears entries or changes display information.
- **Navigation (Up, Down, Left, Right, Enter)**: Navigates through menus and confirms selections.
- **TOOLS** / **MUTING**: Accesses system tools or mutes the audio output.
- **TV VOL (+/-)** / **MASTER VOL (+/-)** Adjusts television volume or master system volume.
- **RETURN/EXIT** / **MENU**: Returns to the previous screen or exits a menu.
- **TV CH (+/-)** / **PRESET (+/-)** Changes television channels or radio presets.
- **REPLAY** / **ADVANCE**: Skips back or forward during playback.
- **TUNING (+/-)**: Manually tunes radio frequencies.
- **Playback Controls (Play, Pause, Stop, Fast Forward, Rewind)**: Controls media playback.

Maintenance

Battery Replacement

Replace batteries when the remote control's response becomes sluggish or stops functioning. Always replace both batteries simultaneously with new 1.5V AA alkaline batteries. Do not mix old and new batteries, or different types of batteries. Dispose of used batteries according to local regulations.

Cleaning

To clean the remote control, use a soft, dry cloth. For stubborn dirt, lightly dampen the cloth with water or a mild cleaning solution, then wipe the remote. Avoid using abrasive cleaners, solvents, or harsh chemicals, as these can damage the remote's surface or internal components.

Troubleshooting

Remote Not Responding

- **Check Batteries**: Ensure batteries are inserted correctly with the correct polarity (+/-) and are not depleted. Replace with fresh batteries if necessary.
- **Line of Sight**: Ensure there is a clear line of sight between the remote control and the infrared sensor on your home theater system. Remove any obstructions.
- **Distance**: Operate the remote within the effective range of your home theater system.
- **System Power**: Confirm that your Sony Home Theater System is powered on.

Limited Remote Range

- **Battery Strength**: Weak batteries can reduce the remote's effective range. Replace them.
- **Interference**: Strong light sources (e.g., direct sunlight, fluorescent lights) or other electronic devices can interfere with the remote's signal. Try operating the remote in a different environment.

Specifications

Model Number	RM-AAU013
Compatible Devices	Sony Home Theater Systems: HT-DDW790, STR-DG510, HT-DDW795, HT-DDW685
Power Supply	2 x 1.5V AA Alkaline Batteries (not included)
Product Dimensions	5.6 x 1.4 x 0.5 inches (approximately)
Item Weight	1.41 ounces (approximately)
Color	Black/White/Silver (as per product variations)

Warranty Information

Specific warranty details for the ZdalaMit RM-AAU013 replacement remote control may vary. Please refer to the warranty information provided at the time of purchase or contact the retailer/manufacturer directly for details regarding warranty coverage and terms.

Support

If you encounter any issues or have questions regarding the ZdalaMit RM-AAU013 replacement remote control that are not addressed in this manual, please contact the seller or manufacturer for assistance. Provide your product model number (RM-AAU013) and a detailed description of the issue to facilitate support.

ZdalaMit RM-AAU013 User Manual © 2023. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question