Burg-Wächter 39900

Burg-Wächter 39900 Key Safe 50 SB Cabinets Instruction Manual

Model: 39900 Key Safe 50 SB

1. Introduction

The Burg-Wächter 39900 Key Safe 50 SB is designed for the secure safekeeping of keys and other small valuables, offering convenient 24-hour access. This key safe features a personal 4-digit customizable number combination and a robust design for reliable security.



Image 1.1: The Burg-Wächter 39900 Key Safe 50 SB in its closed state, showcasing its compact and secure design.

Safety Information

Please read and understand all safety warnings before using the key safe:

- Always use the key safe cabinet with caution.
- Keep out of reach of children and pets.
- Do not attempt to force open the cabinet.
- Always use the correct combination to unlock the safe.
- The shackle can be sharp; handle with care to avoid injury.
- Do not overload the cabinet, as this may cause it to tip over or break.
- Always follow the manufacturer's instructions for installation and use.

2. Package Contents

Verify that all components are present in the package:

- 1 x Burg-Wächter Key Safe 50 SB
- Fixing material (for optional screw mounting)

3. Setup

Setting the Combination

The Burg-Wächter 39900 Key Safe 50 SB comes with a customizable 4-digit combination. To set or change your personal combination:

1. Open the key safe using the current combination (default is usually 0-0-0-0 or specified in separate packaging).
2. Locate the reset lever or screw on the inside of the safe's door, typically near the combination dials.
3. Move the reset lever to the 'SET' position or turn the reset screw (refer to specific markings if available).
4. While the lever/screw is in the 'SET' position, rotate the four combination dials to your desired 4-digit code. Choose a memorable but secure combination.
5. Return the reset lever to the 'LOCK' position or turn the reset screw back to its original position. This locks in your new combination.
6. Scramble the dials to a random number.
7. With the safe door still open, test your new combination to ensure it opens correctly.
8. Once confirmed, close the safe door and scramble the dials to secure it.



Image 3.1: The key safe opened, revealing the internal combination dials and the mechanism for setting the code.

Mounting Options

The Key Safe 50 SB offers flexible mounting options:

- **Shackle Mounting:** The safe features a removable shackle for secure fastening to door handles, fences, or other fixed objects. To attach, simply open the safe, remove the shackle, place it around the desired object, and reinsert it into the safe's top slots. Ensure the shackle is fully engaged before closing the safe.
- **Screw Mounting:** For permanent installation, the safe can be mounted to a wall or other surface using the included fixing material. Open the safe, position it against the desired surface, mark the drilling points, drill pilot holes, and secure the safe with screws. Ensure the mounting surface is strong enough to support the safe and its contents.

4. Operating Instructions

Opening the Key Safe

1. Rotate the combination dials to your personal 4-digit code.
2. Pull down the front cover to open the safe.

Closing the Key Safe

1. Ensure all items are securely placed inside.
2. Close the front cover firmly until it clicks into place.
3. Scramble the combination dials to a random sequence to lock the safe and prevent unauthorized access.

Storing Keys and Valuables

The key safe is equipped with internal hooks for organizing keys. Keys up to 8 cm long can be stored. Place keys on the hooks and ensure they do not obstruct the closing mechanism. Small valuables can be placed directly inside the compartment.



Image 4.1: The key safe opened, showing keys securely stored on the internal hooks.

5. Maintenance

To ensure the longevity and proper functioning of your Burg-Wächter Key Safe:

- **Cleaning:** Wipe the exterior with a soft, damp cloth. Avoid abrasive cleaners or solvents that could damage the finish.
- **Mechanism Care:** Periodically check the combination dials and opening mechanism for smooth

operation. If they become stiff, a small amount of silicone-based lubricant can be applied, avoiding oil-based lubricants.

- **Inspection:** Regularly inspect the shackle and casing for any signs of wear or damage.

6. Troubleshooting

- **Safe will not open with the correct combination:**
  - Ensure each dial is precisely aligned with the indicator mark.
  - Verify that you are using the correct, most recently set combination.
  - Check for any obstructions preventing the door from opening.
- **Safe door is difficult to close:**
  - Ensure no items inside the safe are obstructing the door or the locking mechanism.
  - Check if the shackle is properly seated if it was removed and reinserted.
- **Forgotten Combination:** If you forget your combination, there is no universal reset method without the code. It is crucial to keep your combination in a secure, memorable location. Contact Burg-Wächter customer support for potential solutions, though recovery without the code is often not possible for security reasons.

7. Specifications

Feature	Detail
Brand	Burg-Wächter
Model Number	39900
Model Name	Key Safe 50 SB
Color	Black/Grey
Material	Zinc Alloy Die Casting (Alloy Steel)
Product Dimensions (HxWxD)	178 x 95 x 45 mm (approx. 7.01" x 3.74" x 1.77")
Shackle Thickness	9.5 mm
Shackle Width	78 mm
Shackle Height	83 mm
Lock Type	4-digit customizable combination
Number of Settings	10,000 possible combinations
Max Key Length	8 cm
Additional Features	Magnetic key holder, sliding protective flap, removable shackle

8. Warranty and Support

Burg-Wächter products are manufactured to high-quality standards and come with a manufacturer's warranty. For specific warranty details, claims, or technical support, please refer to the documentation included with your purchase or visit the official Burg-Wächter website. Keep your proof of purchase for warranty purposes.

© 2026 Burg-Wächter. All rights reserved.