ALLIMITY AMT-AKB33871409

Instruction Manual

ALLIMITY AKB33871409 Replacement Remote Control for LG LCD LED TV

1. Introduction

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your new ALLIMITY AKB33871409 Replacement Remote Control. This remote is designed to be a direct replacement for the original LG AKB33871409 remote, offering seamless compatibility with various LG LCD LED TV models without the need for complex programming.

2. Product Overview

The AKB33871409 replacement remote control is an infrared (IR) device specifically manufactured to operate LG LCD LED Plasma TVs. It features a standard layout with all essential buttons for TV control, including power, input selection, channel navigation, volume adjustment, and menu access.





Figure 2.1: Front view of the AKB33871409 Replacement Remote Control, showing all buttons and their labels.





Figure 2.2: Angled view of the remote control, highlighting its ergonomic design.

3. Setup

3.1 Battery Installation

The remote control requires two (2) AAA batteries for operation. Follow these steps to install the batteries:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or outwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.





Figure 3.1: Rear view of the remote control with the battery cover removed, illustrating the battery insertion process.

3.2 Initial Use

This replacement remote control does not require any programming. Once the batteries are correctly installed, it is ready for immediate use with compatible LG TV models.

4. Operating Instructions

4.1 General Usage

To operate your television with the remote control, aim the remote directly at the infrared sensor on your TV. Ensure there are no obstacles between the remote control and the TV sensor that could block the signal.

4.2 Button Functions

The remote control features standard buttons for common television functions:

- **POWER**: Turns the TV on or off.
- **INPUT**: Selects the video input source (e.g., HDMI 1, AV, Component).
- **GUIDE**: Displays the electronic program guide (EPG).
- **TV/RAD**: Switches between TV and Radio modes.
- **Number Buttons (0-9)**: Directly enters channel numbers.
- **LIST**: Displays a list of channels.
- **MENU**: Accesses the TV's main menu.
- **Navigation Buttons (Up, Down, Left, Right, OK)**: Navigates through menus and confirms selections.
- **RETURN**: Returns to the previous screen or menu.
- **TEXT**: Activates or deactivates Teletext.
- **FAV**: Accesses favorite channels.
- **VOLUME (+/-)**: Increases or decreases the volume.
- **MUTE**: Mutes or unmutes the TV sound.
- **CHANNEL (P +/-)**: Changes channels up or down.
- **RATIO**: Adjusts the screen aspect ratio.
- **Color Buttons (Red, Green, Yellow, Blue)**: Used for specific functions within menus or interactive services.
- **SUBPAGE**: Navigates subpages in Teletext.
- **HOLD**: Holds the current Teletext page.
- **INDEX**: Displays the Teletext index page.

- **REVEAL**: Reveals hidden text in Teletext.
- **SUBTITLE**: Toggles subtitles on or off.
- **SLEEP**: Sets the sleep timer.
- **INFO**: Displays information about the current program or input.

5. Compatible Models

This ALLIMITY AKB33871409 Replacement Remote Control is compatible with the following LG LCD LED TV models:

- 19LG30 SERIES
- 22LG30 SERIES
- 26LG30 SERIES
- 19LG3010
- 19LG3000
- 22LG3010
- 22LG3000
- 19LG3000-ZA
- 22LG3000-ZA
- 26LG3000-ZA
- 19LG3010-ZB
- 22LG3010-ZB

If your specific model is not listed, but your original remote was an AKB33871409, this replacement should still be compatible. For further assistance, please contact the seller.

6. Maintenance

6.1 Battery Replacement

Replace batteries when the remote control's response becomes sluggish or stops working. Always replace both batteries at the same time with new AAA batteries. Do not mix old and new batteries, or different types of batteries.

6.2 Cleaning

To clean the remote control, gently wipe its surface with a soft, dry cloth. Do not use liquid cleaners, abrasive pads, or chemical solvents, as these can damage the remote's finish or internal components.

7. Troubleshooting

- **Remote not responding:**
  - Check if the batteries are inserted correctly with the correct polarity (+/-).
  - Replace the batteries with new ones.
  - Ensure there are no obstructions between the remote control and the TV's infrared sensor.
  - Confirm that the remote is aimed directly at the TV's sensor.
- **Some buttons not working:**
  - This remote is a direct replacement. If specific functions are not working, ensure your TV model is listed as compatible.
  - Clean the remote's surface, especially around the non-working buttons, to remove any debris.

8. Specifications

Feature	Detail
Model Number	AKB33871409 (Replacement)
Product Material	Plastic
Connective Technology	Infrared (IR)
Power Source	2 x AAA Batteries (not included)
Product Dimensions	7 x 2 x 0.7 inches (approx.)
Item Weight	2.46 ounces (approx.)
Compatible Devices	LG LCD LED Plasma Televisions
Max Number of Supported Devices	1 (Television)
Special Feature	Ergonomic Design

9. Warranty and Support

As a replacement remote control, specific warranty details may vary. For any questions regarding compatibility, functionality, or if you cannot find your specific TV model listed, please contact the seller directly through your purchase platform. They will be able to provide further assistance and support for your product.

© 2024 ALLIMITY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question