Braun HT5010

Braun HT5010 WH IDCollection Toaster User Manual

Model: HT5010

1. Introduction

Thank you for choosing the Braun HT5010 WH IDCollection Toaster. This manual provides essential information for the safe and efficient operation, maintenance, and care of your new appliance. Please read all instructions carefully before first use and keep this manual for future reference.

2. Important Safety Instructions

- Read all instructions before operating the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse the cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Contact customer service for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended household use.
- Oversize foods, metal foil packages, or utensils must not be inserted into a toaster as they may create a fire or risk of electric shock.
- A fire may occur if toasters are covered or touching flammable material, including curtains, draperies, walls, and the like, when in operation.
- Do not attempt to dislodge food when the toaster is plugged in.

- Do not operate unattended.
- The appliance is equipped with an automatic shut-off feature in case of blockage.

3. Product Overview

Familiarize yourself with the components of your Braun HT5010 WH IDCollection Toaster:

1. Toasting Slots (2)
2. Browning Control Dial (1-13 settings)
3. Function Buttons (Defrost, Reheat, Bagel, Cancel)
4. High-Lift Lever
5. Removable Crumb Tray
6. Warming Rack (removable)
7. Sandwich Insert (removable)
8. Dust Cover



Image 3.1: Front-side view of the Braun HT5010 WH IDCollection Toaster, showcasing its white and stainless steel design with control dial and buttons.

4. Setup

4.1 Unpacking

- Carefully remove the toaster and all accessories from the packaging.
- Remove any protective films or stickers from the appliance.
- Ensure all components listed in the "Product Overview" section are present.

4.2 First Use (Burn-off Cycle)

Before toasting food for the first time, perform a burn-off cycle to eliminate any manufacturing odors:

1. Place the toaster on a stable, heat-resistant surface away from flammable materials.
2. Plug the power cord into a suitable electrical outlet.
3. Set the browning control dial to the highest setting (13).
4. Lower the high-lift lever without any bread in the slots. The toaster will begin a cycle.
5. Allow the cycle to complete. A slight odor or smoke may be present; this is normal.
6. Repeat this process 2-3 times to ensure all odors are dissipated.
7. Unplug the toaster and allow it to cool completely before storage or further use.

5. Operating Instructions

5.1 Basic Toasting

1. Ensure the toaster is plugged in.
2. Place one or two slices of bread into the toasting slots. The automatic centering feature will position the bread for even browning.
3. Select your desired browning level using the browning control dial (settings 1-13). A lower number yields lighter toast, a higher number yields darker toast.
4. Press the high-lift lever down until it locks into place. The toasting cycle will begin.
5. Once the cycle is complete, the toast will automatically pop up. Use the high-lift lever to safely retrieve smaller items.
6. To stop the toasting cycle at any time, press the **Cancel** button.

5.2 Bagel Function

The bagel function toasts the cut side of the bagel while gently warming the outer side.



Image 5.1: The Braun HT5010 WH Toaster on a kitchen counter, with a toasted bagel and cream cheese on a plate nearby, demonstrating its use.

1. Cut the bagel in half and place one half in each toasting slot with the cut side facing inwards (towards the center of the toaster).
2. Select your desired browning level.
3. Press the **Bagel** button. The indicator light will illuminate.
4. Press the high-lift lever down until it locks. The toasting cycle will begin.
5. The toaster will automatically stop when the cycle is complete.

5.3 Defrost Function

Use this function to toast frozen bread without over-browning.

1. Place frozen bread slices into the toasting slots.
2. Select your desired browning level.
3. Press the **Defrost** button. The indicator light will illuminate.
4. Press the high-lift lever down until it locks. The toasting cycle will begin, automatically adjusting for frozen bread.
5. The toaster will automatically stop when the cycle is complete.

5.4 Reheat Function

This function warms already-toasted bread without further browning.

1. Place cold, already-toasted bread slices into the toasting slots.

2. Press the **Reheat** button. The indicator light will illuminate.
3. Press the high-lift lever down until it locks. The reheating cycle will begin.
4. The toaster will automatically stop when the cycle is complete.

5.5 Using the Warming Rack

The removable warming rack is ideal for warming croissants, pastries, or rolls.



Image 5.2: The Braun HT5010 WH Toaster with the removable warming rack positioned over the toasting slots, ready for use.

1. Place the warming rack securely over the toasting slots.
2. Place the items to be warmed on the rack.
3. Set the browning control dial to a low setting (e.g., 1 or 2).
4. Press the high-lift lever down until it locks.
5. Monitor the warming process to prevent over-browning. Press the **Cancel** button to stop at any time.
6. Carefully remove warmed items from the rack. The rack will be hot.

5.6 Using the Sandwich Insert

The removable sandwich insert allows for toasting sandwiches. Ensure the sandwich is not too thick to prevent jamming.

1. Prepare your sandwich. It is recommended to lightly butter the outside of the bread to prevent sticking to the insert.
2. Place the sandwich into the sandwich insert.
3. Insert the sandwich insert into a toasting slot.
4. Select your desired browning level.
5. Press the high-lift lever down until it locks.
6. Monitor the toasting process. Press the **Cancel** button to stop at any time.
7. Carefully remove the hot sandwich insert and sandwich.

6. Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the life of your toaster.

6.1 Crumb Tray Cleaning



Image 6.1: The Braun HT5010 WH Toaster with its removable crumb tray partially extended from the side, illustrating the cleaning process.

1. Always unplug the toaster from the power outlet and allow it to cool completely before cleaning.
2. Locate the crumb tray at the bottom of the toaster.
3. Pull the crumb tray out to remove it.
4. Discard accumulated crumbs.
5. Wipe the tray with a damp cloth, if necessary, and dry thoroughly.

6. Slide the crumb tray back into place until it locks securely.

6.2 Exterior Cleaning

- Ensure the toaster is unplugged and cool.
- Wipe the exterior surfaces with a soft, damp cloth.
- Do not use abrasive cleaners, scouring pads, or harsh chemicals, as these can damage the finish.
- Dry thoroughly with a soft cloth.

6.3 Storage

- Ensure the toaster is clean and completely cool before storing.
- Use the integrated cable storage to wrap the power cord neatly.
- Place the dust cover over the toasting slots to keep them clean.
- Store the toaster in a dry, safe place.

7. Troubleshooting

Problem	Possible Cause	Solution
Toaster does not turn on.	Not plugged in; power outlet malfunction; appliance malfunction.	Ensure the power cord is securely plugged into a working outlet. Test the outlet with another appliance. If the issue persists, contact customer support.
Bread is stuck in the slots.	Oversized bread; appliance malfunction.	Unplug the toaster immediately. Allow it to cool. Carefully remove the bread using non-metallic tongs. The toaster has an automatic shut-off feature for blockages.
Toast is unevenly browned.	Inconsistent bread thickness; initial use; crumb buildup.	Ensure bread slices are of uniform thickness. Perform a burn-off cycle if it's a new toaster. Clean the crumb tray regularly. The toaster features automatic bread centering for even browning.
Smoke or burning smell.	Crumb buildup; food stuck; initial use.	Press the **Cancel** button and unplug the toaster. Allow to cool. Clean the crumb tray thoroughly. Remove any food particles from the slots. A slight smell is normal during first use.

8. Specifications

Brand	Braun
Model Number	HT 5010 WH
Color	White/Silver
Dimensions (L x W x H)	26 x 16 x 19.4 cm
Weight	1 kg
Power	1000 W
Material	Plastic, Stainless Steel

Number of Slots	2
Browning Levels	13 (adjustable)
Special Features	Automatic bread centering, High-lift function, Bagel function, Defrost function, Reheat function, 4-way safety, Removable crumb tray, Sandwich insert, Dust cover, BPA-free parts in contact with food.

9. Warranty and Support

For warranty information, please refer to the warranty card included with your product or visit the official Braun website. For technical support, spare parts, or service, please contact Braun customer service in your region. Keep your proof of purchase for warranty claims.
You can find more information and contact details on the official Braun website: www.braunhousehold.com

© 2023 Braun. All rights reserved.