Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SupplySource PSS/200309/022

SupplySource AC Adapter Charger Instruction Manual

Model: PSS/200309/022

Introduction

This manual provides essential instructions for the safe and effective use of your SupplySource AC Adapter Charger. This adapter is designed to provide power to compatible devices, specifically the NordicTrack Rower RW500 NTRW59140. Please read this manual thoroughly before use and retain it for future reference.

Setup Instructions

Follow these steps to properly set up your AC adapter:

1. **Verify Compatibility:** Ensure your device, such as the NordicTrack Rower RW500 NTRW59140, requires a power supply with the specifications provided by this adapter. Check your device's power input requirements.
2. **Inspect the Adapter:** Before connecting, visually inspect the adapter and its cable for any signs of damage. Do not use if damaged.
3. **Connect to Device:** Locate the power input port on your NordicTrack Rower. Carefully insert the barrel connector of the AC adapter into the device's power port. Ensure a firm and secure connection.
4. **Connect to Power Outlet:** Plug the AC adapter into a standard 100-240V wall outlet. Ensure the outlet is easily accessible and not overloaded.



Image: The SupplySource AC Adapter Charger, showing the main unit and connected power cable.

Operating Instructions

Once connected, the adapter will supply power to your device. Observe the following for optimal operation:

- **Power On:** After connecting the adapter to both the device and the power outlet, your device should receive power. Refer to your device's manual for specific power-on procedures.
- **Stable Current:** This adapter is designed to ensure efficient and stable current delivery to your device.
- **Safety Features:** The adapter incorporates multiple safety features, including protection against incorrect voltage (IV), short circuits (SC), and internal overheating (IO).
- **Cable Management:** Ensure the cable is not kinked, pinched, or placed under heavy objects to prevent damage and maintain strong power output.



Image: Close-up of the adapter's cable, highlighting its length and features for stable current and strong power output.

Maintenance

Proper maintenance ensures the longevity and safe operation of your adapter:

- **Cleaning:** Disconnect the adapter from the power outlet and your device before cleaning. Use a dry, soft cloth to wipe the exterior. Do not use liquid cleaners or solvents.
- **Storage:** When not in use, store the adapter in a cool, dry place away from direct sunlight and extreme temperatures. Avoid wrapping the cable too tightly.
- **Handling:** Avoid dropping the adapter or subjecting it to strong impacts. Do not attempt to open or modify the adapter.

Troubleshooting

If you encounter issues with your AC adapter, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device not receiving power	Loose connection, faulty outlet, incompatible device	Ensure all connections are secure. Test the outlet with another device. Verify the adapter's compatibility with your device's power requirements.
Adapter feels hot	Normal operation, poor ventilation, overloaded circuit	A slight warmth is normal. Ensure adequate ventilation around the adapter. Disconnect if excessively hot and check for overloaded circuits.
Adapter does not fit device	Incorrect model or connector type	Double-check your device's model number and power input specifications against the adapter's compatibility. This adapter is specifically for NordicTrack Rower RW500 NTRW59140.

Product Specifications

Feature	Detail
Brand	SupplySource
Model Number	PSS/200309/022
Input Volt Range	100-240V
Input Frequency	50-60Hz
Cable Length	4FT
Connector Type	Barrel Connector
Compatible Devices	NordicTrack Rower RW500 NTRW59140
Special Features	Short Circuit Protection, Over Voltage Protection, Over Current Protection, Over Temperature Protection, Over Charge Protection
Certifications	CE, FCC
Material	Metal, Plastic
Item Weight	2.89 ounces
Package Dimensions	3.9 x 3.11 x 1.69 inches

Warranty Information

This SupplySource AC Adapter Charger comes with a**24-month warranty** from the date of purchase. This warranty covers manufacturing defects and ensures the product meets its stated specifications under normal use. Please retain your proof of purchase for warranty claims.



Image: The AC adapter highlighting its built-in safety electronics and the 24-month warranty.

Customer Support

For any questions, concerns, or assistance with your SupplySource AC Adapter Charger, please contact our customer support team. Refer to your purchase documentation or the seller's contact information for support details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B085NQSG65

More documents and user manuals: **https://manuals.plus/**