gb 620000109

gb Qbit + All City Compact Lightweight Travel Stroller User Manual

Model: 620000109

Introduction | Safety Information | Components | Setup | Operating | Maintenance | Troubleshooting | Specifications | Warranty & Support

1. Introduction

The gb Qbit + All City Compact Lightweight Travel Stroller is designed for comfort and convenience. Its super lightweight frame and four-wheel suspension provide a smooth ride, making it suitable for various terrains. The stroller features a one-hand fold mechanism, transforming it into a compact, portable package, ideal for travel.



Figure 1: Front view of the gb Qbit + All City Stroller in Night Blue.

2. Safety Information

WARNING: Failure to follow these warnings and instructions could result in serious injury or death.

- Never leave your child unattended in the stroller.
- Always use the restraint system (5-point harness) to secure your child.
- Ensure all locking devices are engaged before use.
- Do not overload the storage basket or hang items on the handle, as this may cause the stroller to become unstable.
- The stroller is suitable for infants and children up to 24.9 kg (55 lbs).
- Always engage the brakes when the stroller is stationary.
- Keep children clear of moving parts when making adjustments.
- This stroller is compatible with Cybex infant car seats using the included adapters (car seat sold separately). Always ensure the car seat is securely attached.

3. Package Contents

Your gb Qbit + All City Stroller package includes the following items:

- gb Qbit + All City Stroller unit
- Rain cover
- Adapters for Cybex infant car seat
- Rear wheels (may require attachment)

Video 1: Unboxing the gb Qbit + All-City Stroller. This video demonstrates the contents of the package and initial setup steps, including attaching the rear wheels.

4. Setup

4.1 Attaching Rear Wheels

1. Remove the rear wheels from their packaging.
2. Align each wheel with its respective axle on the stroller frame.
3. Push firmly until you hear a click, indicating the wheel is securely locked in place.

4.2 Unfolding the Stroller

The gb Qbit + All City Stroller features a one-hand unfolding mechanism:

1. Ensure the stroller is on a flat, stable surface.
2. Locate the folding release button/lever on the handlebar (refer to the operating videos for visual guidance).
3. Press the release button and pull the handlebar upwards firmly until the stroller frame locks into its open position. You should hear a click.
4. Verify that all parts are securely locked before placing a child in the stroller.

Video 2: Demonstrating the one-hand folding and unfolding of the gb Qbit + All City Stroller.

5. Operating the Stroller

5.1 Folding the Stroller

To fold the stroller into its compact form:

1. Ensure your child is removed from the stroller.
2. Locate the folding mechanism on the handlebar (often a button and a lever).
3. Press the safety button and simultaneously pull the lever to initiate the fold.
4. Push the handlebar downwards, allowing the stroller to collapse into its compact, self-standing position.



Figure 2: The gb Qbit + All City Stroller in its compact, folded state.



Figure 3: Side view of the gb Qbit + All City Stroller when folded.

5.2 Adjusting the Seat Recline

The seatback is adjustable with multiple recline positions to ensure your child's comfort, whether they are awake or napping.

1. Locate the recline adjustment strap or lever behind the seat.
2. To recline, squeeze the mechanism and gently lower the seatback to the desired position.
3. To raise, push the seatback up while holding the mechanism.

Video 3: Demonstration of adjusting the seat recline and canopy on the gb Qbit + All City Stroller.

5.3 Canopy Adjustment

The stroller features a canopy for sun protection. It can be extended or retracted as needed. The breathable mesh seatback also helps regulate your child's body temperature on warm days.

5.4 Engaging the Brakes

The stroller is equipped with a reliable brake system:

1. To engage the brakes, press down firmly on the brake pedal located near the rear wheels.
2. To release, lift the brake pedal upwards.
3. Always ensure the brakes are fully engaged when the stroller is stationary.

5.5 Harness System

The 5-point harness system secures your child safely in the seat.

1. Place your child in the seat.
2. Bring the shoulder straps over your child's shoulders and the waist straps around their waist.
3. Insert the buckles into the central buckle until they click.
4. Adjust the straps for a snug, secure fit without being too tight.

Video 4: A detailed review of the gb Qbit + All-City Stroller, including folding, unfolding, and features.

6. Maintenance

To ensure the longevity and safe operation of your stroller, follow these maintenance guidelines:

- **Cleaning:** Wipe clean with a damp cloth and mild soap. Do not use harsh abrasives or solvents.
- **Fabric Care:** The fabric is made of mesh and other materials. Refer to the care label for specific instructions.
- **Wheels:** Regularly check the wheels for wear and tear. Keep them free of dirt and debris.
- **Moving Parts:** Periodically check all moving parts, such as hinges and locking mechanisms, to ensure they operate smoothly. Lubricate if necessary with a silicone-based lubricant.
- **Storage:** Store the stroller in a dry, cool place away from direct sunlight when not in use.

7. Troubleshooting

If you encounter any issues with your gb Qbit + All City Stroller, please refer to the following common solutions:

- **Stroller not unfolding/folding smoothly:** Ensure all locking mechanisms are disengaged. Check for any obstructions in the folding joints. Apply a small amount of silicone lubricant to hinges if stiff.
- **Wheels not turning freely:** Check for debris (e.g., hair, lint) wrapped around the axles. Clean the wheels and axles thoroughly.
- **Brakes not engaging/disengaging:** Inspect the brake mechanism for obstructions. Ensure the brake pedal is fully depressed or lifted.
- **Harness not securing:** Check that all buckle components are correctly aligned and inserted. Adjust straps for a snug fit.

For persistent issues or concerns not addressed here, please contact gb customer support.

8. Specifications



Figure 4: Dimensions of the gb Qbit + All City Stroller.

Feature	Detail
Brand	gb
Model Number	620000109
Item Type Name	Qbit + All City
Color	Night Blue
Item Weight	17.2 Pounds

Feature	Detail
Folded Size	33.5"L x 17"W x 8"H
Item Dimensions (Unfolded)	33"L x 17"W x 41.7"H
Maximum Weight Recommendation	24.9 Kilograms
Age Range Description	Baby, Infant
Harness Type	5 Point
Stroller Type	Umbrella Stroller
Car Seat Compatible	Yes (with included adapters for Cybex infant car seat)
Number of Wheels	4
Stroller Brake System	Yes
Fabric Type	Mesh
Frame Material	Aluminum or Carbon Fiber
Care Instructions	Wipe Clean
Included Components	Rain cover, adapters for Cybex infant car seat

9. Warranty & Support

The gb Qbit + All City Stroller comes with a**2-year limited warranty** from the manufacturer.
For warranty claims, product support, or additional information, please visit the official gb Store or contact their customer service directly.
Official gb Store: gb Store on Amazon

© 2026 gb. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question