Ariete 4618

Ariete 4618 Airy Fryer XXL User Manual

Model: 4618 | Brand: Ariete

Introduction

Welcome to the user manual for your new Ariete 4618 Airy Fryer XXL. This appliance is designed to provide a healthy and convenient way to prepare your favorite fried foods with significantly less oil. Please read this manual thoroughly before first use to ensure safe and optimal operation.

Important Safety Instructions

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury to persons.

- Do not immerse the appliance, cord, or plug in water or other liquid.
- Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting.
- Keep the appliance out of reach of children.
- Do not block any air vents.
- Unplug from outlet when not in use and before cleaning.
- Do not operate any appliance with a damaged cord or plug.
- Do not place the appliance against a wall or other appliances. Leave at least 10 cm free space on the back and sides and 10 cm free space above the appliance.
- Hot air comes out through the air outlet opening. Keep your hands and face at a safe distance from the openings.

Product Overview

Familiarize yourself with the components of your Ariete Airy Fryer XXL.



Figure 1: Front view of the Ariete 4618 Airy Fryer XXL.



Figure 2: Digital control panel with pre-set programs for various food types.



Figure 3: Key features including hot air cooking, minimal oil usage, and large capacity.

The appliance features a large 5.5-liter basket, a digital touch control panel, and a robust design for efficient air frying.

Setup

1. **Unpacking:** Carefully remove the air fryer and all packaging materials. Keep packaging for future storage or disposal.
2. **Initial Cleaning:** Before first use, clean the basket and pan with hot water, dish soap, and a non-abrasive sponge. Wipe the inside and outside of the appliance with a damp cloth.
3. **Placement:** Place the appliance on a stable, horizontal, and level surface. Do not place the appliance on non-heat-resistant surfaces. Ensure adequate ventilation around the unit.
4. **Power Connection:** Plug the power cord into a grounded wall outlet.

Operating Instructions

Basic Operation

1. **Preheating:** For best results, preheat the air fryer for 3-5 minutes at the desired cooking temperature.
2. **Loading Food:** Pull out the basket from the appliance. Place ingredients inside the basket. Do not overfill the basket to allow for proper air circulation.
3. **Setting Temperature and Time:** Use the digital touch controls to set the desired temperature (up to 200°C) and cooking time.
4. **Starting Cooking:** Press the start button to begin the cooking process.
5. **Shaking/Turning:** Some foods may require shaking or turning halfway through the cooking time to ensure even browning.
6. **Completion:** The appliance will beep when the cooking time is complete. Carefully pull out the basket and remove the food.

Pre-set Programs

The Ariete 4618 Airy Fryer XXL comes with 7 pre-set programs for common dishes, simplifying your cooking experience. These programs automatically adjust temperature and time for optimal results.

- French Fries
- Chops
- Crustaceans
- Desserts
- Chicken
- Meat
- Fish

Refer to the control panel for specific temperature and time settings for each program, or adjust manually as needed.

Cooking Tips

- **Oil Usage:** The air fryer technology allows you to fry with only a spoonful of oil, making meals healthier without compromising taste.
- **Large Capacity:** The 5.5-liter basket can cook large quantities, up to 2.5 kg of fries, suitable for family meals.
- **Odor Reduction:** Unlike traditional deep fryers, the air fryer significantly reduces the dispersion of smoke and fried odors in your home.

Maintenance and Cleaning

Regular cleaning ensures the longevity and optimal performance of your air fryer.

1. **Unplug and Cool:** Always unplug the appliance and allow it to cool down completely before cleaning.
2. **Basket and Pan:** The removable basket is non-stick and easy to clean. Wash with hot water, dish soap, and a non-abrasive sponge. Do not use metal utensils or abrasive cleaning materials.
3. **Appliance Exterior:** Wipe the exterior of the air fryer with a damp cloth. Do not immerse the main unit in water.
4. **Interior:** Clean the inside of the appliance with a non-abrasive sponge or cloth.

Note: The appliance is not dishwasher safe.

Troubleshooting

Problem	Possible Cause	Solution
Air fryer does not work.	The appliance is not plugged in.	Plug the main plug into a grounded wall socket.
Food is not cooked evenly.	Basket is overloaded.	Reduce the amount of ingredients in the basket.
White smoke comes from the appliance.	Fat residues from previous use.	Clean the basket and pan thoroughly after each use.
Fresh fries are not crispy.	Not enough oil used or potatoes not dried properly.	Add a little more oil or ensure potatoes are dry before frying.

Specifications

Feature	Detail
Model Name	4618 Airy Fryer XXL
Brand	Ariete
Capacity	5.5 Liters
Output Wattage	1800 Watts
Voltage	230 Volts
Control Method	Touch
Max Temperature Setting	200 Degrees Celsius
Material	Stainless Steel, Aluminium
Product Dimensions (D x W x H)	37.5D x 37.5W x 37.5H Centimeters
Item Weight	5.1 Kilograms
Color	Black
Special Feature	Smart
Nonstick Coating	No
Dishwasher Safe	No (Basket is easy to clean manually)

Warranty and Support

Ariete products are manufactured to the highest quality standards. For information regarding warranty coverage, product registration, or technical support, please refer to the official Ariete website or contact their customer service. You can also visit the official Ariete Store on Amazon for more product information and support.

© 2024 Ariete. All rights reserved.