Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Gewa PS350188

Gewa PURE Violin Case (PS350188)

User Manual

Introduction

Welcome to the user manual for your new Gewa PURE Violin Case, model PS350188. This manual provides essential information on the features, proper use, and maintenance of your violin case to ensure the longevity and protection of your instrument. Please read this manual thoroughly before using the case.

Safety Information

- Always ensure the case latches are securely closed before lifting or transporting to prevent accidental opening and potential damage to your instrument.
- Avoid exposing the case to extreme temperatures or direct sunlight for prolonged periods, as this may affect the case material and the instrument inside.
- Do not place excessively heavy objects on top of the case, as this could cause structural damage.
- Keep the interior of the case clean and free of debris to prevent scratches or damage to your violin.
- When using the rucksack straps, ensure they are properly attached and adjusted for a balanced and secure carry.

Product Overview

The Gewa PURE Violin Case (PS350188) is designed to provide robust protection for your 4/4 violin. Its lightweight yet durable polycarbonate construction ensures excellent impact resistance while maintaining portability.



Figure 1: The Gewa PURE Violin Case in white, showcasing its sleek, closed design and durable polycarbonate exterior.



Figure 2: Interior view of the open case, highlighting the padded suspension system, bow holders, and accessory compartments.

Key Features:

- **Polycarbonate Outer Shell:** Provides lightweight yet extremely resistant protection against impacts.
- **Padded Suspension System:** Ensures your violin is securely positioned and protected from shocks.
- **Flexible GEWA Bow Bridge & Swivel Type Holder:** Designed for stable and secure storage of violin bows.
- **Detachable Accessory Pouch:** Convenient storage for rosin, tuners, and other small items.
- **Removable Padded Music Pocket:** Ideal for carrying sheet music without creasing.
- **Multiple Carrying Options:** Features a stable main handle, a practical side handle, and two detachable rucksack straps for versatile transport.
- **Silk Blanket:** Provides an additional layer of protection for your violin's finish.



Figure 3: Detail of the 'PURE GEWA' logo and the sturdy main handle, designed for comfortable carrying.



Figure 4: Close-up view of one of the robust latches, ensuring secure closure of the case.

Setup

1. **Unpacking:** Carefully remove the violin case from its packaging. Inspect for any signs of damage during transit.
2. **Attaching Rucksack Straps (Optional):** If you wish to use the case as a backpack, locate the two detachable rucksack straps. Attach the clips of each strap to the D-rings located on the back and bottom of the case. Adjust the strap length for comfortable carrying.
3. **Preparing the Interior:** Open the case using the latches. Ensure the silk blanket is properly unfolded and placed over the violin's body area for added protection.
4. **Placing the Violin:** Gently place your 4/4 violin into the padded suspension system. Ensure it sits snugly and is not forced into position.
5. **Securing Bows:** Place your violin bows into the flexible GEWA bow bridge and secure them with the GEWA swivel type holders.
6. **Accessory Storage:** Utilize the detachable accessory pouch for small items like rosin or a tuner. The removable padded music pocket can be used for sheet music.

Operating

- **Opening the Case:** To open, unlatch all four metal latches by pulling the lever outwards. Gently lift the lid.
- **Closing the Case:** Carefully lower the lid, ensuring it aligns correctly with the bottom half. Press each latch firmly until it clicks into place, indicating it is securely fastened. Verify all latches are closed before lifting.
- **Carrying:** Use the stable main handle for horizontal carrying, or the side handle for vertical carrying. For hands-free transport, utilize the attached rucksack straps.

Maintenance

- **Exterior Cleaning:** Wipe the polycarbonate exterior with a soft, damp cloth to remove dust and smudges. For stubborn marks, a mild soap solution can be used, followed by wiping with a clean, dry cloth. Avoid abrasive cleaners.
- **Interior Cleaning:** Periodically vacuum or gently brush the interior fabric to remove dust and lint. If necessary, spot clean with a very slightly damp cloth and allow to air dry completely before closing the case.
- **Latch Care:** Ensure the latches operate smoothly. If they become stiff, a small amount of silicone spray can be applied to the moving parts, avoiding contact with the case material.
- **Storage:** When not in use, store the case in a cool, dry place away from direct sunlight and extreme temperature fluctuations.

Troubleshooting

- **Case Not Closing Properly:** Ensure no items are obstructing the closing mechanism. Check that the lid is aligned correctly with the base.
- **Latches Sticking:** Clean any debris from the latch mechanism. A small amount of lubricant (e.g., silicone spray) can be applied if needed, as mentioned in the Maintenance section.
- **Rucksack Straps Detaching:** Verify that the clips are fully engaged with the D-rings. Ensure the straps are not excessively strained or twisted.
- **Instrument Not Fitting Snugly:** Double-check that the violin is a 4/4 size. Ensure no accessories are misplaced in the violin compartment, preventing proper seating.

Specifications

Attribute	Detail
Model Number	PS350188
Size	Oblong 4/4
Color	White
Body Material	Polycarbonate
Item Styling	Padded
Approximate Weight	2.4 kg (5.3 lbs)
Package Dimensions	33.86 x 11.81 x 8.27 inches

Warranty and Support

For warranty information or technical support regarding your Gewa PURE Violin Case, please refer to the documentation provided at the time of purchase or contact Gewa customer service directly. Contact details can typically be found on the official Gewa website or through your authorized dealer.
For further assistance, you may also visit the product page on Amazon:Gewa PURE Violin Case on Amazon

© 2023 Gewa. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B085XQ4R94

More documents and user manuals: **https://manuals.plus/**