SENSEA 3276200157500

SENSEA DOCCE Water-Saving Chrome Shower Head User Manual

Model: 3276200157500

Introduction

Welcome to the user manual for your SENSEA DOCCE Water-Saving Chrome Shower Head. This manual provides essential information on the product's features, installation, operation, maintenance, and troubleshooting. Please read this manual carefully before using your new shower head to ensure proper function and longevity.

Product Overview

Key Features

- **Water-Saving Design:** Equipped with a water-saving system, reducing water consumption by 15%.
- **5 Spray Settings:** Easily adjustable to provide various spray patterns including Rain, Massage, Foam, Mixed, and Drip.
- **Eco-Stop Function:** Allows you to temporarily pause water flow without altering the set temperature.
- **Durable Chrome Finish:** Lightweight and designed for long-lasting performance.
- **Easy Clean Nozzles:** Designed for simple cleaning and maintenance.

Product Components

The SENSEA DOCCE shower head package includes:

- 1 x SENSEA DOCCE Chrome Shower Head

Product Images







Front view of the SENSEA DOCCE chrome shower head, showcasing its sleek design and nozzle arrangement.


10,4 cm
24,2 cm

Diagram illustrating the dimensions of the shower head: 10.4 cm width and 24.2 cm length.



Close-up of the shower head face, highlighting the '15% Water Saving', 'Pause' function, and 'Easy Clean' nozzle features.



A hand demonstrating the adjustment of the shower head's spray settings by rotating the nozzle plate.



The shower head in operation, demonstrating the wide, gentle 'Rain' spray pattern.



The shower head in operation, demonstrating a more focused or 'Massage' spray pattern.

Installation

Before Installation

Ensure you have all necessary components and basic plumbing tools (e.g., adjustable wrench, plumber's tape). Turn off the main water supply to your shower before beginning installation.

Installation Steps

1. **Remove Old Shower Head:** Unscrew your existing shower head from the shower arm by turning it counter-clockwise. If it's difficult to remove, use an adjustable wrench.
2. **Clean Shower Arm Threads:** Clean any old plumber's tape or debris from the threads of the shower arm.
3. **Apply Plumber's Tape:** Wrap new plumber's tape (PTFE tape) clockwise around the threads of the shower arm 3-4 times.

This helps create a watertight seal.

4. **Attach New Shower Head:** Screw the SENSEA DOCCE shower head onto the shower arm by turning it clockwise. Hand-tighten first, then use an adjustable wrench for a final quarter-turn, being careful not to overtighten.
5. **Check for Leaks:** Turn on the main water supply and check for any leaks around the connection. If leaks occur, tighten slightly or reapply plumber's tape.

Operating Instructions

Adjusting Spray Settings

The SENSEA DOCCE shower head offers 5 distinct spray patterns. To switch between these settings, simply rotate the outer ring or the central dial on the shower head face. The available settings are:

- **Rain:** A gentle, full-coverage spray for a relaxing shower.
- **Massage:** A more focused, pulsating spray for muscle relief.
- **Foam:** A softer, aerated spray.
- **Mixed:** A combination of spray patterns.
- **Drip:** A concentrated, steady stream.

Eco-Stop Function

To temporarily pause the water flow without losing your desired water temperature, press the Eco-stop button located on the side of the shower head handle. Press it again to resume water flow.

Maintenance and Care

Cleaning the Shower Head

Regular cleaning will help maintain the performance and appearance of your shower head.

- **Easy Clean Nozzles:** The flexible silicone nozzles can be easily cleaned by gently rubbing them with your finger or a soft cloth to dislodge mineral buildup.
- **Chrome Finish:** Clean the chrome surface with a soft cloth and mild soap or a non-abrasive bathroom cleaner. Rinse thoroughly with water and dry with a soft cloth to prevent water spots.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, scouring pads, or harsh chemicals (e.g., ammonia, bleach-based cleaners) as they can damage the finish.

Descaling

If you notice reduced water flow or irregular spray patterns due to hard water deposits, you may need to descale the shower head. You can soak the shower head in a solution of equal parts white vinegar and water for a few hours, then scrub the nozzles and rinse thoroughly.

Troubleshooting

If you encounter issues with your SENSEA DOCCE shower head, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Low water pressure	Mineral buildup in nozzles; partially closed water valve; low household water pressure.	Clean nozzles (see Maintenance); ensure water valve is fully open; consult a plumber for household water pressure issues.
Leaking from connection	Improperly tightened connection; insufficient plumber's tape; damaged washer.	Ensure connection is tight but not overtightened; reapply plumber's tape; check and replace washer if damaged.
Difficulty changing spray settings	Mineral buildup preventing rotation.	Clean the spray plate and nozzles thoroughly to remove mineral deposits.
Eco-stop function not working	Internal mechanism obstruction or damage.	Ensure no debris is obstructing the button. If the issue persists, contact customer support.

Specifications

Brand	SENSEA
Model Number	3276200157500
Manufacturer	ADEO
Dimensions (L x W x H)	24 cm x 16 cm x 6 cm
Weight	200 grams
Color	Chrome
Material	Chrome
Finish	Chrome
Style	Modern
Shape	Round
Installation Type	Wall Mount
Number of Spray Patterns	5
Water Efficiency	Water-Saving (-15%)

Warranty and Support

Warranty Information

The SENSEA DOCCE Water-Saving Chrome Shower Head comes with a **3-year warranty** from the date of purchase. This warranty covers manufacturing defects under normal use. Please retain your proof of purchase for warranty claims.

Customer Support

For any questions, technical assistance, or warranty claims, please contact the retailer or SENSEA customer service. Refer to your purchase documentation for specific contact details.

© 2024 SENSEA. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question