Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Kokido RC26CBX/EU

Delta 200 Rechargeable Robotic Pool Cleaner User Manual

Model: RC26CBX/EU | Brand: Kokido

Introduction

The Kokido Delta 200 is a cordless robotic pool cleaner designed for efficient cleaning of various pool sizes. Its cable-free operation makes it highly versatile, suitable for both above-ground pools and built-in pools with flat bottoms. Featuring a patented "Stop & Go" system, this cleaner optimizes its cleaning path for thorough coverage.



Image: The Kokido Delta 200 Robotic Pool Cleaner, a compact black and blue device designed for autonomous pool cleaning.

Safety Information

No specific safety warnings are applicable beyond general electrical appliance safety and proper handling of pool equipment. Always ensure the device is fully charged and the charging port is securely sealed before placing it in water. Keep out of reach of children when not in use or during charging.

What's in the Box

- 1 x Rechargeable Robotic Pool Cleaner
- *(Additional accessories such as charger, filter bag, and retrieval hook may be included. Please check your packaging contents.)*

Setup

1. **Initial Charge:** Before first use, fully charge the robotic pool cleaner. Connect the charger to the device's charging port and plug it into a suitable power outlet. The indicator light will show charging status.
2. **Filter Installation:** Ensure the filter bag or cartridge is correctly installed inside the cleaner. Refer to the internal diagrams for proper placement.
3. **Preparation:** Remove any large debris from the pool surface before operating the cleaner. Ensure the pool water chemistry is balanced.
4. **Submerging the Cleaner:** Gently lower the cleaner into the pool. Allow it to sink to the bottom. Ensure no air bubbles are trapped inside the unit.

Operating Instructions

1. **Activating the Cleaner:** Once fully submerged, activate the cleaner according to the specific model's instructions. This usually involves pressing a power button or a magnetic switch.
2. **Cleaning Cycle:** The Delta 200 will begin its cleaning cycle, moving across the pool floor. Its "Stop & Go" system helps it navigate efficiently.
3. **Monitoring:** Periodically check the cleaner's progress. The device is designed to operate autonomously.
4. **Retrieval:** When the cleaning cycle is complete or the battery is low, the cleaner may automatically move to the pool edge. Use the provided retrieval hook (if applicable) or carefully lift the cleaner out of the water using its handle.
5. **Power Off:** Turn off the cleaner immediately after removal from the water to conserve battery life and prevent motor damage.

Maintenance

- **Filter Cleaning:** After each use, remove and thoroughly clean the filter bag or cartridge. Rinse it with a garden hose until all debris is removed.
- **Unit Cleaning:** Rinse the exterior of the cleaner with fresh water to remove any pool chemicals or debris.
- **Charging Port:** Ensure the charging port is clean and dry before charging. Always secure the charging port cover when the cleaner is in the water.
- **Storage:** Store the cleaner in a cool, dry place away from direct sunlight and extreme temperatures. Ensure it is fully charged before long-term storage.
- **Periodic Inspection:** Regularly inspect the wheels, brushes (if any), and other moving parts for wear and tear. Replace parts as needed.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Cleaner not moving or stopping prematurely.	Low battery, clogged filter, debris obstructing wheels/motor.	Fully charge the unit. Clean the filter. Check for and remove any obstructions.
Poor cleaning performance.	Clogged filter, dirty brushes, insufficient run time.	Clean the filter thoroughly. Clean or replace worn brushes. Ensure the cleaner runs for the recommended duration.
Cleaner floats or does not sink.	Air trapped inside the unit.	Gently rock the cleaner underwater to release trapped air before starting.
Charging indicator not working.	Charger not connected properly, faulty charger/battery.	Ensure secure connection. Test the outlet. Contact customer support if issues persist.

Specifications

Brand: Kokido

Model Name: RC26CBX/21/US

Item Model Number: RC26CBX/EU

Special Feature: Cordless, Rechargeable

Power Source: Battery Powered

Lithium Battery Voltage: 18 Volts

Control Method: App *(Note: While "App" is listed, the product description and other features suggest autonomous operation. Verify app functionality with manufacturer if needed.)*

Material: Metal

Color: Blau, Black

Product Dimensions: 11.81 x 3.54 x 9.45 inches

Item Weight: 12.85 pounds

Assembly Required: No

Efficiency: Cleaning Efficiency

UPC: 844268014030

Warranty and Support

For warranty information and customer support, please refer to the documentation included with your product or visit the official Kokido website. Keep your purchase receipt as proof of purchase for any warranty claims.

© 2024 Kokido. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0861V1XRS

More documents and user manuals: **https://manuals.plus/**