KITCHMIX WT-330T

KitchMix Retro Stainless Steel 2-Slice Toaster (Model WT-330T) Instruction Manual

Model: WT-330T

Safety Instructions | Parts Identification | Setup | Operating Instructions | Maintenance & Cleaning | Troubleshooting | Specifications

Introduction

Thank you for purchasing the KitchMix Retro Stainless Steel 2-Slice Toaster. This manual provides essential information for the safe and efficient operation of your new appliance. Please read all instructions carefully before use and retain this manual for future reference.

Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or toaster in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.

- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- To disconnect, turn any control to 'off', then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Oversize foods, metal foil packages, or utensils must not be inserted in a toaster as they may involve a risk of fire or electric shock.
- A fire may occur if toasters are covered or touching flammable material, including curtains, draperies, walls, and the like, when in operation.
- Do not attempt to dislodge food when toaster is plugged in.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to 'off', then remove plug from wall outlet.
- This appliance is for household use only.
- The toaster features Anti-overheat protection and anti-leakage protection for enhanced safety.

Parts Identification

Familiarize yourself with the components of your KitchMix toaster:



The KitchMix Retro 2-Slice Toaster in cream color, featuring two wide slots with bread inserted, ready for toasting. The control panel with buttons and a dial is visible on the front.

- **Toasting Slots:** Two 1.5-inch extra-wide slots accommodate various bread types, including thick slices and bagels.
- **High Lift Lever:** Used to lower and raise bread into the toasting slots. The high lift feature allows for easy retrieval of smaller items.
- **Shade Control Dial:** Adjusts the browning level from 1 (lightest) to 6 (darkest).
- **CANCEL Button:** Stops the toasting cycle at any time.
- **BAGEL Button:** Toasts the cut side of bagels while gently warming the other side.
- **DEFROST Button:** Defrosts and toasts frozen bread in one cycle.
- **Removable Crumb Tray:** Located at the bottom, slides out for easy cleaning of crumbs.
- **Cord Wrap Storage:** Located on the underside for neat cord management.



A detailed view of the toaster's control panel, highlighting the 'CANCEL', 'BAGEL', and 'DEFROST' function buttons for easy selection.

Setup

1. **Unpack:** Carefully remove the toaster and all packaging materials.

2. **Placement:** Place the toaster on a stable, heat-resistant surface, away from flammable materials. Ensure adequate ventilation around the toaster.
3. **First Use (Burn-off):** Before toasting food, operate the toaster without bread on the highest setting (6) for a few minutes. This will burn off any manufacturing residues and eliminate initial odors. It is normal for a slight odor or smoke to be present during this process.
4. **Power Connection:** Plug the power cord into a standard 110V electrical outlet.

Operating Instructions

Follow these steps for optimal toasting results:



A visual guide demonstrating the simple steps to use the toaster: 1. Insert bread, 2. Press down the lever, 3. Set the shade knob, 4. Automatically pop up, 5. Clean the removable tray, 6. Store the cord.

1. **Insert Bread:** Place slices of bread, bagels, or other items into the toasting slots. The 1.5-inch wide slots accommodate various thicknesses.
2. **Select Shade Setting:** Turn the shade control dial to your desired browning level, from 1 (lightest, approx. 70 seconds) to 6 (darkest, approx. 220 seconds).
3. **Lower Bread:** Press the high lift lever down until it locks into place. The toasting cycle will begin.
4. **Special Functions:**

- **BAGEL:** Press the BAGEL button after lowering the bread for specialized bagel toasting.
- **DEFROST:** Press the DEFROST button after lowering the bread for toasting frozen items.

5. **Cancel Toasting:** To stop the toasting cycle at any time, press the CANCEL button. The bread will automatically pop up.
6. **Automatic Pop-Up:** Once the selected toasting cycle is complete, the bread will automatically pop up. Use the high lift lever to safely retrieve smaller items.

Maintenance & Cleaning

Regular cleaning ensures optimal performance and longevity of your toaster.



The KitchMix Toaster with its slide-out crumb tray partially removed, demonstrating the ease of cleaning. Toasted bread slices are visible next to the toaster.

1. **Unplug:** Always unplug the toaster from the power outlet and allow it to cool completely before cleaning.
2. **Clean Crumb Tray:** Slide out the removable crumb tray from the bottom of the toaster. Discard accumulated crumbs. Wipe the tray with a damp cloth and dry thoroughly before reinserting.
3. **Exterior Cleaning:** Wipe the exterior of the toaster with a soft, damp cloth. Do not use abrasive cleaners or metal scouring pads, as these can scratch the surface.

4. **Interior Cleaning:** Do not insert any objects into the toasting slots to clean. If food becomes lodged, unplug the toaster and carefully remove it once cooled.
5. **Storage:** When not in use, ensure the toaster is clean and dry. Use the cord wrap storage on the underside to keep the power cord tidy.

Troubleshooting

Problem	Possible Cause	Solution
Toaster does not turn on.	Not plugged in; power outage; faulty outlet.	Ensure toaster is securely plugged in. Check circuit breaker. Try a different outlet.
Bread does not toast evenly.	Uneven bread thickness; crumbs in slots.	Ensure bread slices are of similar thickness. Clean crumb tray regularly.
Smoke or burning smell.	Food lodged in slots; excessive crumbs; first use burn-off.	Unplug and remove any lodged food. Clean crumb tray. Initial burn-off is normal. If persistent, discontinue use.
Lever does not stay down.	Toaster not plugged in; internal malfunction.	Ensure toaster is plugged into a live outlet. If problem persists, contact customer support.

Specifications

- **Brand:** KITCHMIX
- **Model Number:** WT-330T
- **Color:** Cream
- **Material:** Stainless Steel
- **Product Dimensions:** 12.2"D x 7.48"W x 7.28"H
- **Specific Uses For Product:** Bagel, Toast, Defrost
- **Wattage:** 825 watts
- **Number of Slices:** 2
- **Special Feature:** Automatic Shut-Off
- **Style:** Retro
- **Finish Type:** Printed
- **Voltage:** 110V
- **Number of Settings:** 6 (browning levels)
- **Item Weight:** 3.87 pounds

Warranty and Support

For warranty information or customer support, please refer to the documentation included with your purchase or contact KitchMix customer service directly. Keep your proof of purchase for any warranty claims.

© 2026 KitchMix. All rights reserved.