Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Tefal FZ773840

Tefal ActiFry Genius+ FZ773840 User Manual

Healthy Air Fryer - Model FZ773840

Introduction

Welcome to the world of healthy and convenient cooking with your new Tefal ActiFry Genius+ FZ773840. This innovative air fryer is designed to make delicious, crispy meals with minimal oil, thanks to its unique automatic stirring paddle and intelligent programs. Please read this manual carefully before first use to ensure safe and optimal operation of your appliance.

Product Overview

The Tefal ActiFry Genius+ combines advanced technology with user-friendly features to deliver perfect results every time. Its intelligent design includes 9 automatic programs that adjust temperature and stirring for a variety of dishes.



Figure 1: Front view of the Tefal ActiFry Genius+ FZ773840 air fryer, showcasing its sleek black design and digital control panel.



Figure 2: Close-up of the digital screen and control panel, highlighting the intuitive interface for selecting programs and adjusting settings.



Figure 3: Illustration of the one-pot cooking capability, showing various ingredients like meat and vegetables being cooked together with the stirring paddle.



Figure 4: The ActiFry Genius+ alongside cooked food (fries and nuggets) and a smartphone displaying the companion recipe app, emphasizing the convenience and recipe support.

Key Features:

- **Ingenious Technology:** 9 automatic programs for perfect meals with minimal effort.
- **Automatic Stirring Paddle:** Ensures even cooking without manual intervention.
- **Recipe-Filled App:** Access over 300 recipes specifically designed for ActiFry.
- **Versatile Cooking:** Capable of one-pot meals, including curries and stews, not just fried foods.
- **Faster Cooking:** 30% faster than previous ActiFry Genius models.
- **Family-Sized Capacity:** Cooks up to 6 portions (1.2 kg capacity).

Setup

Unpacking and Initial Preparation:

1. Carefully remove all packaging materials and promotional labels from the appliance.
2. Wipe the exterior of the appliance with a damp cloth.
3. Wash the removable parts (pan, stirring paddle, lid) with warm soapy water or in a dishwasher. Rinse thoroughly and dry completely.
4. Place the appliance on a stable, flat, heat-resistant surface, away from walls or other appliances to ensure proper ventilation.
5. Ensure the power cord is not tangled or pinched.

Assembling the Appliance:

1. Insert the stirring paddle into its central position in the pan until it clicks into place.
2. Place the pan securely into the main unit.
3. Close the lid firmly until it locks.

Operating Instructions

Basic Operation:

1. Plug the appliance into a grounded electrical outlet. The digital display will illuminate.
2. Open the lid and add your ingredients to the pan. For best results, follow recipe guidelines for quantities.
3. Add the recommended amount of oil (if any) using the ActiFry measuring spoon.
4. Close the lid securely.
5. Select one of the 9 automatic programs using the control panel buttons. Each program is pre-set for specific food types (e.g., fries, nuggets, stir-fries).
6. Press the Start/Pause button to begin cooking. The appliance will automatically adjust temperature and stirring.
7. The appliance will beep when cooking is complete and automatically switch off.
8. Carefully open the lid (steam will escape) and remove your cooked food.

Manual Mode:

For custom recipes, you can use the manual mode to set your own cooking time and temperature.

1. After plugging in, select the manual program option.
2. Use the temperature and time adjustment buttons to set your desired cooking parameters.
3. Press Start/Pause to begin.

Using the ActiFry App:

Download the free ActiFry app from your device's app store. The app provides over 300 recipes with step-by-step instructions, optimized for your ActiFry Genius+.

Maintenance and Cleaning

Regular cleaning ensures the longevity and optimal performance of your ActiFry Genius+.

Daily Cleaning:

1. Always unplug the appliance and allow it to cool completely before cleaning.
2. Remove the lid, pan, and stirring paddle. These parts are dishwasher-safe.
3. Alternatively, wash them by hand with warm soapy water and a non-abrasive sponge. Rinse thoroughly and dry completely.
4. Wipe the main unit with a damp cloth. Do not immerse the main unit in water or any other liquid.
5. Ensure all parts are dry before reassembling or storing.

Deep Cleaning:

- For stubborn food residue, soak the removable parts in warm soapy water for a few minutes before washing.
- Do not use metal scouring pads, abrasive cleaners, or harsh chemicals, as these can damage the non-stick coating and plastic parts.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outage; faulty outlet.	Check power cord connection; check circuit breaker; try a different outlet.
Food is not cooking evenly.	Too much food; stirring paddle not installed correctly; lid not closed properly.	Reduce food quantity; ensure paddle is clicked into place; close lid securely.
Smoke coming from the appliance.	Excess oil or grease buildup; food residue.	Clean the appliance thoroughly; use recommended oil quantity. If smoke persists, unplug immediately.
Digital display shows an error code.	Internal malfunction.	Refer to the full troubleshooting guide in the comprehensive manual or contact customer support.

Specifications

- **Model:** FZ773840
- **Brand:** Tefal
- **Capacity:** 1.2 kg (up to 6 portions)
- **Power:** 1520 Watts
- **Voltage:** 230 Volts (AC)
- **Color:** Black
- **Dimensions (L x W x H):** 17.05 x 11.93 x 9.37 cm
- **Weight:** 5.02 Kilograms
- **Special Features:** Hands-free cooking, automatic stirring, 9 automatic programs.

Warranty and Support

Your Tefal ActiFry Genius+ FZ773840 comes with a standard manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions, including warranty period and coverage details.
For technical assistance, spare parts, or repair services, please contact Tefal Customer Service. Contact information can typically be found on the Tefal official website or on your product's warranty documentation.
Always ensure you have your model number (FZ773840) and proof of purchase ready when contacting support.

© 2024 Tefal. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B086B4819G

More documents and user manuals: **https://manuals.plus/**