Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

YING RAY 20200323-11

YING RAY Replacement Remote Control for Sharp Air Conditioner CRMC-A526JBEZ Instruction Manual

Introduction

This manual provides instructions for the setup, operation, and maintenance of your YING RAY Replacement Remote Control, model 20200323-11, designed for Sharp Air Conditioners using the CRMC-A526JBEZ remote.

Product Overview



Image of the YING RAY replacement remote control. It is white with gray buttons for SELECTOR, SLEEP, OFF TIMER, and TEMP (up/down arrows). A prominent red circular button is located in the center.

The YING RAY replacement remote control is a direct substitute for the original Sharp Air Conditioner remote control model CRMC-A526JBEZ. It features essential functions for controlling your air conditioning unit.

Setup

Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide open the battery compartment cover.
3. Insert two AAA 1.5V batteries, ensuring correct polarity (+ and -).
4. Close the battery compartment cover securely.

Note: No programming is required. The remote control is ready for use once batteries are installed.

Operating Instructions

Operating Instructions

Point the remote control directly at the air conditioner's receiver when operating.

- **SELECTOR Button:** Use this button to cycle through different operating modes of the air conditioner (e.g., Cool, Fan, Dry, Heat, Auto).
- **SLEEP Button:** Activates or deactivates the Sleep mode, which adjusts temperature and fan speed for comfortable sleep and energy saving.
- **OFF TIMER Button:** Sets a timer for the air conditioner to turn off automatically after a specified period. Refer to your air conditioner's manual for specific timer settings.
- **TEMP Up/Down Buttons (Arrows):** Adjusts the desired temperature setting. The up arrow increases the temperature, and the down arrow decreases it.
- **Red Circular Button:** This typically serves as the Power ON/OFF button for the air conditioner. Press once to turn on, press again to turn off.

Maintenance

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's range decreases or it stops responding. Always replace both batteries simultaneously with new ones of the same type (AAA 1.5V).
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage and damage.

Troubleshooting

- **Remote not responding:**
  - Check if the batteries are inserted correctly with the right polarity.
  - Replace old batteries with new AAA 1.5V batteries.
  - Ensure there are no obstructions between the remote and the air conditioner's receiver.
  - Confirm the remote is pointed directly at the air conditioner.
- **Limited range:**
  - Replace batteries.
  - Ensure no strong light sources (like direct sunlight) are interfering with the signal.

Specifications

Model Number	20200323-11
Compatible with	Sharp Air Conditioner Remote Control CRMC-A526JBEZ
Battery Type	2 x AAA 1.5V (not included)
Brand	YING RAY
Controller Type	Button Control
Special Feature	Ergonomic

Warranty Information

Specific warranty details for this replacement remote control are not provided in the product information. Please refer to the seller's return policy or contact the seller directly for warranty inquiries.

Support

For further assistance or questions regarding your YING RAY Replacement Remote Control, please contact the retailer or manufacturer directly. Ensure you have your product model number (20200323-11) and purchase details available when seeking support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B086BN4SMG

More documents and user manuals: **https://manuals.plus/**