AirMyFun A83004

AirMyFun Inflatable Bounce House User Manual

Model: A83004

1. Product Overview

The AirMyFun Inflatable Bounce House is a versatile outdoor play structure designed to provide hours of fun for children. It features a spacious jumping area, an exciting slide, a splash pool that can double as a ball pit, and an integrated water spray system for summer enjoyment. Constructed from durable, puncture-resistant nylon and tarpaulin material, this bouncer is built for safety and longevity.



Figure 1: A vibrant purple, orange, and green inflatable bounce house featuring a slide, a splash pool, and a water cannon, with two children playing.

2. Safety Information

WARNING: Failure to follow these instructions may result in serious injury or death.

- **Adult Supervision Required:** Always supervise children playing in the bounce house. Never leave children unattended.
- **Age and Weight Limits:** Suitable for children aged 3 to 12 years. Maximum total weight capacity is 350 lbs (158.76 kg). Do not exceed 3-4 children at a time.
- **Clear Area:** Ensure the setup area is clear of obstacles, sharp objects, and any potential hazards. Maintain a safe distance from fences, walls, and other structures.
- **No Sharp Objects:** Do not allow children to bring sharp objects, toys, or jewelry into the bounce house.
- **Weather Conditions:** Do not use in strong winds, heavy rain, or lightning. Deflate and secure the unit during adverse weather.
- **Proper Inflation:** Ensure the bounce house is fully inflated before use and remains inflated throughout play.
- **Secure Anchoring:** Always use the provided stakes to securely anchor the bounce house to the ground.
- **No Flipping or Rough Play:** Prohibit flipping, wrestling, or other overly rough play that could lead to injury.
- **Water Safety:** When using with water, ensure the splash pool depth is appropriate for the children's age and swimming ability. Do not allow children to dive headfirst.

3. Package Contents

Verify that all components listed below are present in your package:

- 1 x Inflatable bounce house
- 1 x Air blower (450W)
- 1 x Storage bag
- 4 x Bouncer stakes
- 4 x Air blower stakes
- 1 x Instruction sheet
- 2 x Various color patches
- 1 x Water spray hose assembly



Figure 2: An assortment of items included in the package: a purple storage bag, a yellow air blower, yellow ground stakes, an instruction sheet, colorful repair patches, a red mini basketball, a blue hand pump, and a water spray hose assembly.

4. Setup Instructions

1. **Choose a Location:** Select a flat, level, and clear outdoor surface, such as a lawn. Ensure there are no sharp objects, rocks, or debris.
2. **Unroll the Bounce House:** Lay the inflatable bounce house flat on the chosen surface, spreading it out completely.
3. **Connect the Blower:** Attach the air blower to the inflation tube of the bounce house. Ensure the connection is secure and airtight.
4. **Inflate the Unit:** Plug in the air blower and turn it on. The bounce house should inflate within 3 minutes. Ensure the blower runs continuously during use.
5. **Secure with Stakes:** Once fully inflated, use the provided bouncer stakes to anchor the bounce house firmly to the ground through the designated loops. Use the air blower stakes to secure the blower as well.
6. **Connect Water Hose (Optional):** If using the water spray feature, connect a standard garden hose to the water

spray assembly on the bounce house. Ensure all connections are tight to prevent leaks.

7. **Inspect Before Use:** Before allowing children to play, visually inspect the entire unit for any tears, punctures, or loose connections. Ensure the blower is operating correctly and the unit is fully inflated and stable.

5. Operating Instructions

Once the bounce house is properly set up and secured, children can begin to enjoy the various features:

- **Jumping Area:** Children can safely jump and bounce within the main enclosed area.
- **Slide:** Encourage children to slide down feet first. Ensure the landing area (splash pool) is clear.
- **Water Spray:** Turn on the water supply to activate the integrated water sprayers for a refreshing water park experience.
- **Ball Pit:** The splash pool can be filled with play balls (not included) to create a fun ball pit.



Figure 3: An aerial view of the inflatable water park filled with colorful balls and water, with children enjoying the slide and water spray, and an adult operating the water cannon.

6. Maintenance

- **Cleaning:** After use, especially with water, clean the bounce house with a mild soap solution and water. Rinse thoroughly.
- **Drying:** It is crucial to completely dry the bounce house before storage to prevent mold and mildew. Allow it to air dry in the sun, or use towels to absorb moisture.
- **Storage:** Once completely dry, deflate the unit by turning off the blower and allowing all air to escape. Fold or roll it neatly and store it in the provided storage bag in a cool, dry place away from direct sunlight and extreme temperatures.
- **Repairs:** Use the included repair patches for small punctures or tears. Clean the damaged area, apply the patch firmly, and allow it to cure according to patch instructions before re-inflating.

7. Troubleshooting

- **Bounce House Not Inflating:**
  - Check if the blower is plugged in and turned on.
  - Ensure the inflation tube is securely attached to the blower and there are no twists or kinks.
  - Verify that all zippers and air vents on the bounce house are closed.
  - Check for large tears or punctures that might be preventing inflation.
- **Water Spray Not Working:**
  - Ensure the garden hose is properly connected and the water supply is turned on.
  - Check for kinks in the water hose or the spray assembly.
  - Verify that the spray nozzles are not clogged.
- **Unit Losing Air:**
  - Confirm the blower is running continuously and is not obstructed.
  - Inspect for small punctures or tears and use the provided repair patches.
  - Ensure all seams and connections are intact.

8. Specifications

Feature	Detail
Product Dimensions (L x W x H)	10.5 x 9.4 x 10 Feet (approx. 320 x 286 x 305 cm)
Product Weight	35.5 Lbs (approx. 16.1 kg)
Blower Wattage	450W
Maximum Weight Capacity	350 Lbs (approx. 158.76 kg)
Recommended Age	3 to 12 years
Maximum Children	3-4 children
Material	Puncture-resistant 420D Nylon and Tarpaulin



Figure 4: A technical diagram illustrating the overall dimensions of the inflatable bounce house: 177.1 inches in length, 122 inches in width, and 74.8 inches in height.

9. Warranty and Support

For warranty information, product registration, or technical support, please refer to the official AirMyFun website or contact their customer service directly. Keep your purchase receipt as proof of purchase.

Contact Information: Please visit www.airmyfun.com for the most up-to-date contact details and support resources.

© 2023 AirMyFun. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question