Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HCDZ AK59-00156A

HCDZ Replacement Remote Control User Manual

For Samsung DVD/VCR Combo Players

1. Product Overview

This manual provides instructions for the HCDZ replacement remote control, designed for use with various Samsung DVD and VCR combo players. This remote is a direct replacement and requires no programming.

Compatible Samsung Models:

- AK59-00072A
- DVD-P270KR
- DVD-P375KD
- DVD-P376KD
- DVD-P470K
- DVD-P475KD



Image 1: Front view of the HCDZ replacement remote control. This image shows the general layout of the buttons on the remote.

2. Setup

2.1 Inserting Batteries

The remote control requires two (2) AAA batteries (not included). Follow these steps to insert them:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



Image 2: Back of the remote control with the battery cover removed, illustrating the battery compartment and correct battery orientation.



Image 3: Back of the remote control with the battery cover securely in place after battery insertion.

2.2 Initial Use

Once batteries are correctly inserted, the remote control is ready for immediate use. No programming or pairing is required. Point the remote directly at your Samsung DVD/VCR combo player.

3. Operation

3.1 Basic Functions

The remote control provides standard functions for your Samsung DVD/VCR combo player. Common buttons include:

- **Power:** Turns the device on or off.
- **Play/Pause:** Starts or pauses playback.
- **Stop:** Stops playback.
- **Fast Forward/Rewind:** Skips through content.
- **Volume Up/Down:** Adjusts the audio volume.
- **Channel Up/Down:** Changes channels (if applicable to your device).
- **Number Pad:** For direct input of track numbers or channels.

Refer to your Samsung DVD/VCR combo player's original manual for specific button functionalities if needed.

4. Maintenance

4.1 Cleaning

To clean the remote control, use a soft, dry cloth. For stubborn dirt, lightly dampen the cloth with water. Do not use harsh chemicals, abrasive cleaners, or immerse the remote in water.

4.2 Battery Replacement

Replace batteries when the remote's responsiveness decreases or it stops functioning. Always replace both batteries at the same time with new AAA batteries. Do not mix old and new batteries or different types of batteries.

5. Troubleshooting

5.1 Remote Not Responding

- **Check Batteries:** Ensure batteries are inserted correctly with the correct polarity (+/-) and are not depleted. Replace with fresh batteries if necessary.
- **Line of Sight:** Make sure there is a clear path between the remote control and the infrared sensor on your DVD/VCR player. Obstructions can block the signal.
- **Distance:** Operate the remote within a reasonable distance from the player.
- **Player Power:** Ensure your DVD/VCR player is powered on.

5.2 Intermittent Functionality

If the remote works intermittently, check for potential sources of infrared interference, such as direct sunlight, strong fluorescent lighting, or other electronic devices emitting IR signals.

6. Specifications

Feature	Detail
Model Number	AK59-00156A
Batteries Required	2 x AAA (not included)
Connectivity Technology	Infrared (IR)

Feature	Detail
Special Feature	No programming needed, works out of package

7. Warranty Information

Specific warranty details for this HCDZ replacement remote control are not provided in the product information. Please refer to the seller or manufacturer's website for any available warranty terms.

8. Support

If you continue to experience issues after following the troubleshooting steps, or for further assistance, please contact the seller or manufacturer directly. You may find additional support information on the HCDZ Brand Store on Amazon.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question