Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY RC311FUI1

ALLIMITY RC311FUI1 Remote Control User Manual

Model: RC311FUI1

Introduction

This manual provides comprehensive instructions for the ALLIMITY RC311FUI1 remote control, designed as a replacement for various TCL and Thomson 4K TV models. Please read this manual carefully before using the remote control to ensure proper operation and longevity.

Compatible TV Models:

- TCL Thomson 4K TV models: 50UB6406, U40S6906, U43S6916, U49C6916, U50S6806S, U50S6906, U50S7806S, U50S7906, U55C6916, U55S6006, U55S6806S, U55S6906, U55S7906, U55S8866S, U58S7806S, U65S7906.

Setup

Battery Installation

The ALLIMITY RC311FUI1 remote control requires two AAA alkaline batteries (not included). No special programming or configuration is needed. Simply insert the batteries, and the remote will be ready for use.

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch (if present) to open the compartment.
3. Insert two AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Close the battery compartment cover securely.



Image 1: Top-down view of the ALLIMITY RC311FUI1 remote control, showing the button layout. The battery compartment is located on the back.

Operating Instructions

To operate your TV, point the remote control directly at the TV's infrared sensor. Ensure there are no obstructions between the remote and the TV.

Button Functions



Image 2: Angled view of the ALLIMITY RC311FUI1 remote control, highlighting the ergonomic design and button arrangement.

Button	Function
Power (Red)	Turns the TV on or off.
Netflix	Direct access to the Netflix application.

Button	Function
TV	Switches to TV mode.
0-9 (Number Buttons)	Selects channels directly or enters numerical input.
ECO	Activates or deactivates Eco mode for power saving.
SOURCE	Selects input source (HDMI, AV, etc.).
Volume Up/Down (+/-)	Adjusts the TV volume.
Channel Up/Down (P+/P-)	Changes TV channels.
Mute	Mutes or unmutes the TV sound.
INFO	Displays program information.
OPTION	Accesses additional options or settings.
SmartTV	Direct access to Smart TV features.
GUIDE	Opens the electronic program guide.
Navigation Buttons (Up, Down, Left, Right)	Navigates through menus and options.
OK	Confirms selections.
MENU	Opens the main TV menu.
Back/Return (Curved Arrow)	Returns to the previous screen or menu.
EXIT	Exits the current menu or application.
ZOOM- / ZOOM+	Adjusts screen zoom level.
LIST	Displays a list of channels or other content.
PRE-CH	Switches to the previously viewed channel.
FAV	Accesses favorite channels or content.
Color Buttons (Red, Green, Yellow, Blue)	Functions vary depending on the TV menu or application.
SUBTITLE	Toggles subtitles on or off.
TEXT	Accesses teletext services.
CDLANG	Changes audio language (e.g., for multi-audio broadcasts).
Media Control Buttons (Play/Pause, Stop, Rewind, Fast Forward, Previous, Next)	Controls media playback (e.g., USB content, streaming apps).

Maintenance

Battery Replacement

Replace batteries when the remote control's response becomes sluggish or stops working. Always replace both batteries at the same time with new AAA alkaline batteries. Do not mix old and new batteries, or different types of batteries.

Cleaning

To clean the remote control, wipe it with a soft, dry cloth. Do not use liquid cleaners, sprays, or abrasive materials, as these can damage the remote's surface or internal components.

Storage

Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures. If the remote will not be used for an extended period, remove the batteries to prevent leakage.

Troubleshooting

Problem	Possible Cause / Solution
Remote not responding	• **Batteries are dead or inserted incorrectly:** Replace with fresh AAA alkaline batteries, ensuring correct polarity (+/-). • **Obstruction between remote and TV:** Ensure a clear line of sight to the TV's infrared sensor. Remove any objects blocking the path. • **Remote is too far from the TV:** Operate the remote within its effective range (up to 10 meters).
Some buttons not working	• **Dirty contacts:** Clean the remote control as described in the Maintenance section. • **Specific TV model incompatibility:** While this remote is broadly compatible, some advanced functions might vary or not be supported on all listed TV models.
Short operating range	• **Weak batteries:** Replace batteries. • **Interference:** Other electronic devices or strong light sources might interfere with the infrared signal. Try operating in a different environment.

Specifications

- **Brand:** ALLIMITY
- **Model:** RC311FUI1
- **Manufacturer:** MaxControlFactory
- **Compatible Devices:** TCL Thomson 4K TV models (refer to Introduction for full list)

- **Special Features:** Ergonomic design
- **Battery Type:** AAA Alkaline (not included)
- **Connectivity Technology:** Infrared
- **Maximum Operating Range:** 10 meters
- **Product Dimensions:** 6 x 0.5 x 17 cm (approximately)
- **Product Weight:** 50 g (approximately)

Warranty and Support

Information regarding specific warranty terms or direct customer support contacts is not provided in the product details. Please refer to your purchase documentation or contact the retailer for warranty claims and support inquiries.

This manual is for informational purposes only. ALLIMITY reserves the right to make changes without prior notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B086P7DZYG

More documents and user manuals: **https://manuals.plus/**