Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY SE-R0301 AH802276

ALLIMITY SE-R0301 AH802276 Remote Control Instruction Manual

For Toshiba DVD Disc Player Systems

Introduction

This instruction manual provides essential information for the proper use and maintenance of your ALLIMITY SE-R0301 AH802276 remote control. This remote is designed as a replacement for various Toshiba DVD Disc Player models, ensuring seamless operation without complex setup procedures. Please read this manual thoroughly before use.

Product Overview

The ALLIMITY SE-R0301 AH802276 remote control features an ergonomic design for comfortable handling and intuitive button placement for easy navigation of your Toshiba DVD player functions.





Image 1: Front view of the ALLIMITY SE-R0301 AH802276 remote control. This image displays the full layout of the remote, including all buttons for power, disc control, navigation, and special functions. The model number "SE-R0301" is visible at the bottom.

Button Functions:

- **ON/STANDBY:** Powers the DVD player on or off.
- **OPEN/CLOSE:** Opens or closes the disc tray.
- **DISPLAY:** Shows on-screen information.
- **Number Buttons (0-9, +10):** Direct track selection or input.
- **T-SEARCH:** Initiates title search.
- **MENU:** Accesses the DVD menu.
- **SETUP:** Enters the system setup menu.

- **Directional Arrows (Up, Down, Left, Right) & OK:** Navigates menus and confirms selections.
- **RETURN:** Returns to the previous menu or screen.
- **TITLE:** Accesses the DVD title menu.
- **F.R (Fast Reverse):** Rewinds playback.
- **F.F (Fast Forward):** Fast forwards playback.
- **PREV (Previous):** Skips to the previous track/chapter.
- **NEXT:** Skips to the next track/chapter.
- **STEP:** Advances playback frame by frame.
- **PLAY/PAUSE:** Starts or pauses playback.
- **STOP:** Stops playback.
- **REPEAT:** Repeats current track, chapter, or disc.
- **A-B:** Repeats a specified section.
- **SLOW:** Initiates slow-motion playback.
- **CLEAR:** Clears input or cancels a function.
- **SUBTITLE:** Toggles subtitle display.
- **ANGLE:** Changes viewing angle (if available on disc).
- **AUDIO:** Selects audio track.
- **ZOOM:** Zooms in on the picture.
- **RANDOM:** Plays tracks in random order.
- **PROG (Program):** Programs playback order.

Setup

Battery Installation:

1. Locate the battery compartment on the back of the remote control.
2. Slide open the battery cover.
3. Insert two new AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Close the battery cover securely.

Note: This remote control requires no additional programming or setup. Once batteries are installed, it is ready for use with compatible Toshiba DVD Disc Players.

Operating Instructions

To operate your Toshiba DVD Disc Player with the ALLIMITY SE-R0301 AH802276 remote control, point the remote directly at the infrared sensor on your DVD player. Ensure there are no obstructions between the remote and the device.

- **Power On/Off:** Press the **ON/STANDBY** button.
- **Disc Playback:**
    a. Press **OPEN/CLOSE** to open the disc tray.
    b. Place a DVD disc onto the tray.
    c. Press **OPEN/CLOSE** again to close the tray.
    d. Press **PLAY/PAUSE** to begin playback.

- **Navigation:** Use the directional arrow buttons (**Up, Down, Left, Right**) to move through menus and the **OK** button to confirm selections.
- **Volume Control:** (*Note: This remote primarily controls DVD player functions. Volume control is typically handled by your TV remote.*)

Maintenance

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new alkaline batteries.
- **Storage:** If the remote will not be used for an extended period, remove the batteries to prevent leakage. Store in a cool, dry place.

Troubleshooting

Problem	Possible Cause	Solution
Remote control not working.	• Batteries are depleted or incorrectly inserted. • Obstruction between remote and DVD player. • Remote control is out of range. • DVD player's infrared sensor is blocked or faulty.	• Replace batteries with new ones, ensuring correct polarity. • Remove any objects blocking the line of sight. • Move closer to the DVD player (within 10 meters). • Check the DVD player's sensor for obstructions or consult its manual.
Specific buttons not responding.	• Button may be stuck or damaged. • Function not supported by the specific DVD player model.	• Gently press the button multiple times. If still unresponsive, the button may be faulty. • Refer to your DVD player's manual to confirm feature compatibility.

Specifications

- **Model Number:** SE-R0301 AH802276
- **Brand:** ALLIMITY
- **Connectivity Technology:** Infrared
- **Special Feature:** Ergonomic design
- **Maximum Range:** 10 Meters
- **Battery Type:** 2 x AAA Alkaline (not included)
- **Compatible Devices:**

  Toshiba DVD Disc Player models including:

  - SD1010KB, SD-1010KB, SD1010KE2, SD-1010KE-2
  - SD1020KB, SD-1020KB, SD1020KE, SD-1020KE
  - SD170EK, SD-170EK
  - SD180E, SD-180E, SD180EKE, SD-180EKE
  - SD185EKB, SD-185EKB, SD185EKTE, SD-185EKTE
  - SD186, SD-186, SD186EKE, SD-186EKE

- SD189EKE, SD-189EKE
- SD190EKB, SD-190EKB, SD190EKE, SD-190EKE
- SD191EKF, SD-191EKF
- SD280EKB, SD-280EKB, SD280EKE, SD-280EKE, SD280EKTE, SD-280EKTE
- SD280SS, SD-280SS
- SD281EKF, SD-281EKF
- SD3020KB, SD-3020KB, SD3020KE, SD-3020KE
- SD585KR, SD-585KR
- SD591KTR, SD-591KTR
- SD601KR, SD-601KR
- SD690KTR, SD-690KTR
- SD700KR, SD-700KR
- SD702KR, SD-702KR

Support

For further assistance or inquiries regarding your ALLIMITY remote control, please refer to the seller's contact information on your purchase platform or visit the ALLIMITY official website if available.

Warranty Information

Specific warranty details for this product may vary depending on the retailer and region of purchase. Please retain your proof of purchase for any warranty claims. For detailed warranty terms, consult the documentation provided with your purchase or contact the seller directly.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B086PQMJJ7

More documents and user manuals: **https://manuals.plus/**