Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Beurer HR 8000

Beurer HR 8000 Rotary Electric Shaver

User Manual

Introduction

The Beurer HR 8000 rotary electric shaver is designed for a precise and comfortable shave, adapting perfectly to facial contours. This manual provides detailed instructions for the safe and effective use, maintenance, and care of your device.



Figure 1: Beurer HR 8000 Rotary Electric Shaver. This image shows the main unit with its three rotary shaving heads, power button, and an LED display indicating battery charge.

Important Safety Warnings

Please observe the following precautions for safe and optimal use of your Beurer HR 8000 electric shaver:

- Do not use the shaver near water or while it is charging.
- Exercise caution when using removable attachments such as the pop-up trimmer and the 2-in-1 beard and sideburn styler.
- Do not leave the shaver charging for extended periods.

- Keep the device out of reach of children.
- Only use the provided power adapter for charging.

Package Contents

Verify that all items are present in the package:

- 1x Beurer HR 8000 Rotary Electric Shaver
- 1x Pop-up Trimmer (attached to the device)
- 1x 2-in-1 Beard and Sideburn Styler
- 1x Storage Pouch
- 1x Protective Cover for Shaving Head
- 1x Cleaning Brush
- 1x Power Cord / Adapter
- 1x Instruction Manual (this document)

Setup and Charging

Before first use, ensure your shaver is fully charged.

1. **Initial Charge:** Connect the power adapter to the shaver and plug it into a suitable power outlet. The LED display will show the charging progress. A full charge takes approximately 90 minutes.
2. **Battery Life:** A full charge provides approximately 60 minutes of shaving time.
3. **Quick Charge:** For a single quick shave, a 5-minute charge can provide enough power.
4. **Operation During Charging:** The shaver can be used while connected to the power supply.

Operating Instructions

Basic Shaving (Wet or Dry)

The Beurer HR 8000 is suitable for both dry and wet shaving, including use under the shower.

1. **Power On:** Press the power button to turn on the shaver.
2. **Shaving Technique:** Gently press the shaving heads against your skin and move the shaver in small, circular motions. The flexible shaving heads will adapt to the contours of your face and neck.
3. **For Dry Shaving:** Ensure your skin is clean and dry before shaving.
4. **For Wet Shaving:** Apply shaving foam or gel to your skin. The shaver is fully waterproof (IPX6) and can be rinsed under running water.
5. **Power Off:** Press the power button again to turn off the shaver.

Using the Pop-up Trimmer

The integrated pop-up trimmer is ideal for precise trimming of sideburns, mustaches, and defining beard lines.

1. **Activate Trimmer:** Locate the slider or button on the back of the shaver and push it upwards to extend the pop-up trimmer.
2. **Trimming:** Hold the shaver at a right angle to your skin and carefully trim the desired areas.
3. **Retract Trimmer:** Push the slider or button back down to retract the trimmer when finished.

Using the 2-in-1 Beard and Sideburn Styler

This attachment allows for more versatile beard styling and precise edge creation.

1. **Attach Styler:** Ensure the shaver is off. Remove the rotary shaving head unit by gently pulling it off. Attach the 2-in-1 styler accessory in its place until it clicks securely.
2. **Styling:** Use the styler to shape your beard or sideburns. It may include a comb attachment (e.g., 3mm) for uniform length.
3. **Remove Styler:** After use, turn off the shaver and carefully detach the styler. Reattach the rotary shaving head unit.

Maintenance and Cleaning

Regular cleaning ensures optimal performance and hygiene of your shaver.

1. **Daily Cleaning (Quick Rinse):** After each use, turn off the shaver. Open the hinged shaving head unit (if applicable, by pressing a release button) and rinse the shaving heads and the internal hair chamber thoroughly under warm running water. Shake off excess water and let it air dry.
2. **Thorough Cleaning:** For a more thorough cleaning, detach the shaving head unit completely. Use the provided cleaning brush to remove any trapped hair from the blades and the shaver body. You can also rinse the detached head unit under water.
3. **Drying:** Allow all parts to air dry completely before reassembling or storing the shaver. Do not use cloths or abrasive materials on the shaving heads.
4. **Lubrication:** Periodically, apply a drop of light machine oil (not included) to the shaving foils to maintain optimal performance.
5. **Storage:** Store the shaver in its protective pouch with the protective cover on the shaving head when not in use.

Troubleshooting

If you encounter issues with your Beurer HR 8000, refer to the following common solutions:

Problem	Possible Cause	Solution
Shaver does not turn on or operate.	Battery is depleted.	Charge the shaver for at least 90 minutes. Ensure the power adapter is correctly connected.
Poor shaving performance / pulling hairs.	Shaving heads are dirty or clogged with hair. Blades are dull.	Clean the shaving heads thoroughly as described in the Maintenance section. Consider replacing shaving heads if performance does not improve after cleaning (replacement heads sold separately).
Shaver makes excessive noise.	Hair accumulation or lack of lubrication.	Clean the shaver thoroughly. Apply a drop of light machine oil to the shaving foils.
LED display not working.	Device malfunction.	Ensure the device is charged. If the issue persists, contact Beurer customer support.

If the problem persists after attempting these solutions, please contact Beurer customer support.

Specifications

Model: Beurer HR 8000 (Article Number: 580.09)

Product Dimensions (L x W x H): 20.1 x 11.8 x 7.2 cm

Weight: 276.2 grams

Power Source: Battery-powered (Lithium-ion)

Battery Life: Approx. 60 minutes shaving time

Charging Time: Approx. 90 minutes (with quick charge function)

Water Resistance: IPX6 (fully waterproof)

Blade Material: Stainless Steel

Head Type: Rotary, three double-ring shaving heads

Special Features: Cordless, Removable head, Pop-up trimmer, 2-in-1 beard styler, LED battery display, Travel adapter, Charge indicator

Included Battery: 1 AA (likely refers to the internal Li-ion, or a mislabeling in source data)

Warranty and Support

Beurer products are manufactured with high quality standards. In case of any issues or for warranty claims, please contact your local Beurer customer service or the retailer from whom you purchased the product. Keep your proof of purchase for warranty purposes.
For more information, visit the official Beurer website or refer to the contact details provided in your product packaging.

© 2023 Beurer GmbH. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B086VYLDPX

More documents and user manuals: **https://manuals.plus/**