Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LONPOO LP-D01

LONPOO LP-D01 Portable CD Player User Manual

Model: LP-D01

1. Introduction

Thank you for purchasing the LONPOO LP-D01 Portable CD Player. This device offers versatile audio playback options including CD, FM radio, Bluetooth, AUX input, and USB playback. Its compact design and stereo speakers make it suitable for various environments. Please read this manual carefully before use to ensure proper operation and to maximize your listening experience.

2. Product Overview

2.1 Key Features

- Compact and portable design.
- Supports CD, CD-R, and CD-RW playback.
- Integrated 2x2 W RMS stereo speakers.
- FM Radio tuner (76.0-95.0 MHz).
- Bluetooth wireless connectivity.
- AUX audio input.
- USB playback.
- Headphone output.
- Multiple sound modes (Pop, Jazz, Rock, Classic, Flat).

2.2 Controls and Components

Familiarize yourself with the various parts and controls of your LONPOO LP-D01 CD Player:



Figure 1: Front and Rear Panel Controls of the LP-D01 CD Player. This image displays the layout of buttons, ports, and features on the device, including the CD door, volume controls, track navigation, play/pause, stop/repeat, mode selection, AUX IN, USB, headphone jack, FM antenna, handle, and AC IN terminal.

- **Power Button:** Turns the unit on or off.
- **CD Door (Open/Close):** Access for inserting or removing CDs.
- **Mode Button:** Switches between CD, FM, Bluetooth, USB, and AUX modes.
- **Volume - / + Buttons:** Adjusts the audio output level.
- **Previous/Skip (-) / Search (-) Buttons:** Navigates to the previous track/station or performs a backward search.
- **Next/Skip (+) / Search (+) Buttons:** Navigates to the next track/station or performs a forward search.
- **Stop/Repeat Button:** Stops playback or cycles through repeat modes (Repeat 1, Random, Repeat All).
- **Play/Pause/Scan Button:** Starts/pauses playback or initiates an FM radio scan.
- **Sound Quality (EQ) Button:** Selects different equalizer presets (Pop, Jazz, Rock, Classic, Flat).
- **AUX IN (Audio Input) Terminal:** Connects external audio devices via a 3.5mm audio cable.
- **USB Terminal:** Connects USB storage devices for MP3 playback.
- **Headphone Output Terminal:** Connects headphones for private listening.
- **FM Rod Antenna:** Extendable antenna for improved FM radio reception.
- **Handle:** For easy portability.

- **AC IN Terminal:** Connects the AC power adapter.

3. Setup

3.1 Power Connection

1. Ensure the unit is placed on a stable, flat surface.
2. Connect the supplied AC power adapter to the AC IN terminal on the back of the unit.
3. Plug the other end of the AC power adapter into a standard wall outlet.
4. Press the Power button to turn on the unit.

The unit can also be powered by batteries for portable use (batteries not included). Refer to the battery compartment for correct battery type and insertion.

4. Operating Instructions

4.1 General Operation

- **Power On/Off:** Press the **Power** button.
- **Volume Adjustment:** Use the **Volume -** or **Volume +** buttons.
- **Mode Selection:** Press the **Mode** button repeatedly to cycle through CD, FM, Bluetooth, USB, and AUX modes.
- **Sound Mode (EQ):** Press the **EQ** button to select Pop, Jazz, Rock, Classic, or Flat sound presets.

4.2 CD Playback

1. Press the **CD Door (Open/Close)** to open the CD compartment.
2. Carefully place a CD (CD, CD-R, or CD-RW) onto the spindle with the label side facing up.
3. Close the CD door firmly until it clicks.
4. Press the **Mode** button to select CD mode. The display will show "CD".
5. The CD will begin playing automatically. If not, press the **Play/Pause** button.
6. To skip tracks, press the **Next/Skip (+)** or **Previous/Skip (-)** buttons.
7. To fast forward/rewind, press and hold the **Next/Skip (+)** or **Previous/Skip (-)** buttons.
8. To stop playback, press the **Stop** button.
9. To repeat a track or all tracks, press the **Repeat** button repeatedly to cycle through Repeat 1, Random Play, and Repeat All.

4.3 FM Radio Operation

1. Extend the FM rod antenna for optimal reception.
2. Press the **Mode** button to select FM radio mode. The display will show the frequency.
3. **Automatic Scan:** Press and hold the **Play/Pause/Scan** button to automatically scan and store available FM stations.
4. **Manual Tuning:** Press the **Next/Skip (+)** or **Previous/Skip (-)** buttons briefly to fine-tune the frequency.
5. **Preset Stations:** Use the **Next/Skip (+)** or **Previous/Skip (-)** buttons to navigate through stored preset stations after an automatic scan.

4.4 Bluetooth Connection

1. Press the **Mode** button to select Bluetooth mode. The display will show "BT" and flash, indicating it's ready for

pairing.

2. Enable Bluetooth on your external device (smartphone, tablet, etc.).
3. Search for "LP-D01" in your device's Bluetooth settings and select it to pair.
4. Once paired, the display will stop flashing, and you can play audio from your external device through the CD player.
5. Control playback (play/pause, next/previous track) using your external device or the CD player's controls.

4.5 AUX Input

1. Connect one end of a 3.5mm audio cable (AUX line) to the**AUX IN** terminal on the CD player.
2. Connect the other end of the audio cable to the headphone jack or AUX output of your external audio device.
3. Press the **Mode** button to select AUX mode. The display will show "AUX".
4. Play audio from your external device. The sound will be output through the CD player's speakers.
5. Volume can be adjusted on both the CD player and your external device.

4.6 USB Playback

1. Insert a USB storage device containing MP3 audio files into the**USB** terminal.
2. Press the **Mode** button to select USB mode. The display will show "USB".
3. The unit will automatically detect and begin playing MP3 files from the USB device.
4. Use the **Next/Skip (+)** or **Previous/Skip (-)** buttons to navigate between tracks.
5. Press the **Play/Pause** button to pause or resume playback.

5. Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the unit. Do not use abrasive cleaners or solvents.
- **CD Care:** Handle CDs by their edges. Clean dirty CDs with a soft, lint-free cloth, wiping from the center outwards.
- **Storage:** When not in use for extended periods, unplug the unit and store it in a cool, dry place.
- **Antenna:** Handle the FM rod antenna gently to avoid damage.

6. Troubleshooting

Problem	Possible Cause	Solution
No power	Power adapter not connected; Batteries depleted or incorrectly inserted.	Check power adapter connection; Replace batteries or ensure correct polarity.
CD not playing	CD inserted incorrectly; CD is dirty or scratched; Unit is not in CD mode.	Reinsert CD correctly; Clean or replace CD; Press Mode button to select CD mode.
Poor FM reception	Antenna not extended; Weak signal.	Fully extend the FM rod antenna; Try repositioning the unit.
Bluetooth not pairing	Unit not in Bluetooth mode; External device's Bluetooth is off; "LP-D01" not selected.	Select Bluetooth mode; Enable Bluetooth on your device; Select "LP-D01" from your device's list.

Problem	Possible Cause	Solution
No sound from AUX/USB	Incorrect mode selected; Cable not fully inserted; Volume too low.	Ensure AUX/USB mode is selected; Check cable connections; Increase volume on both devices.

7. Specifications

Feature	Detail
Brand	LONPOO
Model Number	LP-D01
Connectivity Technology	AUX, Bluetooth, USB
Color	White
Bluetooth Support	Yes
Number of Speakers	2
Speaker Output	2x2 W RMS Stereo
FM Radio Frequency	76.0 - 95.0 MHz
Supported Disc Types	CD, CD-R, CD-RW
UPC	789371479843

8. Package Contents

The package includes the following items:



Figure 2: Contents of the LP-D01 package. This image shows the main unit, power cable, AUX cable, and user manual.

- 1 x LONPOO LP-D01 Portable CD Player
- 1 x AC Power Cable (1.2M, PSE Certified)
- 1 x AUX Audio Cable
- 1 x User Manual (Japanese/English)

9. Warranty and Support

LONPOO provides a 1-year warranty for this product. For any issues or support inquiries, please contact your retailer or LONPOO customer service. Keep your purchase receipt for warranty claims.

© 2026 LONPOO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B086W786WC

More documents and user manuals: **https://manuals.plus/**