Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

KREAFUNK 18194

KREAFUNK aCOUSTIC Portable Bluetooth Speaker User Manual

Model: 18194

1. Introduction

Thank you for choosing the KREAFUNK aCOUSTIC Portable Bluetooth Speaker. This manual provides essential information for setting up, operating, and maintaining your speaker. Designed for both indoor and outdoor use, the aCOUSTIC speaker delivers incredible clarity and depth of 360-degree sound, filling any room or outdoor space. Its water-resistant (IPX5) design makes it suitable for various environments, from your living room to the poolside.

2. What's in the Box

- KREAFUNK aCOUSTIC Portable Bluetooth Speaker
- Charging Cable (USB)

3. Product Overview

3.1 Front/Side View





Image: Front view of the KREAFUNK aCOUSTIC speaker in pink, showcasing its cylindrical design, perforated metal grille, and a brown leather strap with 'KREAFUNK' embossed on it.

3.2 Top Panel Controls



Image: Top view of the KREAFUNK aCOUSTIC speaker, showing the control panel with a central 'K' button (power/play/pause), a '-' button (volume down/previous track), and a '+' button (volume up/next track).

4. Setup

4.1 Charging the Speaker

Before first use, fully charge your aCOUSTIC speaker. A full charge takes approximately 5 hours and provides up to 30

hours of playtime.

1. Connect the included USB charging cable to the charging port on the speaker.
2. Connect the other end of the USB cable to a compatible USB power adapter (not included) or a computer's USB port.
3. The charging indicator light will illuminate during charging and turn off when fully charged.

4.2 Initial Bluetooth Pairing

Pair your speaker with your Bluetooth-enabled device (smartphone, tablet, laptop) to enjoy wireless audio.

1. Ensure the speaker is charged and powered off.
2. Press and hold the central 'K' button on the top panel for approximately 3 seconds until you hear a power-on sound and the Bluetooth indicator light begins to flash, indicating pairing mode.
3. On your device, go to Bluetooth settings and enable Bluetooth.
4. Select "aCOUSTIC" from the list of available devices.
5. Once connected, you will hear a confirmation sound, and the Bluetooth indicator light will become solid.

5. Operating Instructions

5.1 Power On/Off

- **Power On:** Press and hold the central 'K' button for 3 seconds.
- **Power Off:** Press and hold the central 'K' button for 3 seconds.

5.2 Bluetooth Connection

- After initial pairing, the speaker will automatically attempt to connect to the last paired device when powered on.
- If connection fails, ensure Bluetooth is enabled on your device and the speaker is within range.

5.3 Volume Control

- **Increase Volume:** Press the '+' button.
- **Decrease Volume:** Press the '-' button.

5.4 Playback Control

- **Play/Pause:** Press the central 'K' button once.
- **Next Track:** Press and hold the '+' button for 2 seconds.
- **Previous Track:** Press and hold the '-' button for 2 seconds.

5.5 Stereo Pairing (True Wireless Stereo - TWS)

Enhance your audio experience by pairing two aCOUSTIC speakers for true stereo sound.

1. Ensure both aCOUSTIC speakers are powered on and not connected to any Bluetooth device.
2. On one speaker (this will be the primary speaker), double-press the central 'K' button. You will hear a sound indicating it's searching for another speaker.
3. The two speakers will automatically connect to each other. You will hear a confirmation sound once connected.
4. Now, connect your device to the primary speaker via Bluetooth as described in section 4.2. The audio will play in stereo across both speakers.

6. Maintenance

To ensure the longevity and optimal performance of your KREAFUNK aCOUSTIC speaker, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe the speaker's surface. For stubborn dirt, slightly dampen the cloth with water. Do not use harsh chemicals, solvents, or abrasive cleaners.
- **Water Resistance:** The speaker is IPX5 water-resistant, meaning it can withstand splashes and light rain. Do not submerge the speaker in water or expose it to strong jets of water. Ensure the charging port cover is securely closed when near water.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To preserve battery life, avoid fully discharging the battery frequently. If storing for an extended period, charge the speaker to about 50% every few months.

7. Troubleshooting

Problem	Possible Cause	Solution
Speaker does not power on.	Battery is depleted.	Charge the speaker fully.
Cannot pair with Bluetooth device.	Speaker is not in pairing mode. Device's Bluetooth is off. Speaker is already connected to another device. Device is too far from speaker.	Ensure speaker is in pairing mode (flashing light). Turn on Bluetooth on your device. Disconnect from other devices or reset speaker. Move device closer to speaker (within 10 meters).
No sound or low volume.	Volume on speaker or device is too low. Speaker is not connected. Audio source issue.	Increase volume on both speaker and device. Ensure speaker is properly paired. Check audio source and playback on your device.
Sound distortion.	Volume too high. Low battery. Interference.	Reduce volume. Charge the speaker. Move speaker away from other electronic devices.
Cannot connect two speakers for stereo pairing.	Speakers are already paired to a device. Incorrect pairing procedure.	Ensure both speakers are disconnected from any device before attempting TWS pairing. Follow TWS pairing steps precisely (Section 5.5).

8. Specifications

Feature	Detail
Model Name	aCOUSTIC
Model Number	18194
Brand	KREAFUNK
Speaker Type	Surround Sound

Feature	Detail
Special Features	Hi Res Audio, Lightweight, 360 degree sound, Water Resistant (IPX5)
Connectivity Technology	Bluetooth, USB
Wireless Communication	Bluetooth
Compatible Devices	Laptop, Tablet, Smartphone
Power Source	Battery Powered (1 Lithium Ion battery required)
Battery Life	Up to 30 Hours
Charging Time	Approx. 5 Hours
Speaker Max Output Power	20 Watts
Product Dimensions (DxWxH)	2.95"D x 2.95"W x 6.46"H
Item Weight	1.12 Pounds
Material	Plastic, Metal
Color	Pink
Controller Type	Touchpad

9. Warranty and Support

Your KREAFUNK aCOUSTIC speaker comes with a**2-Year Limited Warranty** from the date of purchase. This warranty covers manufacturing defects in materials and workmanship under normal use.
For warranty claims, technical support, or any inquiries regarding your product, please contact KREAFUNK customer service through the official KREAFUNK website or your point of purchase. Please have your model number (18194) and proof of purchase ready when contacting support.

© 2024 KREAFUNK. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B086Z941RS

More documents and user manuals: **https://manuals.plus/**