Kalorik AFO 46045 SS

Kalorik MAXX Air Fryer Oven User Manual

Model: AFO 46045 SS

Introduction

The Kalorik MAXX Air Fryer Oven is a versatile 26-quart 10-in-1 countertop appliance designed to simplify your cooking experience. It combines the functions of an air fryer, toaster oven, and more, allowing you to fry, bake, toast, roast, rotisserie, braise, sear, dehydrate, broil, and warm meals with ease. Featuring powerful Turbo MAXX Technology and a spacious interior, this appliance is engineered for efficient and healthy cooking.



Image: The Kalorik MAXX Air Fryer Oven, showcasing its large capacity with a pizza and air-fried items visible through its French doors.

Setup

1. **Unpacking:** Carefully remove all packaging materials, including any internal packing. Retain packaging for future storage or shipping.
2. **Placement:** Place the appliance on a stable, heat-resistant, and level surface. Ensure adequate clearance (at least 6 inches) on all sides, especially the back and top, for proper ventilation. Do not place under cabinets due to heat and steam output.
3. **Initial Cleaning:** Before first use, wipe down the exterior with a damp cloth. Wash all accessories (air frying basket, baking tray, air rack, crumb tray, bacon tray, steak tray, rotisserie spit & forks, rack handle, rotisserie handle) with warm, soapy water. Dry thoroughly.
4. **First Use Burn-Off:** It is recommended to run the appliance empty for about 15-20 minutes at 400°F (200°C) to burn off any manufacturing residues. A slight odor or smoke may be present; this is normal. Ensure the area is well-ventilated.
5. **Power Connection:** Plug the appliance into a grounded electrical outlet.

Operating Instructions

The Kalorik MAXX Air Fryer Oven offers 10 versatile cooking functions and 21 smart presets for optimal results.

Key Features and Functions:

- **10-in-1 Versatility:** This appliance can Air Fry, Bake, Toast, Roast, Rotisserie, Braise, Sear, Dehydrate, Broil, and Warm.
- **Turbo MAXX Technology:** Experience accelerated cooking performance. This technology cooks French fries up to 22% faster, steak up to 37% faster, and chicken up to 27% faster compared to traditional ovens, while also saving over 77% in energy.
- **21 Smart Presets:** Utilize the intuitive digital interface to select from a variety of pre-programmed settings for common dishes like French fries, onion rings, chicken wings, shrimp, steak, and vegetables.
- **Large Capacity:** The 26-quart interior can accommodate a 14-pound turkey, a 12-inch pizza, or up to 9 slices of toast, making it suitable for family-sized meals.
- **Searing Capability:** Achieve perfectly caramelized proteins and vegetables by searing up to 500°F.
- **Modern French Door System:** Designed for single-hand opening, this system helps prevent scalding and dripping.

Using the Control Panel:

The digital control panel allows for easy selection of cooking modes, temperature, and time. Refer to the detailed user manual (PDF) for specific instructions on each preset and function.



Image: A detailed view of the digital control panel, showing temperature, time, and various cooking presets.

Cooking Examples:



Image: The oven in action, demonstrating the accelerated air flow of Turbo MAXX Technology for faster cooking.



Image: A large roast and vegetables cooking inside, showcasing the extra-large 26-quart capacity.



Image: Perfectly seared steaks, illustrating the oven's ability to reach 500°F for optimal caramelization.



Image: The French door system, designed for convenient and safe single-hand operation.

Accessories

The Kalorik MAXX Air Fryer Oven comes with 9 essential accessories to enhance your cooking versatility:

- Air Frying Basket
- Baking Tray
- Air Rack
- Crumb Tray
- Bacon Tray
- Steak Tray
- Rotisserie Spit & Forks

- Rack Handle
- Rotisserie Handle

A bonus cookbook is also included, featuring a diverse assortment of easy-to-follow, chef-inspired recipes.



Image: An illustration of the nine included accessories, such as the air frying basket, baking tray, and rotisserie kit.

Maintenance and Cleaning

Proper maintenance ensures the longevity and optimal performance of your Kalorik MAXX Air Fryer Oven.

- **Always unplug** the appliance and allow it to cool completely before cleaning.
- **Exterior:** Wipe the exterior with a clean, damp cloth. Do not use abrasive cleaners or scouring pads, as they may damage the stainless steel finish.
- **Interior:** The interior can be wiped with a damp cloth and mild detergent. For stubborn food residue, a non-abrasive sponge can be used. Ensure the interior is completely dry before next use.

- **Accessories:** All removable accessories are dishwasher-safe or can be washed by hand with warm, soapy water. Ensure they are thoroughly dried before storing or reinserting into the oven.
- **Crumb Tray:** Regularly remove and empty the crumb tray to prevent grease buildup and potential fire hazards. Wash and dry it after each use.

Troubleshooting

If you encounter issues with your Kalorik MAXX Air Fryer Oven, refer to the following common troubleshooting tips:

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet malfunction; main power switch off.	Ensure the power cord is securely plugged into a working outlet. Check the main power switch.
Food is not cooking evenly.	Overcrowding the basket/tray; incorrect temperature/time setting.	Do not overcrowd. Cook in smaller batches if necessary. Adjust temperature and time according to recipe or manual guidelines. Shake or flip food halfway through cooking.
White smoke coming from the appliance.	Grease/oil residue from previous use; high-fat food cooking.	Clean the crumb tray and interior thoroughly after each use. For high-fat foods, place a small amount of water in the crumb tray to reduce smoke.
Appliance emits a burning smell.	Food particles stuck inside; new appliance burn-off.	Ensure the interior and accessories are clean. If it's the first few uses, this is normal and should dissipate. If persistent, unplug and contact customer support.

For more detailed troubleshooting or issues not listed here, please refer to the official user manual or contact Kalorik customer support.

Specifications

- **Brand:** Kalorik
- **Model Name:** MAXX Air Fryer Oven
- **Item Model Number:** AFO 46045 SS
- **Color:** Stainless Steel
- **Product Dimensions:** 12.5"D x 15.75"W x 14"H
- **Capacity:** 26 Quart
- **Power:** 1700-Watts
- **Control Type:** Button Control
- **Door Style:** French Door
- **Temperature Range:** Up to 500°F
- **Item Weight:** 17.2 pounds
- **Country of Origin:** China
- **UPC:** 848052006874



Image: Product dimensions for placement and space planning.

Warranty and Support

For warranty information, product registration, or technical support, please refer to the official Kalorik website or the comprehensive User Manual provided with your appliance.
You can access the digital User Manual here.
Kalorik is committed to providing high-quality products and customer satisfaction. If you have any questions or require assistance, please do not hesitate to contact their customer service department.

© 2025 Kalorik. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question