Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Huntertall kitchen HT-2019A

Huntertall kitchen Hand Blender Mixer HT-2019A User Manual

Model: HT-2019A | Brand: Huntertall kitchen

1. Introduction

Thank you for purchasing the Huntertall kitchen Hand Blender Mixer HT-2019A. This manual provides essential information for the safe and efficient operation, maintenance, and care of your new appliance. Please read these instructions thoroughly before first use and keep them for future reference.
This ergonomic hand blender is designed for processing dips, sauces, soups, mayonnaise, baby food, and mixed drinks. Its powerful motor and multi-speed control make blending tasks quick and quiet.

2. Important Safety Instructions

- Read all instructions before using the appliance.
- To protect against electric shock, do not immerse the motor unit, cord, or plug in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
- Avoid contact with moving parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been dropped or damaged in any manner.
- The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock, or injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter or touch hot surfaces.
- Keep hands and utensils out of the container while blending to prevent the possibility of severe injury to persons or damage to the unit. A scraper may be used but only when the unit is not running.
- Blades are sharp. Handle carefully.
- Always operate the blender with the blade guard fully immersed in the liquid.
- Do not use the appliance for other than intended use.

3. Product Overview

The Huntertall kitchen Hand Blender Mixer HT-2019A features a powerful motor and a durable stainless steel blending shaft. It is designed for ease of use and cleaning.



Figure 1: Huntertall kitchen Hand Blender Mixer HT-2019A. This image shows the complete hand blender unit, highlighting its sleek design and stainless steel finish.

4. Setup

4.1 Assembly

The hand blender features a detachable shaft for easy assembly and cleaning.

1. Align the blending shaft with the motor unit.
2. Twist the shaft clockwise until it locks securely into place.
3. To detach, twist counter-clockwise and pull apart.



Figure 2: Key features of the hand blender, including the antiskid handle for comfortable grip, the detachable shaft for easy cleaning, and the durable 304 stainless steel cutter head.

4.2 Initial Use

Before first use, wash all parts that will come into contact with food. Ensure the unit is properly assembled and plugged into a standard 120 Volt outlet.

5. Operating Instructions

5.1 Powering On and Safety Lock

When plugged in, the indicator light on the top of the motor unit will be red, indicating it is in a safe, locked state. To activate the blender:

1. Press the indicator light button until it turns blue. This unlocks the power button.
2. Press and hold the power button on the side of the handle to begin blending.

The red light serves as a child safety lock, preventing accidental activation.

Your browser does not support the video tag.

Video 1: Demonstrates the assembly, safety lock (red/blue light), and variable speed control of the hand blender. The user shows how to detach the blending shaft, activate the blue light for operation, and adjust speeds by pressing the power button.

5.2 Blending

The hand blender features multi-speed control, allowing you to easily control the fineness of your food. The harder you press the power button, the faster the blade will spin, providing variable stepless speed control.

- Immerse the blending shaft into your ingredients.
- Press and hold the power button (now blue) to start blending.
- Adjust pressure on the button for desired speed.
- Move the blender up and down in the container for even blending.



Figure 3: Illustrates the multi-speed control feature of the hand blender, showing how varying pressure on the power button adjusts the blending speed from minimum to maximum.

5.3 Versatile Applications

This hand blender is ideal for a variety of tasks, from preparing baby food to making smoothies and sauces.



Figure 4: Highlights the hand blender as an essential tool for preparing complementary foods for babies of all ages, demonstrating its utility in a family kitchen setting.



Figure 5: Showcases the versatility of the hand blender, capable of handling different cooking ingredients for various uses such as smoothies, baking, and baby food preparation.

6. Maintenance and Cleaning

Proper cleaning ensures the longevity and hygiene of your hand blender.

1. Always unplug the appliance before cleaning.
2. The blending shaft with the blade is easily removable and top-rack dishwasher safe for quick cleanup.
3. To clean the blade, simply immerse the detachable shaft in clean water and run the blender for a few seconds.
4. Wipe the motor unit with a damp cloth. Never immerse the cord or motor unit in water or any other liquid.



Figure 6: Demonstrates the easy cleaning process of the hand blender by immersing the blending shaft in clean water and activating it to rinse the blade, ensuring hygiene after use.

7. Troubleshooting

- **Blender does not turn on:** Ensure the appliance is properly plugged into a working 120V outlet. Check that the safety indicator light is blue before pressing the power button. If the light is red, press it to activate.
- **Inconsistent blending:** Ensure the blending shaft is fully immersed in ingredients. Move the blender up and down to ensure all ingredients are processed evenly.
- **Overheating:** If the motor unit feels hot, unplug the appliance and allow it to cool down for at least 15-20 minutes before resuming use. Avoid continuous operation for extended periods.

8. Specifications

Feature	Specification
Brand	Huntertall kitchen
Model Number	HT-2019A
Power Source	Corded Electric
Wattage	300 watts
Voltage	120 Volts
Number of Speeds	5 (Variable Stepless Speed)
Blade Material	Stainless Steel
Item Weight	2.1 Pounds
Dishwasher Safe Parts	Yes (Blade/Shaft, Top Rack)
UPC	759337374031

9. Warranty and Support

9.1 Warranty Information

A 1-year hassle-free warranty is provided by Lanb for your convenience. Please retain your proof of purchase for warranty claims.

9.2 Customer Support

For any questions, concerns, or support needs regarding your Huntertall kitchen Hand Blender Mixer, please refer to the contact information provided with your product packaging or visit the manufacturer's official website.

© 2023 Huntertall kitchen. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0872TK296

More documents and user manuals: **https://manuals.plus/**