USHA Fontana Orchid

Usha Fontana Orchid 1280mm Ceiling Fan with Decorative Lights

Model: Fontana Orchid

Introduction

Thank you for choosing the Usha Fontana Orchid 1280mm Ceiling Fan. This fan is designed to provide efficient air circulation and enhance your living space with its integrated decorative lighting. This manual provides essential information for the safe installation, operation, and maintenance of your ceiling fan.

Key features include a stylish high-gloss electroplated motor with a removable underlight, wide-tip blades for high air delivery, and separate pull-chain controls for both the fan speed and the light.



An image of the Usha Fontana Orchid 1280mm Ceiling Fan, showcasing its gold ivory finish and integrated decorative light fixture.

Safety Instructions

Please read all safety instructions carefully before installing or operating the fan. Failure to follow these instructions may result in electric shock, fire, or personal injury.

- **Electrical Safety:** Ensure the main power supply is disconnected before installation, maintenance, or cleaning. All electrical connections must comply with local codes and standards.
- **Professional Installation:** Installation of ceiling fans should be performed by a qualified electrician to ensure proper wiring and secure mounting.
- **Mounting:** The fan must be mounted to a structure capable of supporting its weight (approximately 4.23 kg per fan). Ensure the mounting bracket is securely fastened to the ceiling joist or a suitable support structure.
- **Blade Clearance:** Maintain a minimum clearance of 2.3 meters (7.5 feet) from the floor to the fan blades and at least 0.5 meters (1.6 feet) from the wall to the blade tips.
- **Voltage:** This fan operates on 230 Volts. Verify your power supply matches this requirement.
- **Moving Parts:** Do not insert any objects into the path of the fan blades while the fan is operating.

Package Contents

The Usha Fontana Orchid 1280mm Ceiling Fan (pack of 2) includes the following components:

- Two (2) Fan Motors (Gold Ivory finish)
- Six (6) Fan Blades (three per fan)
- Two (2) Sets of Decorative Lights (integrated with motor housing)
- Two (2) Downrods and mounting hardware
- Two (2) Instruction Manuals
- Two (2) Warranty Cards

Setup and Installation

Detailed installation instructions are provided in the separate instruction manual included with your fan. It is highly recommended that a certified electrician performs the installation to ensure safety and proper functionality.

General Installation Steps (Refer to included manual for specifics):

1. **Power Disconnection:** Turn off power at the main circuit breaker before beginning installation.
2. **Mounting Bracket Installation:** Securely attach the mounting bracket to a ceiling joist or a suitable support structure using the provided hardware. This fan supports a Downrod Mount and Semi Flush Mount installation.
3. **Wiring:** Connect the electrical wires according to the wiring diagram in the instruction manual. Ensure all connections are secure and insulated.
4. **Fan Assembly:** Attach the downrod to the motor housing, then hang the fan assembly onto the mounting bracket.
5. **Blade Attachment:** Securely attach the three fan blades to the motor housing.
6. **Light Kit Installation:** Install the decorative light kit and any required bulbs (bulbs may not be included).
7. **Final Checks:** Double-check all connections and ensure the fan is securely mounted before restoring power.



A detailed view of the fan's electroplated motor housing and the integrated decorative light, highlighting the design elements.

Operating Instructions

The Usha Fontana Orchid ceiling fan features convenient pull-chain controls for both fan speed and lighting.

- **Fan Speed Control:** Locate the pull chain designated for fan speed. Each pull will cycle through the available speeds: Off → Speed 1 (Low) → Speed 2 (Medium) → Speed 3 (High) → Off. The fan has 3 speed settings.
- **Light Control:** Locate the pull chain designated for the decorative light. Each pull will toggle the light On or Off.

Ensure the fan is securely installed and all connections are tight before operating.



A close-up of the wide-tip blades of the Usha Fontana Orchid ceiling fan, designed for optimal air delivery.

Maintenance

Regular maintenance helps ensure the longevity and optimal performance of your ceiling fan.

- **Cleaning:** To clean the fan, wipe the surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents, as these can damage the finish. Ensure the power is off before cleaning.
- **Blade Cleaning:** Dust the fan blades regularly to prevent dust buildup, which can affect air delivery and cause imbalance.
- **Tightening Fasteners:** Periodically check all screws and fasteners on the fan and mounting hardware to ensure they are tight. Loose fasteners can cause wobbling or noise.
- **Light Bulb Replacement:** If the decorative light bulb needs replacement, ensure the power is off and the bulb has cooled before attempting to replace it. Use bulbs of the correct wattage and type as specified in the full

instruction manual.

Troubleshooting

If you experience issues with your Usha Fontana Orchid ceiling fan, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Fan does not start	No power supply; Loose wiring; Faulty pull chain	Check circuit breaker/fuse; Ensure all wires are securely connected; Pull chain firmly to cycle through speeds.
Light does not work	Loose bulb; Faulty bulb; Loose wiring; Faulty pull chain	Tighten or replace bulb; Check wiring connections; Pull light chain firmly.
Fan wobbles	Loose blades; Uneven blade balance; Loose mounting hardware	Ensure all blade screws are tight; Check for bent blades; Verify mounting bracket is secure.
Noisy operation	Loose screws; Motor issues; Blades hitting an obstruction	Tighten all screws; Ensure no wires are rubbing; Check blade clearance.

If the problem persists after attempting these solutions, please contact customer support.

Specifications

Brand	USHA
Model Name	Fontana Orchid
Model Number	111055447 (Part Number: GLI622)
Colour	Gold Ivory
Electric Fan Design	Ceiling Fan
Power Source	Electric
Product Dimensions (D x W x H)	40D x 22W x 23H Centimeters
Room Type	Dining Room, Bedroom (Indoor Usage)
Special Feature	High Velocity
Mounting Type	Downrod Mount, Semi Flush Mount
Controller Type	Pull Chain Control
Number Of Speeds	3
Wattage	70 Watts
Number of Blades	3
Voltage	230 Volts
Switch Type	Push Button (for light, via pull chain)

Material Type	Aluminium
Blade Material	Aluminium
Blade Length	1280 Millimetres
Item Weight	4230 Grams (per fan)
Finish Type	Glossy
Country of Origin	India

Warranty and Support

Your Usha Fontana Orchid 1280mm Ceiling Fan comes with a**1-year warranty** on the product from the date of purchase. Please retain your purchase receipt for warranty claims.

For warranty service, technical assistance, or any product-related inquiries, please contact Usha International Ltd. customer support. Refer to the warranty card included in your package for specific contact details and terms.

Manufacturer: Usha International Ltd

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question