**Camp4 706622**

# Camp4 Gas Cartridge Stove with Ignition Safety

Model: 706622

## Introduction

This user manual provides essential information for the safe and efficient operation of your Camp4 Gas Cartridge Stove, Model 706622. Please read this manual thoroughly before using the appliance and keep it for future reference. This cartridge stove features folding and collapsible legs for compact storage and comes with a practical storage case. It is designed for use with space-saving threaded gas cartridges and includes an ignition safety mechanism.

## Safety Information

***WARNING:*** Failure to follow these instructions could result in fire, explosion, or carbon monoxide poisoning, which could cause property damage, personal injury, or death.

- **For Outdoor Use Only:** This appliance is designed for outdoor use in well-ventilated areas. Never use it indoors, in tents, vehicles, or any enclosed space.
- **Ventilation:** Ensure adequate ventilation during operation to prevent carbon monoxide buildup.
- **Flammable Materials:** Keep the stove clear of all flammable materials, including tents, clothing, and other combustibles. Maintain a safe distance from walls and ceilings.
- **Gas Leaks:** Before each use, check for gas leaks. Apply soapy water to connections; bubbles indicate a leak. Do not use if a leak is detected.
- **Stable Surface:** Always place the stove on a firm, level, non-combustible surface.
- **Children and Pets:** Keep children and pets away from the stove during operation and while it is cooling down.
- **Unattended Operation:** Never leave the operating stove unattended.
- **Gas Cartridge:** Use only the type of gas cartridge specified by the manufacturer. Ensure the cartridge is correctly connected before ignition.
- **Hot Surfaces:** The stove and surrounding areas will become extremely hot during use. Allow sufficient time for cooling before handling or storing.
- **Storage:** Store the stove and gas cartridges in a cool, dry, well-ventilated area, away from direct sunlight and heat sources.

## Package Contents

Your Camp4 Gas Cartridge Stove package should include the following items:

- Camp4 Gas Cartridge Stove unit
- Practical Storage Case

## Setup

Follow these steps to set up your Camp4 Gas Cartridge Stove:

1. **Unpack:** Carefully remove the stove from its storage case and packaging.
2. **Unfold Legs:** Extend and lock the folding legs into their upright position. Ensure all four legs are stable and fully extended.
3. **Position Stove:** Place the stove on a stable, level, non-combustible surface, ensuring it is in a well-ventilated outdoor area.
4. **Connect Gas Cartridge:** Ensure the stove's control knob is in the 'OFF' position. Carefully screw the threaded gas cartridge onto the stove's gas inlet until hand-tight. Do not overtighten.
5. **Check for Leaks:** Before lighting, perform a leak test. Apply a soapy water solution to the gas connection. If bubbles appear, there is a leak. Tighten the connection or replace the cartridge if necessary. Do not proceed if a leak is present.



Image showing the Camp4 Gas Cartridge Stove with its legs unfolded for use (left) and folded for storage (right). Detailed views include the gas control knob, the threaded gas cartridge connection point, and the red ignition button.

## Operating Instructions

To operate your Camp4 Gas Cartridge Stove:

1. **Prepare:** Ensure the stove is set up correctly and the gas cartridge is securely connected. Have your cooking pot or pan ready.
2. **Ignite:** Slowly turn the control knob counter-clockwise towards the 'ON' or ignition position. You should hear the gas flowing. Immediately press the red ignition button (if equipped) repeatedly until the burner ignites.
3. **Adjust Flame:** Once ignited, adjust the flame intensity by rotating the control knob. Turn clockwise to decrease the flame and counter-clockwise to increase it.
4. **Cooking:** Place your cooking pot or pan centrally on the pot support. Monitor your cooking closely.
5. **Turn Off:** After use, turn the control knob fully clockwise to the 'OFF' position until the flame extinguishes completely.
6. **Cool Down:** Allow the stove to cool down completely before handling, cleaning, or storing. This may take several minutes.

## Maintenance

Proper maintenance ensures the longevity and safe operation of your stove:

- **Cleaning:** After each use and once the stove has cooled, wipe down the surfaces with a damp cloth. For stubborn stains, use a mild detergent. Do not use abrasive cleaners or solvents.
- **Burner Cleaning:** Keep the burner clean and free from food debris or blockages. Use a soft brush if necessary.
- **Inspection:** Regularly inspect the gas hose (if applicable), connections, and the stove body for any signs of wear, damage, or corrosion.
- **Storage:** When not in use, disconnect the gas cartridge and store the stove in its practical storage case in a cool, dry, well-ventilated place, away from direct sunlight and heat sources.

## Troubleshooting

If you encounter issues with your Camp4 Gas Cartridge Stove, refer to the following common problems and solutions:

| Problem | Possible Cause | Solution |
|---|---|---|
| Stove does not ignite. | Gas cartridge empty or improperly connected.<br>Ignition mechanism faulty.<br>Control knob not fully open. | Replace or re-connect gas cartridge. Check for leaks.<br>Ensure control knob is turned to ignition position.<br>If igniter fails, use a long match or lighter carefully. |
| Flame is weak or inconsistent. | Low gas level in cartridge.<br>Partial blockage in burner or gas line.<br>Cold weather affecting gas pressure. | Replace gas cartridge.<br>Clean burner and check for obstructions.<br>Warm the gas cartridge slightly (e.g., by holding it in your hands, never with direct heat). |
| Gas smell detected. | Gas leak from connections or cartridge. | Immediately turn off the stove and gas supply. Move to a well-ventilated area. Perform a leak test with soapy water. Do not use until the leak is resolved. |

## Specifications

Detailed technical specifications for the Camp4 Gas Cartridge Stove:

| Feature | Detail |
|---|---|
| Brand | Camp4 |
| Model Number | 706622 |
| Product Dimensions (L x W x H) | 30.5 x 22 x 12 cm (folded); 37 x 20 x 23 cm (unfolded, approximate) |
| Item Weight | 1.8 Kilograms |
| Material | Plastic (body), Metal (burner/pot support) |

| Feature | Detail |
|---|---|
| Fuel Type | Butane (threaded gas cartridge) |
| Power Source | Butane Gas Cartridge |
| Maximum Output Power | 2.4 Kilowatts |
| Gas Consumption | 175 g/h (grams per hour) |
| Automatic Shut-off Function | No |
| Spare Parts Availability | Information not available |

## Warranty and Support

Information regarding specific warranty terms for the Camp4 Gas Cartridge Stove is not provided in the product details. For warranty claims, technical support, or inquiries about spare parts, please contact the retailer where you purchased the product or refer to the official Camp4 website for their customer service contact information.
Always ensure you have your proof of purchase (receipt or order number) when contacting support.

© 2023 Camp4. All rights reserved. This manual is for informational purposes only.


### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question