Mabe LMA77113CBC

Mabe LMA77113CBC Aqua Saver Automatic Washing Machine User Manual

Model: LMA77113CBC | Brand: Mabe

1. Introduction

This manual provides essential information for the safe and efficient operation, installation, and maintenance of your Mabe LMA77113CBC Aqua Saver Automatic Washing Machine. Please read this manual thoroughly before using the appliance and keep it for future reference.

2. Safety Information

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, or injury to persons.

- Ensure the washing machine is properly grounded.
- Do not operate the machine if it is damaged or malfunctioning.
- Keep children and pets away from the appliance during operation.
- Do not wash items that have been soiled with flammable substances.
- Unplug the appliance before performing any maintenance or cleaning.
- Do not reach into the washer while the tub is moving.

3. Product Overview

The Mabe LMA77113CBC is a 17 kg top-load automatic washing machine designed for efficient and thorough cleaning. It features an agitator wash type and a durable stainless steel tub.



Figure 1: Front-side view of the Mabe LMA77113CBC washing machine. This image shows the control panel with four knobs, the top-load lid, and the overall white exterior of the appliance.



Figure 2: Front view of the Mabe LMA77113CBC washing machine. This image highlights the control panel at the top, the Mabe branding, and the clean, white finish of the appliance.

Key Features:

- **Capacity:** 17 kg
- **Wash Type:** Agitator
- **Tub Type:** Stainless steel
- **Control Type:** 4 Knobs, Push Button
- **Water Saving:** Up to 76% water per wash
- **Programs:** 11 automatic programs, plus manual soaking
- **Temperature Levels:** 5
- **Water Levels:** 4 + automatic
- **Dispenser:** Yes
- **Load Sensor:** Yes

4. Setup and Installation

Proper installation is crucial for the optimal performance and longevity of your washing machine. It is recommended to have the appliance installed by a qualified technician.

4.1 Unpacking

- Carefully remove all packaging materials, including the base packaging and any internal packing.
- Inspect the machine for any shipping damage. Contact your retailer immediately if damage is found.

4.2 Location Requirements

- Place the washing machine on a firm, level floor capable of supporting its weight (approximately 49.9 kg without packaging, 58.6 kg with packaging).
- Ensure there is adequate space around the machine for ventilation and access. Refer to specifications for dimensions.
- Avoid direct sunlight or extreme temperatures.

4.3 Water and Electrical Connections

- Connect the hot and cold water supply hoses to the corresponding inlets on the back of the machine. Ensure connections are tight to prevent leaks.
- Position the drain hose securely into a standpipe or laundry tub.
- Plug the power cord into a grounded electrical outlet. Do not use extension cords.

5. Operating Instructions

Follow these steps for effective and efficient washing.

5.1 Loading Laundry

- Sort laundry by fabric type, color, and soil level.
- Open the top lid and load items loosely around the agitator. Do not overload the machine. The maximum capacity is 17 kg.

- Close the lid securely.

5.2 Adding Detergent and Additives

- Add the recommended amount of detergent to the dispenser.
- If using fabric softener or bleach, add them to their respective compartments in the dispenser.

5.3 Selecting a Wash Cycle

The machine offers 11 automatic programs and manual soaking. Use the control knobs to select your desired settings:

- **Program Selection:** Turn the program knob to choose from cycles such as:
  - White
  - Color
  - Delicates
  - Jeans
  - Towels and Sheets
  - Self Cleaning
  - Sportswear
  - Baby Clothing
  - Cycle Fast
  - Bulky
  - Intensive
- **Water Level:** Select from 4 manual water levels or choose the automatic setting. The load sensor will adjust water automatically.
- **Temperature:** Choose one of the 5 available temperature levels.
- **Manual Programs:** A 'Soaking' option is available for pre-treatment.

5.4 Starting the Wash

- Press the Start/Pause button to begin the cycle.
- The lid insurance feature ensures the lid is locked during operation.

6. Maintenance and Care

Regular maintenance helps ensure the longevity and efficiency of your washing machine.

6.1 Cleaning the Exterior

- Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners.

6.2 Cleaning the Dispenser

- Periodically remove and clean the detergent dispenser drawer to prevent residue buildup. Rinse with warm water.

6.3 Tub Cleaning

- Utilize the 'Self Cleaning' program regularly to maintain the cleanliness of the stainless steel tub and prevent odors.

6.4 Water Inlet Filters

- Check and clean the water inlet filters periodically to prevent blockages and ensure proper water flow.

7. Troubleshooting

Before contacting service, refer to this section for common issues and their solutions.

- **Machine does not start:**
  - Ensure the power cord is securely plugged in.
  - Check if the lid is fully closed.
  - Verify that the water supply is turned on.
  - Check for tripped circuit breakers.
- **Water does not fill or fills slowly:**
  - Check if water faucets are fully open.
  - Inspect water inlet hoses for kinks or blockages.
  - Clean the water inlet filters.
- **Machine is noisy or vibrates excessively:**
  - Ensure the machine is level. Adjust leveling feet if necessary.
  - Check if the load is unbalanced. Redistribute laundry evenly.
  - Remove any shipping bolts if they were not removed during installation.
- **Clothes are not clean:**
  - Ensure correct detergent amount and type are used.
  - Do not overload the machine.
  - Select an appropriate wash cycle for the soil level.
  - Check water temperature settings.

8. Specifications

Feature	Detail
Brand	Mabe
Model Info	LMA77113CBC
Capacity	17 Kilograms
Installation Type	Freestanding
Color	White
Control Console	Push Button, 4 Knobs
Access Location	Top Load
Material Type	Metal (Tub: Stainless Steel)

Item Weight (without packaging)	49.9 kg
Item Weight (with packaging)	58.6 kg
Width without packaging	68 cm
Width with packing	73.32 cm
Height without packaging	111.63 cm
Height with packaging	118.11 cm
Depth without packaging	67.8 cm
Depth with packaging	72.39 cm
Number of automatic programs	11
Manual programs	Soaking
Temperature levels	5
Water Levels	4 + automatic
Water Saving	Up to 76% water per wash
First Available Date	20 April 2020

9. Warranty and Support

For warranty information and customer support, please refer to the warranty card included with your product or contact Mabe customer service. Keep your purchase receipt as proof of purchase.
For service or technical assistance, please have your model number (LMA77113CBC) and serial number ready.

© 2023 Mabe. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question