Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

XVEFAT RMT-AM120U

XVEFAT RMT-AM120U Replacement Remote Control User Manual

Model: RMT-AM120U | Brand: XVEFAT

1. Introduction

This manual provides comprehensive instructions for the XVEFAT RMT-AM120U replacement remote control. This remote is designed to operate various Sony Home Audio Systems without the need for programming or pairing. Simply insert batteries, and it is ready for use. Please read this manual thoroughly to ensure proper operation and to maximize your experience with the remote control.

2. Safety Information

- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Always remove exhausted batteries promptly to prevent leakage and damage.
- Keep batteries out of reach of children.
- Do not expose the remote control to direct sunlight, heat sources, or moisture.

3. Product Overview

The XVEFAT RMT-AM120U is a replacement remote control for specific Sony Home Audio Systems. It features a standard button layout for intuitive control over your audio system's functions.



Figure 1: Front view of the XVEFAT RMT-AM120U Replacement Remote Control. This image displays the ergonomic design and button layout, including power, display, timer, sleep, playback controls, sound field options, navigation, and volume adjustments.

Package Contents:

- 1x XVEFAT RMT-AM120U Remote Control

4. Setup

Battery Installation:

The remote control requires two (2) 1.5V AAA Alkaline batteries for operation. No programming or pairing is necessary after battery installation.

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch and lift to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.

The remote control is now ready for use with your compatible Sony Home Audio System.

5. Operating Instructions

Point the remote control directly at the infrared sensor on your Sony Home Audio System. Ensure there are no obstructions between the remote and the audio system.

Key Functions:

- ⏻/⏻ **(Power):** Turns the audio system on or off.
- **DISPLAY:** Changes the information displayed on the audio system's screen.
- **TIMER MENU:** Accesses timer settings.
- **SLEEP:** Sets a sleep timer for automatic power off.
- **PLAY MODE:** Selects playback modes (e.g., Normal, Shuffle, Repeat).
- **REPEAT/FM MODE:** Toggles repeat playback or switches FM radio modes.
- **PARTY LIGHT:** Controls party lighting features.
- **LIGHT MODE:** Adjusts light display modes.
- **MUSIC** / **VIDEO** / **FOOTBALL:** Selects sound field presets for different content types.
- **SUBTITLE** / **AUDIO** / **ANGLE:** Controls DVD/Blu-ray specific functions.
- **SETUP:** Accesses system settings.
- **MEDIA MODE:** Switches between different media inputs or modes.
- **CLEAR:** Clears entries or selections.
- **VOCAL FADER** / **MIC ECHO** / **KEY CONTROL** / **SCORE:** Controls karaoke or microphone-related functions.
- **Number Buttons (0-9):** For direct track selection, channel input, or other numerical entries.
- **DVD/TOP MENU** / **DVD/POP UP MENU:** Navigates DVD menus.
- **Directional Arrows (▲, ▼, ◄, ►) and Enter:** Navigates menus and confirms selections.
- **RETURN:** Goes back to the previous menu or screen.
- **OPTIONS:** Displays context-sensitive options.
- **MEGA BASS:** Enhances bass output.
- **FUNCTION:** Cycles through input sources or functions.
- **SEARCH:** Initiates search functions.
- **Volume (+/-):** Adjusts the master volume level.
- **TUNING (+/-)** / **PRESET (+/-):** For radio tuning or navigating preset stations.
- **Playback Controls (◀◀, ▶▶, ▶, ❚❚, ■):** Rewind, Fast Forward, Play, Pause, Stop.

Compatible Sony Home Audio Systems:

- MHC-V7D
- SHAKE-X7D
- MHC-GT3D
- MHC-GT5D
- SHAKE-X1D
- SHAKE-X3D

6. Maintenance

Cleaning:

To clean the remote control, wipe it gently with a soft, dry cloth. Do not use abrasive cleaners, solvents, or chemical wipes, as these may damage the surface or internal components.

Battery Replacement:

Replace batteries when the remote control's range decreases or if it stops responding. Always replace both batteries simultaneously with new AAA alkaline batteries.

7. Troubleshooting

Remote Control Not Responding:

- **Check Batteries:** Ensure batteries are inserted correctly with the correct polarity (+/-) and are not depleted. Replace with fresh AAA alkaline batteries if necessary.
- **Line of Sight:** Verify that there are no obstructions between the remote control and the infrared sensor on your audio system.
- **Distance:** Ensure you are within the effective operating range of the remote control.
- **Compatibility:** Confirm that your audio system model is listed as compatible with the RMT-AM120U remote control.

8. Specifications

Brand	XVEFAT
Model Name	RMT-AM120U
Compatible Devices	Sony MHC-GT3D, MHC-GT5D, MHC-V7D, SHAKE-X1D, SHAKE-X3D, SHAKE-X7D
Power Supply	2x 1.5V AAA Alkaline Batteries
Connectivity Technology	Infrared
Controller Type	Button Control
Color	Black
Special Feature	Ergonomic

Maximum Number of Supported Devices	7 (referring to the remote's capability, not simultaneous control)

9. Warranty and Support

For warranty information or technical support, please refer to the retailer or manufacturer's official website where the product was purchased. Keep your purchase receipt as proof of purchase.

© 2023 XVEFAT. All rights reserved. Sony is a registered trademark of Sony Corporation.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B087BQNL9X

More documents and user manuals: **https://manuals.plus/**