Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

NOBRAND KD-2328

KD-2328 Facial Steamer User Manual

Model: KD-2328

1. Introduction

The KD-2328 Facial Steamer is a beauty instrument designed to provide deep cleansing and promote better circulation for facial skin. By generating warm steam, it helps to open pores, allowing for the removal of impurities, dirt, and toxins, leading to a softer, healthier glow. This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your facial steamer.

2. Safety Information

Please read all safety warnings and instructions carefully before using this appliance to avoid injury or damage.

- Always ensure the power supply matches the appliance's requirements (220V/50Hz).
- Do not immerse the appliance in water or any other liquid.
- Keep out of reach of children.
- Do not use if the power cord or plug is damaged.
- Avoid touching the steam nozzle directly during operation as it emits hot steam.
- Only use distilled or purified water in the water tank to prevent mineral buildup.
- Unplug the steamer when not in use, before cleaning, or when refilling the water tank.
- Do not overfill the water tank beyond the MAX line.
- Ensure the appliance is placed on a stable, flat surface during use.

3. Product Overview

The KD-2328 Facial Steamer is a compact and efficient device designed for personal skin care. It features a rotatable nozzle for targeted steam application.



Figure 3.1: Main unit of the KD-2328 Facial Steamer. This image shows the complete white facial steamer with its transparent blue water tank and adjustable nozzle.



Figure 3.2: The 360-degree rotatable nozzle. This image illustrates the flexibility of the steam nozzle, allowing it to be rotated in a full circle for optimal positioning during use.

Components:

- Main Unit
- Water Tank (removable)
- Steam Nozzle (rotatable)
- Power Button
- Indicator Lights

4. Setup

1. **Unpack:** Carefully remove the facial steamer and all its components from the packaging.
2. **Placement:** Place the steamer on a firm, flat, and heat-resistant surface. Ensure it is near a power outlet and away

from water sources.

3. **Fill Water Tank:** Remove the water tank from the main unit. Fill the tank with distilled or purified water up to the 'MAX' fill line. Do not overfill.



Figure 4.1: Close-up of the water tank showing the 'MAX' fill line. This image highlights the maximum water level indicator on the transparent water tank, crucial for proper operation.



Figure 4.2: A hand indicating the 'MAX' fill line on the water tank. This image provides a visual reference for the correct water level when filling the tank.

4. **Insert Water Tank:** Securely place the filled water tank back into the main unit.
5. **Connect Power:** Plug the power cord into a suitable 220V/50Hz electrical outlet.

5. Operating Instructions

1. **Power On:** Press the power button to turn on the steamer. An indicator light will illuminate, signifying that the device is heating up.
2. **Pre-heating:** Allow a few minutes for the water to heat up and steam to begin emitting from the nozzle.
3. **Positioning:** Position your face approximately 20-30 cm (8-12 inches) away from the steam nozzle. Adjust the nozzle angle as needed using its 360-degree rotation feature to direct the steam comfortably onto your face.



Figure 5.1: The facial steamer actively emitting steam. This image demonstrates the steamer in operation, with visible steam being released from the nozzle.

4. **Steaming Duration:** For optimal results, steam your face for 8-10 minutes. If you have sensitive skin, start with shorter sessions (5 minutes).
5. **Post-Steaming:** After steaming, gently pat your face dry with a clean towel. Follow with your regular skincare routine, such as applying a mask, cleanser, or moisturizer, as your pores are now open and receptive.
6. **Power Off:** Press the power button again to turn off the steamer. Unplug the device from the power outlet.

6. Maintenance

Regular cleaning and maintenance will prolong the life of your facial steamer and ensure hygienic operation.

- **Empty Water Tank:** After each use, allow the steamer to cool down completely. Remove the water tank and empty any remaining water.
- **Clean Water Tank:** Rinse the water tank with clean water. For thorough cleaning, you can use a mild detergent and a soft brush, then rinse thoroughly.
- **Wipe Exterior:** Wipe the exterior of the steamer with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Descaling (Monthly):** If you notice reduced steam output or mineral buildup, descale the unit. Mix a solution of equal parts white vinegar and distilled water. Pour into the water tank up to the MAX line. Run the steamer for 5-10 minutes in a well-ventilated area. Power off, unplug, and let it cool. Empty the solution and rinse the tank and unit thoroughly with clean water several times to remove any vinegar residue.
- **Storage:** Store the steamer in a cool, dry place, away from direct sunlight and moisture.

7. Troubleshooting

Problem	Possible Cause	Solution
No steam or very little steam	• Water tank empty or low • Mineral buildup • Appliance not plugged in or powered on	• Refill water tank • Perform descaling procedure • Check power connection and press power button
Water leaking from unit	• Water tank not properly seated • Water tank overfilled	• Ensure water tank is securely in place • Do not fill past the MAX line
Unusual odor during use	• First use (normal) • Mineral buildup	• Odor should dissipate after a few uses • Perform descaling procedure

8. Specifications

Feature	Detail
Model	KD-2328
Material	Plastic
Color	White
Power	300W
Electric Requirement	220V/50Hz
Dimensions (Approx.)	Height: 33cm, Width: 14cm, Depth: 28cm (including arm)



Figure 8.1: Approximate dimensions of the KD-2328 Facial Steamer. This image provides a visual representation of the steamer's height, width, and depth, including the arm.

9. Warranty and Support

For warranty information or technical support, please refer to the retailer or point of purchase. As this product is listed under the brand 'NOBRAND', specific warranty details may vary. Please retain your purchase receipt for any warranty claims.

© 2023 NOBRAND. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B087BR8PX1

More documents and user manuals: **https://manuals.plus/**