Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

XVEFAT Universal Replacement Remote

XVEFAT Replacement Remote Control User Manual

For LG TV Models: 55LN5400, 39LN5300, 50LN5100, 47LN5200, 55LN5100, 55LN5200, 32LN530B, 32LN5300, 39LN5300, 42LN5300, 47LN5310

Introduction

This manual provides instructions for the XVEFAT replacement remote control, designed for various LG TV models. This remote control is a direct replacement and does not require any programming or pairing. Simply install batteries to begin use.

Setup

1. Battery Installation

The remote control requires two (2) 1.5V AAA alkaline batteries for operation. Follow these steps to install them:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover until it clicks securely into place.





Figure 1: Front view of the XVEFAT replacement remote control, showing various buttons for TV operation.

2. Initial Use

Once batteries are installed, the remote control is ready for immediate use. No programming or pairing with your LG TV is required. Point the remote control directly at your television and press the desired function button.

Operating Instructions

This remote control provides standard functions for operating compatible LG televisions. Below is a general overview of common button functions:

- **Power ( )**: Turns the TV on or off.
- **TV/Input**: Switches between different input sources (HDMI, AV, Component, etc.).
- **Number Buttons (0-9)**: Directly select channels.
- **VOL (+/-)**: Adjusts the volume level.
- **MUTE**: Mutes or unmutes the TV audio.
- **CH (Page Up/Down)**: Changes channels sequentially.
- **Navigation Buttons (Up, Down, Left, Right, OK)**: Navigate through menus and confirm selections.
- **BACK**: Returns to the previous menu or screen.
- **EXIT**: Exits the current menu or application.
- **SETTINGS**: Accesses the TV's main settings menu.
- **Q.MENU**: Accesses the Quick Menu for common settings.
- **LIST**: Displays the channel list.
- **INFO**: Displays information about the current program or input.
- **Color Buttons (Red, Green, Yellow, Blue)**: Used for specific functions within certain TV applications or menus, as indicated on screen.





Figure 2: Angled view of the XVEFAT replacement remote control, highlighting the ergonomic design and button layout.

Maintenance

Proper maintenance ensures the longevity and optimal performance of your remote control.

- **Cleaning**: Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as they may damage the surface or internal components.
- **Battery Replacement**: Replace batteries when the remote control becomes unresponsive or its range decreases. Always replace both batteries at the same time with new ones of the same type (AAA 1.5V).
- **Storage**: If the remote control will not be used for an extended period, remove the batteries to prevent leakage, which can damage the device.
- **Environment**: Avoid exposing the remote control to extreme temperatures, direct sunlight, high humidity, or liquids.

Troubleshooting

If you experience issues with your remote control, refer to the following common troubleshooting steps:

- **Remote Not Responding**:

- Check if the batteries are inserted correctly with the correct polarity (+/-).
- Replace old batteries with new AAA 1.5V alkaline batteries.
- Ensure there are no obstructions between the remote control and the TV's infrared sensor.
- Make sure you are within the effective operating range and pointing the remote directly at the TV.

- **Specific Buttons Not Working**:
  - Clean the remote control, especially around the unresponsive buttons, to remove any dirt or debris.
  - If cleaning and battery replacement do not resolve the issue, the button or remote may be faulty.
- **TV Not Turning On/Off**:
  - Verify that the TV itself is plugged into a power source and is not in a standby mode that prevents remote activation.
  - Confirm that your TV model is listed as compatible with this remote control.

Specifications

Brand	XVEFAT
Compatible Devices	LG Televisions (Models: 55LN5400, 39LN5300, 50LN5100, 47LN5200, 55LN5100, 55LN5200, 32LN530B, 32LN5300, 39LN5300, 42LN5300, 47LN5310)
Power Supply	2 x 1.5V AAA Alkaline Batteries (not included)
Connectivity Technology	Infrared (IR)
Color	Black
Special Feature	Ergonomic Design

Warranty and Support

For warranty information or technical support, please refer to the documentation provided at the time of purchase or contact the seller directly. Specific warranty terms and support channels are typically managed by the retailer or manufacturer.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B087M1GX8M

More documents and user manuals: **https://manuals.plus/**