Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

XVEFAT NS-50D510MX17, NS-50D510NA17, NS-55D510NA17

XVEFAT Replacement Remote Control User Manual

For Insignia TV Models: NS-50D510MX17, NS-50D510NA17, NS-55D510NA17

Introduction

This manual provides instructions for the XVEFAT replacement remote control, designed for use with specific Insignia TV models. Please read this manual carefully before using the remote control to ensure proper operation and longevity.
Compatible Insignia TV Models:

- NS-50D510MX17
- NS-50D510NA17
- NS-55D510NA17
- NS50D510MX17
- NS50D510NA17
- NS55D510NA17

Package Contents

The package should contain the following item:

- 1X XVEFAT Replacement Remote Control

Setup

The XVEFAT replacement remote control does not require any programming or pairing. Simply install the batteries to begin use.

Battery Installation

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch and lift to open the compartment.
3. Insert two (2) 1.5V AAA Alkaline batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



Image: Back view of the remote control, showing the battery compartment.

Note: Always use new alkaline batteries for optimal performance. Do not mix old and new batteries, or different types of batteries.

Operating Instructions

This section outlines the primary functions of the remote control buttons.



Image: Front view of the XVEFAT replacement remote control, displaying all buttons and their labels.

Button Functions:

Button	Function
POWER	Turns the TV on or off.
INPUT	Selects the input source (e.g., HDMI 1, AV, Component).
SLEEP	Sets the TV to turn off automatically after a specified time.

Button	Function
CCD	Activates or deactivates Closed Captioning.
GAME	Switches to Game Mode (if supported by TV).
PICTURE	Adjusts picture settings (e.g., brightness, contrast).
MENU	Opens the TV's main menu.
CH+ / CH-	Changes channels up or down.
VOL+ / VOL-	Increases or decreases volume.
MUTE	Mutes or unmutes the TV audio.
ENTER	Confirms selections within menus.
Directional Arrows	Navigates through menus and options.
EXIT	Exits the current menu or function.
INFO*	Displays program information.
Number Keys (0-9)	Direct channel selection.
- (Dash)	Used for entering sub-channels (e.g., 7-1).
(Return/Recall)	Returns to the previous channel.

Maintenance

Battery Replacement

If the remote control becomes unresponsive or its range decreases, the batteries may need to be replaced. Follow the battery installation steps outlined in the "Setup" section.

Cleaning

To clean the remote control, gently wipe its surface with a soft, dry cloth. Do not use liquid cleaners, solvents, or abrasive materials, as these can damage the remote.

Troubleshooting

Problem	Possible Cause / Solution
Remote control is not working.	• **Batteries:** Ensure batteries are inserted correctly with the correct polarity (+/-). Replace with new AAA alkaline batteries. • **Line of Sight:** Make sure there are no obstructions between the remote control and the TV's infrared sensor. • **Distance:** Ensure you are within the effective operating range of the TV's IR receiver. • **TV Compatibility:** Verify that your TV model is listed as compatible with this remote control.

Problem	Possible Cause / Solution
Some buttons are not responding.	• **Batteries:** Low battery power can cause intermittent button response. Replace batteries. • **Dirt/Debris:** Clean the remote control surface, especially around the unresponsive buttons.

Specifications

- **Brand:** XVEFAT
- **Model:** Replacement Remote Control for Insignia TV
- **Compatible Devices:** Insignia Televisions (specific models listed in Introduction)
- **Connectivity Technology:** Infrared (IR)
- **Power Supply:** 2 x 1.5V AAA Alkaline Batteries (not included)
- **Special Feature:** Ergonomic design

Warranty and Support

Specific warranty information for this XVEFAT replacement remote control is not provided in the product details. Please refer to the retailer or manufacturer's website for any available warranty terms or customer support contact information.
For further assistance, you may contact the seller directly through the platform where the purchase was made.

© 2023 XVEFAT. All rights reserved.
This manual is for informational purposes only. Product specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B087M4FC48

More documents and user manuals: **https://manuals.plus/**