Kid Trax KT1592AZ

Kid Trax Toddler Dinosaur Quad Ride-On Toy

Model: KT1592AZ | Brand: Kid Trax

Introduction

This instruction manual provides essential information for the safe assembly, operation, and maintenance of your Kid Trax Toddler Dinosaur Quad Ride-On Toy. Please read this manual thoroughly before initial use and retain it for future reference. This ride-on toy is designed for a single rider, aged 18 to 30 months, with a maximum weight limit of 44 lbs (20 kg).



The Kid Trax Toddler Dinosaur Quad Ride-On Toy, featuring a green body and a white dinosaur skull bumper.

Safety Information

WARNING: This product contains chemicals, including lead and lead compounds, which are known to the State of California to cause cancer, birth defects, or other reproductive harm. For more information, visit www.P65Warnings.ca.gov.

- Always supervise children during operation.
- Ensure the rider meets the age (18-30 months) and weight (max 44 lbs) requirements.
- Operate on flat, dry surfaces away from traffic, pools, or steep inclines.
- Do not allow children to operate the toy near stairs, hills, or roads.
- Always wear appropriate safety gear, such as a helmet.

What's in the Box

Carefully unpack all components and ensure all items are present before beginning assembly.

- Ride-On Toy (main body and components)
- 6-Volt Rechargeable Battery
- Wall Charger

Assembly Instructions

Adult assembly is required. Please follow the included diagrams and instructions carefully. Some users have noted that the diagrams may require close attention.

1. Attach the front dinosaur skull bumper to the main body of the quad.
2. Secure the handlebars to the steering column.
3. Install the wheels, ensuring they are properly aligned and secured.
4. Connect the battery terminals as instructed.
5. Place the seat securely onto the quad.



Close-up view of the dinosaur skull bumper, a key component during assembly.

Battery Charging

Before first use, the 6-volt rechargeable battery must be charged for a minimum of 14 hours. Subsequent charges should also be approximately 14 hours, but no more than 18 hours.

- Locate the charging port, typically under the seat.
- Connect the wall charger to the charging port and then plug it into a standard wall outlet.
- Ensure the charger indicator light (if present) shows it is charging.
- Disconnect the charger once charging is complete. Do not leave the battery charging for extended periods beyond the recommended time.



An icon depicting a 6V battery and charger, indicating the power components.

Operating Instructions

The Dinosaur Quad features a simple push-button drive system designed for young children.

1. Ensure the battery is fully charged and properly connected.
2. Have the child sit comfortably on the seat with both hands on the handlebars.
3. To move forward, press and hold the large push button located on the handlebar. The quad will move at a top speed of 1.5 MPH.
4. To stop, release the push button.
5. Steer by turning the handlebars left or right.



A child operating the quad, highlighting the 6V battery, push-button drive system, and 1.5 mph maximum speed.



Close-up of a child's hand on the handlebar, demonstrating the simple controls designed for small hands.

Maintenance

- **Cleaning:** Wipe the toy with a damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Battery Care:** Always recharge the battery after each use. If storing the toy for an extended period, charge the battery once a month to prolong its lifespan.
- **Storage:** Store the ride-on toy in a dry, cool place away from direct sunlight and moisture.
- **Inspection:** Regularly check for loose parts, damaged wiring, or worn tires. Tighten fasteners as needed.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Toy does not move	Battery not charged or connected; loose wiring; faulty switch.	Ensure battery is fully charged and connected. Check all wiring connections. Contact customer support if issues persist.
Short battery life	Battery not fully charged; old battery; excessive use on rough terrain.	Charge battery for the recommended time. Consider replacing old batteries. Operate on appropriate surfaces.
Unusual noises	Loose parts; debris in wheels/motor.	Inspect for and tighten any loose components. Clear any obstructions from wheels or motor area.

Specifications

- **Brand Name:** Kid Trax
- **Model Number:** KT1592AZ
- **Manufacturer:** Pacific Cycle, Inc.
- **Age Range:** 18 - 30 Months
- **Maximum Weight Capacity:** 44 lbs (20 kg)
- **Speed:** 1.5 MPH (Forward only)
- **Battery:** 6-Volt Rechargeable
- **Material Type:** Plastic
- **Item Weight:** 5 Kilograms
- **Item Dimensions:** 29.92 x 16.54 x 18.31 inches (L x W x H)
- **Assembly Required:** Yes
- **GTIN/UPC:** 038675224223

Warranty Information

The Kid Trax Toddler Dinosaur Quad Ride-On Toy comes with a one-year limited warranty on the product itself. The included 6-volt battery is covered by a 6-month limited warranty. Please retain your proof of purchase for warranty claims. For detailed terms and conditions, refer to the warranty card included with your product or contact customer support.

Customer Support

For assistance with assembly, operation, troubleshooting, or warranty inquiries, please contact Kid Trax customer support. Refer to the packaging or the official Kid Trax website for the most current contact information, including phone numbers and email addresses.

© 2024 Kid Trax. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question