Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

XVEFAT N2QAYB000835

XVEFAT N2QAYB000835 Replacement Remote Control User Manual

For Panasonic TV Models: TC-P50ST60, TC-P55ST60, TC-L55ET60

1. Product Overview

This manual provides instructions for the XVEFAT N2QAYB000835 replacement remote control, designed for use with specific Panasonic TV models. This remote offers direct functionality without the need for complex programming or pairing.

Key Features:

- Direct replacement for original Panasonic N2QAYB000835 remote.
- No programming or pairing required.
- Compatible with Panasonic TV models: TC-P50ST60, TC-P55ST60, TC-L55ET60.
- Operates using 2x 1.5V AAA Alkaline Batteries (not included).



Image 1.1: Front view of the XVEFAT N2QAYB000835 replacement remote control. This image displays the full layout of buttons, including power, input, channel, volume, navigation, and media playback controls.

2. Setup

Setting up your XVEFAT N2QAYB000835 replacement remote control is a straightforward process that primarily involves installing batteries.

1. **Open the Battery Compartment:** Locate the battery compartment cover on the back of the remote control. Gently slide or press the latch to open the cover.
2. **Insert Batteries:** Insert two (2) 1.5V AAA Alkaline batteries into the compartment. Ensure that the positive (+) and negative (-) terminals of the batteries align correctly with the markings inside the compartment. Incorrect insertion can prevent the remote from functioning.

3. **Close the Battery Compartment:** Replace the battery compartment cover by sliding it back into place until it clicks securely.
4. **Test the Remote:** Point the remote control towards your Panasonic TV and press the Power button. The TV should respond. No further programming or pairing is required.



Image 2.1: View of the remote control with the battery compartment open. This image illustrates the location of the battery compartment and how batteries should be inserted.

3. Operating Instructions

The XVEFAT N2QAYB000835 remote control functions identically to the original Panasonic remote. Below is a general guide to common button functions.



Image 3.1: Angled view of the remote control, highlighting the ergonomic design and button placement. This perspective helps in identifying various control sections.

- **Power (Red Button):** Turns the TV on or off.
- **Input:** Cycles through available input sources (HDMI, AV, Component, etc.).
- **TV:** Switches to TV mode.
- **Menu/Home:** Accesses the TV's main menu or smart TV home screen.
- **Navigation Buttons (Up, Down, Left, Right, OK):** Used to navigate menus and confirm selections.
- **Volume (+/-):** Adjusts the TV's volume level.
- **Mute:** Silences the TV audio.
- **Channel (CH ^/v):** Changes TV channels.
- **Number Pad (0-9):** Directly enters channel numbers.

- **Netflix:** Direct access button for the Netflix application.
- **Media Player Controls (Play, Pause, Stop, Rewind, Fast Forward):** Controls media playback on compatible devices or applications.

4. Maintenance

To ensure the longevity and optimal performance of your remote control, follow these maintenance guidelines:

- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries simultaneously with new ones.
- **Cleaning:** Use a soft, dry cloth to clean the remote's surface. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid excessive moisture.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Drops:** Protect the remote from physical impact, as drops can damage internal components.
- **Remove Batteries for Long Storage:** If the remote will not be used for an extended period, remove the batteries to prevent leakage, which can damage the remote.

5. Troubleshooting

If you encounter issues with your remote control, refer to the following troubleshooting steps:

1. **Remote Not Responding:**
    - Check if the batteries are inserted correctly with the correct polarity (+/-).
    - Replace old batteries with new 1.5V AAA Alkaline batteries.
    - Ensure there are no obstructions between the remote and the TV's infrared sensor.
    - Confirm you are within the effective range of the TV's IR receiver.
2. **Specific Buttons Not Working:**
    - Clean the remote's surface, especially around the non-functional buttons, to remove any dirt or debris that might be obstructing them.
    - If only specific buttons are affected after battery replacement, the remote might be faulty.
3. **TV Not Responding to Remote:**
    - Verify that your TV model is listed as compatible (TC-P50ST60, TC-P55ST60, TC-L55ET60).
    - Ensure the TV's own power is on and it's not in standby mode.
    - Check the TV's settings to ensure its remote control sensor is enabled and not blocked.

6. Specifications

Feature	Detail
Model Number	N2QAYB000835
Brand	XVEFAT
Compatible TV Models	Panasonic TC-P50ST60, TC-P55ST60, TC-L55ET60
Power Supply	2x 1.5V AAA Alkaline Batteries
Connectivity Technology	Infrared (IR)

Special Feature	Ergonomic design

7. Warranty and Support

Information regarding warranty coverage and customer support for XVEFAT products is typically provided at the point of purchase or through the seller. Please refer to your purchase documentation or contact the seller directly for details on warranty terms, return policies, and technical assistance.
For general inquiries or further assistance, please consult the seller's support channels.

© 2023 XVEFAT. All rights reserved. Panasonic is a registered trademark of Panasonic Corporation.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B087NS54YK

More documents and user manuals: **https://manuals.plus/**