Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

XVEFAT BN59-01178W

XVEFAT BN59-01178W Remote Control Instruction Manual

1. Introduction

This manual provides instructions for the XVEFAT BN59-01178W replacement remote control. This remote is designed to function as a direct replacement for various Samsung Smart LED HDTV models without the need for programming or pairing.

1.1. Compatible TV Models

The BN59-01178W remote control is compatible with the following Samsung TV models:

- UN46H6201AFXZA
- UN46H6203AF
- UN46H6203AFXZA
- UN50H5203AF
- UN50H5203AFXZA
- UN50H6201AF
- UN50H6201AFXZA
- UN50H6203AF
- UN50H6203AFXZA
- UN55H6203AF
- UN55H6203AFXZA
- UN55HU6830F
- UN55HU6830FXZA
- UN60H6203AF
- UN60H6203AFXZA
- UN65H6203AF
- UN65H6203AFXZA
- UN58H5202AFXZA

2. Setup

2.1. Battery Installation

The remote control requires two (2) 1.5V AAA batteries (not included). Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the battery compartment cover downwards or press the latch and lift to open.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



Figure 1: Battery compartment with batteries inserted.

Once batteries are installed, the remote control is ready for use. No programming or pairing is required.

3. Operating Instructions

3.1. General Use

Point the remote control directly at your Samsung TV's infrared receiver. Ensure there are no obstructions between the remote and the TV. Press the desired button to perform the corresponding function.

3.2. Button Functions

Below is an overview of the main buttons and their functions:



Figure 2: Front view of the BN59-01178W remote control.

Button	Function
TV Power	Turns the TV on or off.

Button	Function
STB Power	Turns the Set-Top Box on or off (if connected and configured).
SOURCE	Changes the input source (HDMI, AV, Component, etc.).
VOL +/-	Adjusts the volume level.
CH +/-	Changes the TV channel.
MUTE	Mutes or unmutes the TV sound.
MENU	Opens the TV's main menu.
GUIDE	Displays the electronic program guide.
SMART HUB	Accesses the Samsung Smart Hub for apps and streaming services.
INFO	Displays information about the current program or input.
TOOLS	Opens a quick menu with common settings and options.
Directional Pad (Up/Down/Left/Right)	Navigates through menus and options.
ENTER (Center button)	Confirms selections.
RETURN	Returns to the previous screen or menu.
EXIT	Exits the current menu or application.
Colored Buttons (A, B, C, D)	Perform specific functions depending on the current menu or application.
E-MANUAL	Accesses the TV's electronic user manual.
SEARCH	Opens the search function.
KEYPAD	Displays an on-screen numeric keypad.
P.SIZE	Adjusts the picture size/aspect ratio.
MTS	Selects Multi-channel Television Sound options (e.g., Stereo, SAP).
CC	Toggles Closed Captions on or off.
Playback Controls	Controls media playback (Play, Pause, Stop, Fast Forward, Rewind, Record).

4. Maintenance

4.1. Cleaning the Remote

To clean the remote control, gently wipe it with a soft, dry cloth. Do not use liquid cleaners, sprays, or abrasive materials, as these can damage the remote's surface or internal components.

4.2. Battery Care

- Replace batteries when the remote's response becomes sluggish or stops working.
- Always replace both batteries at the same time with new ones of the same type (AAA 1.5V).
- Do not mix old and new batteries, or different types of batteries.
- Remove batteries if the remote control will not be used for an extended period to prevent leakage.

- Dispose of used batteries according to local regulations.

5. Troubleshooting

- **Remote not responding:**
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace the batteries with new AAA 1.5V batteries.
  - Ensure there are no obstructions between the remote and the TV's infrared sensor.
  - Make sure you are pointing the remote directly at the TV.
- **Some buttons not working:**
  - This remote is a standard replacement. Some advanced functions specific to original Samsung Smart remotes (e.g., voice control, motion control) may not be supported.
  - Ensure the TV model is listed in the compatibility section.
- **Remote works intermittently:**
  - Batteries may be low; replace them.
  - Ensure a clear line of sight to the TV.

6. Specifications

- **Model:** BN59-01178W
- **Power Supply:** 2 x 1.5V AAA Batteries
- **Connectivity Technology:** Infrared (IR)
- **Compatible Devices:** Samsung Smart LED HDTVs (specific models listed in Section 1.1)
- **Special Feature:** Ergonomic design
- **Controller Type:** Button Control

7. Warranty and Support

This XVEFAT remote control comes with a standard manufacturer's warranty. For warranty claims, technical support, or further assistance, please refer to the seller's contact information or the original purchase platform. Keep your proof of purchase for warranty purposes.

© 2024 XVEFAT. All rights reserved. Samsung is a registered trademark of Samsung Electronics Co., Ltd.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B087P2NTQG

More documents and user manuals: **https://manuals.plus/**