Acer X1527i

Acer Essential X1527i Projector User Manual

Model: X1527i

1. Introduction

This manual provides detailed instructions for the safe and efficient operation of your Acer Essential X1527i DLP WUXGA projector. It covers setup, basic operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your device. The Acer Essential X1527i offers 4000 ANSI lumens brightness, WUXGA (1920x1200) resolution, automatic keystone correction, and flexible installation options, including a wireless adapter for convenient connectivity.

2. Safety Information

Please read all safety instructions carefully before using the projector. Failure to follow these instructions may result in fire, electric shock, or other injuries.

- Do not block ventilation openings. Ensure adequate space around the projector for proper airflow.
- Do not look directly into the projector lens when the lamp is on, as the bright light can cause eye damage.
- Do not place the projector on an unstable cart, stand, or table. The projector may fall, causing serious injury to a child or adult, and serious damage to the unit.
- Unplug the projector from the power outlet before cleaning. Use a damp cloth for cleaning; do not use liquid or aerosol cleaners.
- Refer all servicing to qualified service personnel.

3. Package Contents

Verify that all items listed below are included in your package. If any items are missing or damaged, contact your retailer.

- Acer Essential X1527i Projector

- Infrared Remote Control (with batteries)
- Lens Cap
- Printed Quick Start Guide
- 1x Wireless USB Adapter
- Power Cable (1.8 m)
- VGA Cable (1.8 m)

4. Product Overview

The Acer Essential X1527i projector features a compact design with a powerful lens and intuitive controls. Below is an image illustrating the projector's general appearance.



Figure 4.1: Front-side view of the Acer Essential X1527i Projector.

Key components include the projection lens, control panel on the top surface, ventilation grilles on the sides, and various input/output ports on the rear.



Figure 4.2: Top-down view of the Acer Essential X1527i Projector, showing the control panel.

5. Setup

5.1 Placement

The Acer Essential X1527i offers flexible installation options. It can be placed on a table, mounted on the ceiling, or used for front or rear projection. Ensure the projector is positioned between 1.0 and 10.0 meters from the screen for optimal image size and clarity. For ceiling mounting, note that the projector has three mounting holes that are not symmetrically placed; check compatibility with universal ceiling mounts or consider manufacturer-specific options.

5.2 Connections

Connect your source devices to the projector using the appropriate ports:

- **HDMI:** Connect devices like Blu-ray players, gaming consoles, or computers using an HDMI 1.4a (HDCP compatible) cable.
- **VGA In:** Connect older computers or laptops using a VGA cable.
- **Composite Video (RCA):** For standard definition video sources.
- **Audio In (Jack):** Connect audio from external sources.
- **RS232:** For control system integration.
- **USB Type-A:** Provides 5V power output for charging devices or connecting the included wireless adapter.
- **VGA Out:** To loop through the VGA signal to another display.

For wireless connectivity, insert the included USB wireless adapter into the USB Type-A port.

5.3 Power On/Off

- **To Power On:** Connect the power cable to the projector and a power outlet. Press the power button on the projector or the remote control.

- **To Power Off:** Press the power button twice. The projector will enter a cooling cycle before completely shutting down. Do not unplug the projector during the cooling cycle.

6. Operation

6.1 Basic Controls

The projector can be controlled using the buttons on the top panel or the included infrared remote control. The remote control provides full functionality for navigating menus and adjusting settings.

6.2 Image Adjustment

- **Focus:** Rotate the focus ring around the lens to achieve a sharp image.
- **Zoom:** Adjust the zoom ring (if available) or use the digital zoom function via the menu to change the image size without moving the projector.
- **Keystone Correction:** The projector features automatic keystone correction to square the image if the projector is not perfectly perpendicular to the screen. Manual adjustment options are also available in the OSD (On-Screen Display) menu.

6.3 Input Source Selection

Press the 'Source' button on the remote control or projector panel to cycle through available input sources (HDMI, VGA, Composite Video, Wireless). The projector will automatically detect active sources.

6.4 Wireless Connectivity

With the included wireless USB adapter, you can establish a wireless connection to WLAN-enabled devices. Refer to the on-screen menu for detailed instructions on setting up the wireless connection. Note that while convenient, direct HDMI connections often provide more stable performance for high-bandwidth applications like gaming or high-definition video to avoid potential synchronization issues.

7. Maintenance

Regular maintenance ensures the best performance and extends the lifespan of your projector.

- **Cleaning the Lens:** Use a soft, lint-free cloth specifically designed for optical lenses. Do not use abrasive cleaners.
- **Cleaning the Casing:** Wipe the projector casing with a soft, damp cloth. Avoid harsh chemicals.
- **Ventilation:** Periodically check that the ventilation grilles are free from dust and obstructions to prevent overheating.
- **Lamp Replacement:** The projector lamp has a limited lifespan. When the lamp indicator lights up or the image becomes dim, replace the lamp according to the instructions in the full service manual or by a qualified technician.

8. Troubleshooting

If you encounter issues with your projector, refer to the following common problems and solutions:

Problem	Possible Solution

Problem	Possible Solution
No image on screen	Ensure power cable is securely connected. Check input source selection. Verify source device is powered on and outputting a signal.
Image is blurry	Adjust the focus ring on the lens. Ensure the projection surface is flat.
Image is distorted (trapezoid shape)	The projector has automatic keystone correction. If needed, adjust manually via the OSD menu. Ensure the projector is as perpendicular to the screen as possible.
No sound	Check audio cable connections. Ensure volume is not muted on the projector or source device.
Projector overheats or shuts down	Ensure ventilation openings are not blocked. Clean dust from air filters (if applicable). Operate in a well-ventilated area.

9. Specifications

Below are the technical specifications for the Acer Essential X1527i Projector:

Feature	Specification
Model Number	MR.JS411.001
Display Technology	DLP
Native Resolution	WUXGA (1920 x 1200)
Maximum Resolution	1920 x 1080
Brightness	4000 ANSI Lumens
Connectivity Technology	HDMI, USB, VGA, RCA, RS232
Special Feature	Automatic Keystone Correction, Wireless Connectivity (via adapter)
Recommended Use	Gaming
Mounting Type	Table Mount
Product Dimensions	11.3 x 31.3 x 11.3 cm
Product Weight	2.9 kg
Batteries Required	1 A (for remote control)

10. Warranty and Support

For warranty information and technical support, please refer to the warranty card included with your product or visit the official Acer support website. Keep your proof of purchase for warranty claims.

© 2023 Acer Inc. All rights reserved. Specifications are subject to change without notice.