Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Gemmy B087RSM0CZ

Gemmy 4.5' Airblown Inflatable Santa and Friends Scene

Model: B087RSM0CZ

Introduction

This manual provides essential instructions for the safe and proper setup, operation, and maintenance of your Gemmy 4.5' Airblown Inflatable Santa and Friends Scene. Please read all instructions carefully before use and retain this manual for future reference.

Safety Instructions

- Always unplug the inflatable when not in use or during strong winds.
- Do not operate near water or in standing water to prevent electrical shock.
- Ensure the power cord is not damaged or pinched.
- Keep children and pets away from the inflatable during operation.
- Do not attempt to repair electrical components or the blower motor. Contact qualified personnel for service.
- Use only the provided stakes and tethers to secure the inflatable.
- Avoid placing the inflatable near heat sources or open flames.

Setup Instructions

1. **Unpack:** Carefully remove the inflatable and all accessories (stakes, tethers) from the packaging.
2. **Placement:** Choose a flat, clear area for placement, free from debris, sharp objects, or overhead obstructions. This inflatable is suitable for both indoor and outdoor use.
3. **Position:** Lay the inflatable flat on the ground. Ensure the air intake on the blower motor is clear of obstructions.
4. **Inflate:** Plug the power cord into a standard electrical outlet. The inflatable will begin to self-inflate within seconds.
5. **Secure:** Once fully inflated, use the provided stakes and tethers to secure the inflatable to the ground. Attach tethers to the designated loops on the inflatable and stake them firmly into the ground at an angle. This prevents the inflatable from being blown away by wind.



Image: The Gemmy 4.5-foot Airblown Inflatable Santa and Friends Scene, featuring Santa Claus, a reindeer holding a gift, and a snowman holding a candy cane. All figures are standing upright and fully inflated.



Image: The Gemmy 4.5-foot Airblown Inflatable Santa and Friends Scene displayed outdoors in a snowy yard, illuminated at night. The inflatable is positioned in front of a house with festive lighting, showcasing its visual impact.

Operating Instructions

- **Power On:** Connect the power plug to a suitable electrical outlet. The internal blower will activate, and the inflatable will inflate. Internal lights will also illuminate.
- **Power Off:** Disconnect the power plug from the electrical outlet. The inflatable will begin to deflate.
- **Deflation for Storage:** After unplugging, allow the inflatable to fully deflate. Gently press out any remaining air before folding for storage.

Maintenance

- **Cleaning:** To clean the inflatable, wipe with a damp cloth. Do not use harsh chemicals or abrasive cleaners. Ensure the inflatable is completely dry before storing.

- **Storage:** When not in use, store the deflated inflatable in its original packaging or a suitable storage bag in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Light Replacement:** Please note that the LED lights within this inflatable are designed to be irreplaceable. If a light fails, it cannot be individually replaced.

Troubleshooting

- **Inflatable does not inflate:**
  - Check that the power cord is securely plugged into a working outlet.
  - Ensure the blower motor's air intake is not blocked.
  - Verify that the zipper on the inflatable is fully closed.
- **Inflatable does not stand upright:**
  - Ensure the inflatable is fully inflated.
  - Check that all stakes and tethers are properly secured to prevent leaning or falling.
  - Adjust tether tension if necessary.
- **Lights are not working:**
  - Confirm the power is connected.
  - As noted in maintenance, the internal LED lights are not replaceable.

Specifications

Brand	Gemmy
Model	B087RSM0CZ
Dimensions (L x W x H)	50.39 in x 20.87 in x 53.94 in (approx. 4.5 feet tall)
Material	Polyvinyl Chloride (PVC)
Color	Multicolor (Red, Green, White, Brown)
Special Feature	Easy Setup, Self-inflates
Usage	Indoor or Outdoor
UPC	191245170860

Warranty and Support

For warranty information or customer support regarding your Gemmy Airblown Inflatable, please refer to the documentation included with your purchase or visit the official Gemmy website. Keep your proof of purchase for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B087RSM6CZ

More documents and user manuals: **https://manuals.plus/**