Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bush bc3b9454-2939-450c-a447-fc87b0034157

Bush DAB/FM Digital Radio User Manual

Model: bc3b9454-2939-450c-a447-fc87b0034157

Introduction

Thank you for purchasing the Bush DAB/FM Digital Radio. This manual provides essential information for setting up, operating, and maintaining your radio. Please read it thoroughly before use and retain it for future reference.
This portable radio features both Digital Audio Broadcasting (DAB) and FM radio capabilities, housed in a stylish wooden design. It is battery-powered for convenience and portability.

Safety Information

Please observe the following safety precautions:

- Do not expose the unit to rain or moisture to prevent fire or electric shock.
- Do not open the casing. Refer all servicing to qualified personnel.
- Avoid placing the unit near heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Use only attachments/accessories specified by the manufacturer.
- Dispose of batteries responsibly. Do not expose batteries to excessive heat.
- Clean only with a dry cloth.

Product Overview

Familiarize yourself with the components and controls of your Bush DAB/FM Digital Radio.



Figure 1: Front view of the Bush DAB/FM Digital Radio. This image displays the radio's main features, including the speaker grille on the left, the LCD screen displaying "WELCOME TO DIGITAL RADIO", and various control buttons and a volume knob on the right. The casing is made of wood.

Controls and Functions:

- **Power Button:** Turns the radio on or off.
- **Mode Button:** Switches between DAB and FM radio modes.
- **Scan Button:** Initiates an automatic scan for available radio stations.
- **Prev Button:** Navigates to the previous station or menu option.
- **Next Button:** Navigates to the next station or menu option.
- **Menu Button:** Accesses the radio's menu settings.
- **Preset Button:** Used to save and recall favorite stations.
- **Volume Knob:** Adjusts the audio output level.
- **LCD Display:** Shows station information, time, and menu options.

Setup

1. Unpacking

1. Carefully remove the radio from its packaging.
2. Check that all components are present, including the radio unit and the Quick Start Guide.
3. Retain the packaging for future transport or storage.

2. Powering On

The Bush DAB/FM Digital Radio is battery-operated. Ensure batteries are correctly inserted into the battery compartment (location typically on the back or bottom of the unit).

1. Open the battery compartment cover.
2. Insert the required batteries (e.g., AA or C type, refer to the battery compartment markings) ensuring correct polarity (+/-).
3. Close the battery compartment cover securely.
4. Press the **Power** button to turn on the radio.

3. Initial Scan (DAB Mode)

Upon first power-on, the radio will typically perform an automatic scan for DAB stations. If not, follow these steps:

1. Ensure the radio is in DAB mode (press **Mode** if necessary).
2. Press the **Scan** button. The radio will display "Scanning..." and search for available DAB stations.
3. Once the scan is complete, the radio will automatically tune to the first available station.

Operating Instructions

1. Power On/Off

- To turn on the radio, press the **Power** button.
- To turn off the radio, press the **Power** button again.

2. Switching Modes (DAB/FM)

- Press the **Mode** button to toggle between DAB (Digital Audio Broadcasting) and FM (Frequency Modulation) radio modes. The current mode will be displayed on the LCD screen.

3. Tuning Stations

DAB Mode:

- After an initial scan, use the **Prev** and **Next** buttons to browse through the available DAB stations.
- To perform a full scan for new stations, press the **Scan** button.

FM Mode:

- In FM mode, press and hold the **Scan** button to automatically scan for the next available FM station.
- Alternatively, use the **Prev** and **Next** buttons for manual fine-tuning or to step through frequencies.

4. Setting and Recalling Presets

You can save your favorite stations for quick access.

To Save a Preset:

1. Tune to the desired station.
2. Press and hold the **Preset** button until "Preset Store" or similar appears on the display.
3. Use the **Prev** or **Next** buttons to select a preset number (e.g., P1, P2).
4. Press the **Preset** button again to confirm and save the station.

To Recall a Preset:

1. Press the **Preset** button briefly. "Preset Recall" or similar will appear.
2. Use the **Prev** or **Next** buttons to select the desired preset number.
3. The radio will automatically tune to the saved station.

5. Adjusting Volume

- Rotate the **Volume Knob** clockwise to increase the volume and counter-clockwise to decrease it.

6. Menu Options

- Press the **Menu** button to access various settings such as display brightness, time/date settings, and system

information.

- Use the **Prev** and **Next** buttons to navigate through menu options and the**Menu** or **Preset** button (depending on model) to select.

7. USB Connectivity

The radio features USB connectivity. This port is typically used for firmware updates or potentially for playing audio from a USB device, depending on the specific model's capabilities. Refer to the Quick Start Guide for detailed USB functionality.

Maintenance

1. Cleaning

- Always turn off and unplug the radio before cleaning.
- Wipe the exterior surfaces with a soft, dry cloth.
- Do not use abrasive cleaners, waxes, or solvents as they may damage the finish.

2. Battery Care

- Remove batteries if the radio will not be used for an extended period to prevent leakage.
- Replace all batteries at the same time with new ones of the same type.
- Dispose of used batteries according to local regulations.

Troubleshooting

If you encounter issues with your radio, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
No power	Batteries are dead or incorrectly inserted.	Replace batteries or ensure correct polarity.
Poor DAB/FM reception	Weak signal; antenna not extended; interference.	Extend the telescopic antenna fully. Try repositioning the radio. Perform a full scan for stations.
No sound	Volume too low; radio muted; station not broadcasting.	Increase volume. Check if the radio is muted (if applicable). Try another station.
Display not working	Radio off; display brightness too low; fault.	Turn on the radio. Check display brightness settings in the menu. If problem persists, contact support.

Specifications

Feature	Detail
Brand	Bush
Model Number	bc3b9454-2939-450c-a447-fc87b0034157

Feature	Detail
Tuner Technology	DAB, FM
Display Type	LCD
Power Source	Battery Operated
Connectivity Technology	USB
Material	Wood
Special Feature	Wooden Design
Included Components	Quick Start Guide

Warranty and Support

For warranty information and customer support, please refer to the documentation included with your product or visit the manufacturer's official website. Keep your proof of purchase for warranty claims.
If you require further assistance, please contact Bush customer service.

© 2023 Bush. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B087T2VQGL

More documents and user manuals: **https://manuals.plus/**