Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Jojospring 702142069456

Jojospring 3-Light Brushed Champagne Crystal Chandelier

Model: 702142069456

Introduction

This manual provides detailed instructions for the safe installation, operation, and maintenance of your Jojospring 3-Light Brushed Champagne Crystal Chandelier. Please read all instructions carefully before beginning installation and retain this manual for future reference. Professional installation is recommended for this hard-wired fixture.
The Jojospring 3-Light Brushed Champagne Crystal Chandelier features a contemporary design with a brushed champagne finish and clear crystals, providing elegant illumination for indoor spaces.

Safety Information

- **WARNING:** To avoid electric shock, always disconnect power at the main circuit breaker or fuse box before installation or servicing.
- This fixture is designed for indoor use only. Do not expose to moisture or outdoor elements.
- All electrical connections must be in accordance with local codes, ordinances, or the National Electric Code (NEC). Consult a qualified electrician if you are unfamiliar with electrical wiring.
- Ensure the mounting surface can support the weight of the fixture.
- Do not exceed the maximum wattage specified for the light bulbs.
- Handle crystal components with care to prevent breakage.
- Assembly is required. Professional installation is recommended.

Package Contents

Carefully unpack all components and check for any damage. Ensure all parts are present before discarding packaging materials.

- Chandelier Fixture (with brushed champagne frame and pre-attached wiring)
- Crystal Components (various shapes and sizes)
- Ceiling Plate
- Adjustable Chain
- Mounting Hardware (screws, wire nuts, crossbar)
- Instruction Manual

Note: Light bulbs are not included and must be purchased separately.

Specifications

Brand	Jojospring
Model Number	702142069456
Fixture Finish	Brushed Champagne
Crystal Color	Clear
Material	Metal and Crystal
Fixture Dimensions	16 inches (Diameter) x 17.5 inches (Height)
Ceiling Plate Dimensions	5.1 inches (Diameter) x 1 inch (Height)
Chain Length	39.4 inches (Adjustable)
Number of Lights	3
Bulb Base	E12 Candelabra
Max Wattage per Bulb	60 Watts
Total Max Wattage	180 Watts
Voltage	110 Volts
Light Source Type	Candelabra, Incandescent, Halogen, or LED (E12)
Installation Type	Semi Flush Mount, Hard-wired
Certification	ETL/cETL Listed
Assembly Required	Yes
Dimmable	Yes, with dimmable bulbs and a compatible dimmer switch (not included)

Setup & Installation

Professional installation is recommended. Ensure power is disconnected at the circuit breaker before proceeding.

1. **Prepare for Installation:**
    - Turn off the electricity at the main fuse box or circuit breaker.
    - Unpack all components and lay them out on a clean, soft surface to prevent scratches.
    - Identify all parts using the package contents list.
2. **Attach Mounting Hardware:**

    Secure the mounting crossbar to the junction box in the ceiling using the provided screws. Ensure it is firmly attached.

Image: The brushed champagne ceiling plate connected to the adjustable chain, ready for mounting.

3. **Adjust Chain Length:**

   Determine the desired hanging height for your chandelier. Adjust the chain length by removing or adding links as needed. Connect one end of the chain to the fixture loop and the other end to the ceiling plate loop.

4. **Make Electrical Connections:**
   - Connect the fixture's black wire to the house's black (live) wire using a wire nut.
   - Connect the fixture's white wire to the house's white (neutral) wire using a wire nut.
   - Connect the fixture's ground wire (bare copper or green) to the house's ground wire and the mounting crossbar using a wire nut or ground screw.
   - Carefully tuck all wires into the junction box.

5. **Secure the Fixture:**

   Lift the chandelier and secure the ceiling plate to the mounting crossbar using the provided screws. Ensure the fixture is stable and flush against the ceiling.

6. **Install Light Bulbs:**

   Screw three (3) E12 candelabra base bulbs (max 60W each, not included) into the sockets. Ensure bulbs are fully seated.

Image: Detail of the three E12 bulb sockets within the chandelier's brushed champagne frame.

7. **Attach Crystal Components:**

   Carefully hang the crystal components onto the fixture's frame using the provided hooks or rings. Refer to the product image for the intended arrangement.

Image: A detailed view of the clear crystals attached to the brushed champagne metal frame.

Image: Detail showing how individual crystals are secured to the chandelier's metal structure.

Image: A cluster of clear hanging crystals, featuring a prominent faceted crystal at the center.

8. **Restore Power:**

   Once installation is complete and all components are securely in place, restore power at the circuit breaker.

Image: The Jojospring chandelier illuminating a kitchen island, showcasing its overall appearance.

Operating Instructions

This chandelier is operated via a standard wall switch (not included) connected to the fixture's electrical wiring.

- **Turning On/Off:** Use the wall switch to turn the chandelier on or off.
- **Dimmable Feature:** If you use dimmable E12 light bulbs and a compatible dimmer switch (both not included), the chandelier's light output can be adjusted. Follow the dimmer switch manufacturer's instructions for operation.

Maintenance

- **Cleaning:**

  Always disconnect power before cleaning. Dust the fixture regularly with a soft, dry cloth. For crystal components, a slightly damp cloth with mild glass cleaner can be used, then dry immediately with a clean, lint-free cloth. Avoid harsh chemicals or abrasive cleaners, as they may damage the finish or crystals.

- **Bulb Replacement:**

  Ensure power is off and bulbs have cooled before attempting to replace them. Unscrew the old bulb and screw in a new E12 candelabra base bulb (max 60W). Do not overtighten.

- **Inspections:**

  Periodically check all connections and mounting hardware for tightness. If any damage is observed, discontinue use and consult a qualified electrician.

Troubleshooting

Problem	Possible Cause	Solution
Light does not turn on.	◦ Power is off at the circuit breaker. ◦ Loose wire connections. ◦ Faulty light bulb.	◦ Check the circuit breaker and ensure it is in the "ON" position. ◦ Verify all wire connections are secure (ensure power is off first). ◦ Replace the light bulb with a new one.
Flickering lights.	◦ Loose bulb. ◦ Incorrect bulb type for dimmer. ◦ Loose wiring.	◦ Tighten bulbs. ◦ Ensure dimmable bulbs are used with a compatible dimmer switch. ◦ Check wiring connections (ensure power is off first).
Fixture is unstable or wobbles.	◦ Mounting hardware not securely fastened. ◦ Junction box not adequately supported.	◦ Ensure all mounting screws are tightened. ◦ Consult a professional electrician to assess junction box support.

Warranty & Support

This Jojospring chandelier comes with a manufacturer's warranty. Please refer to the warranty card included in your package or contact Jojospring customer support for specific warranty terms and conditions.
For technical assistance, missing parts, or warranty claims, please contact Jojospring customer service. Contact information can typically be found on the product packaging or the official Jojospring website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B087TJ9QQH

More documents and user manuals: **https://manuals.plus/**