ONN ONA19DP006

ONN ONA19DP006 Swivel Portable DVD Player Kit - User Manual

Model: ONA19DP006

Introduction

This user manual provides essential information for the safe and efficient operation of your ONN ONA19DP006 Swivel Portable DVD Player Kit. Please read this manual thoroughly before using the device and retain it for future reference.

Product Overview



Figure 1: The ONN ONA19DP006 Swivel Portable DVD Player Kit with its 7-inch screen swiveled open, revealing the DVD disc tray and control buttons. The device is black with a brushed metal texture on the base.

The ONN ONA19DP006 is a compact and versatile 7-inch portable DVD player designed for on-the-go entertainment. It features a swivel screen for flexible viewing angles and supports various media types, including DVD discs and content via USB connectivity.

Package Contents

Verify that all items are present in the package:

- ONN ONA19DP006 Portable DVD Player
- AC Power Adapter
- Car Power Adapter
- Remote Control (with battery)
- AV Cable
- User Manual (this document)

Setup

1. Charging the Battery

Before first use, fully charge the internal battery. Connect the AC power adapter to the DC IN port on the player and plug the other end into a standard wall outlet. The charging indicator light will illuminate. Once fully charged, the light may change color or turn off.

2. Powering On/Off

To power on the device, slide the POWER switch to the ON position. To power off, slide the switch to the OFF position. For extended periods of non-use, disconnect the power adapter.

3. Connecting to External Devices

Use the provided AV cable to connect the player to an external display (e.g., TV) or audio system. Connect the AV OUT port on the player to the corresponding AV IN ports on your external device.

Operating Instructions

1. Inserting a DVD Disc

1. Gently open the disc cover.
2. Place the DVD disc onto the spindle with the label side facing up.
3. Press down gently on the center of the disc until it clicks into place.
4. Close the disc cover firmly. The player will automatically begin reading the disc.

2. Basic Playback Controls

- **Play/Pause:** Press the **PLAY/PAUSE** button to start or pause playback.
- **Stop:** Press the **STOP** button to stop playback.
- **Skip:** Press the **NEXT** or **PREV** buttons to skip to the next or previous chapter/track.
- **Fast Forward/Rewind:** Press and hold the **FF** or **REW** buttons for fast forward or rewind.
- **Volume:** Use the **VOL+** and **VOL-** buttons to adjust the volume.

3. Using the Swivel Screen

The screen can be swiveled up to 180 degrees clockwise and folded flat against the base, transforming the player into a tablet-like form factor. Exercise caution when swiveling the screen to avoid damage.

4. USB Media Playback

Insert a USB flash drive into the USB port. The player will automatically detect the media and display a menu for selecting files (e.g., video, audio, photos). Navigate using the directional buttons and press **ENTER** to select.

Maintenance

Cleaning the Device

Wipe the exterior of the player with a soft, dry cloth. For stubborn marks, slightly dampen the cloth with water. Do not use abrasive cleaners or solvents. For the disc lens, use a specialized DVD lens cleaning kit.

Storage

When not in use for extended periods, store the player in a cool, dry place away from direct sunlight and extreme temperatures. Ensure the disc tray is empty before storage.

Troubleshooting

Problem	Possible Cause	Solution
Player does not power on.	Battery is depleted; Power adapter not connected; Power switch is OFF.	Charge the battery; Connect the power adapter securely; Slide power switch to ON.
No picture on screen.	Screen brightness too low; AV cable not connected properly (if using external display); Disc is dirty or scratched.	Adjust brightness; Check AV cable connections; Clean or replace disc.
No sound.	Volume is too low or muted; Headphones not fully inserted; AV cable issues.	Increase volume; Check headphone connection; Verify AV cable connection.
Disc not playing.	Disc inserted incorrectly; Disc is dirty or damaged; Unsupported disc format.	Reinsert disc correctly; Clean or replace disc; Ensure disc format is supported (DVD, CD).

Specifications

Model: ONA19DP006

Screen Size: 7 Inches (Visible screen diagonal: 18 cm)

Display Type: LCD

Media Type Supported: DVD, CD, USB (for compatible file formats)

Connectivity Technology: USB, AV Out

Product Dimensions: 11 x 7 x 4 inches (approximate)

Item Weight: 5.84 pounds (approximate)

Power Source: AC Adapter, Car Adapter, Internal Rechargeable Battery

Warranty Information

This product comes with a limited warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions, including warranty period and coverage details. Keep your purchase receipt as proof of purchase for warranty claims.

Customer Support

For technical assistance, troubleshooting beyond this manual, or warranty inquiries, please contact ONN customer

support. Refer to the contact information provided on the product packaging or the official ONN website.

Note: Product specifications and features are subject to change without notice.

© 2024 ONN. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question