XVEFAT ELST4017 ELSJ5517 E4SFC5017 E2SW3918

XVEFAT Replacement Remote Control User Manual

Compatible with Element TV Models: ELST4017, ELSJ5517, E4SFC5017, E2SW3918

1. Introduction

This manual provides essential instructions for the XVEFAT Replacement Remote Control. This remote is designed as a direct replacement for your original Element TV remote, offering seamless compatibility with the specified models without requiring any programming or setup. Simply insert batteries, and it is ready for use.

2. Package Contents

- 1 x XVEFAT Replacement Remote Control

3. Setup: Battery Installation

To begin using your remote control, you must first install batteries. This remote requires two AAA batteries (not included).

1. Locate the battery compartment on the back of the remote control.
2. Press down on the latch and slide the battery cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.



Image: Rear view of the remote control with the battery cover removed, illustrating the battery placement.

4. Operating Instructions

This remote control is pre-programmed for immediate use with compatible Element TV models. No additional setup or pairing is required.

4.1. Compatible TV Models

The XVEFAT Replacement Remote Control is compatible with the following Element TV models:

- ELST4017
- ELSJ5517
- E4SFC5017
- E2SW3918

4.2. Basic Functions

Point the remote control directly at your television's infrared sensor. Ensure there are no obstructions between the remote and the TV.



Image: Front view of the remote control, displaying the layout of all buttons.

- **POWER**: Turns the TV on or off.
- **MUTE**: Mutes or unmutes the TV sound.
- **Number Buttons (0-9)**: Directly select channels.
- **VOL +/-**: Adjusts the volume level.

- **CH +/-**: Changes the TV channel.
- **Navigation Pad (Up, Down, Left, Right, OK)**: Navigates menus and confirms selections.
- **MENU**: Accesses the TV's main menu.
- **SOURCE**: Selects input sources (HDMI, AV, etc.).
- **RETURN** / **EXIT**: Returns to the previous screen or exits a menu.
- **NETFLIX, VUDU, PANDORA, YouTube**: Direct access buttons for streaming services.
- **USB**: Accesses content from a connected USB device.
- **Playback Controls (REW, PLAY/PAUSE, FF, PREV, NEXT, REPEAT)**: Controls media playback.
- **INFO**: Displays program information.
- **FREEZE**: Pauses the current image on screen.
- **FAV**: Accesses favorite channels.
- **CH.LIST**: Displays the channel list.
- **P.MODE**: Changes picture modes.
- **S.MODE**: Changes sound modes.
- **V-CHIP**: Accesses V-Chip settings for parental controls.
- **CC**: Activates or deactivates Closed Captions.
- **MTS**: Selects Multi-channel Television Sound options.
- **ASPECT**: Changes the screen aspect ratio.
- **SLEEP**: Sets the sleep timer.
- **AUTO**: Automatic picture adjustment (for VGA input).
- **HDMI, VGA, TV**: Direct input selection buttons.

5. Maintenance

5.1. Cleaning

To clean the remote control, gently wipe it with a soft, dry cloth. Do not use liquid cleaners, abrasive materials, or chemical solvents, as these may damage the remote's surface or internal components.

5.2. Battery Replacement

Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones of the same type (AAA). Do not mix old and new batteries, or different types of batteries.

6. Troubleshooting

6.1. Remote Not Responding

- **Check Batteries**: Ensure batteries are inserted correctly with the correct polarity (+/-) and are not depleted. Replace with fresh batteries if necessary.
- **Line of Sight**: Make sure there are no objects blocking the path between the remote control and the TV's infrared sensor.
- **Distance**: Ensure you are within the effective operating range of the TV's infrared receiver.
- **No Programming Needed**: Remember, this remote does not require any programming. If it's not working, it's typically a battery or line-of-sight issue.

7. Specifications

Brand	XVEFAT
Manufacturer	XVEFAT
Compatible Devices	Element Televisions (Models: ELST4017, ELSJ5517, E4SFC5017, E2SW3918)
Connectivity Technology	Infrared
Special Feature	Ergonomic design
Color	Black

8. Warranty and Support

Specific warranty information for this product is not provided in the available details. For any warranty claims or technical support, please contact the seller or manufacturer directly through your purchase platform.

© 2023 XVEFAT. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question