Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

XVEFAT DE550M3N4AU-YA4

XVEFAT Replacement Remote Control User Manual

For Polaroid TV Models

1. Product Overview

This manual provides instructions for the XVEFAT replacement remote control, designed for use with various Polaroid TV models. This remote control requires no programming or pairing; simply install batteries to begin operation.

Compatible Polaroid TV Models:

- 32GSR3000FC
- 40GSR3000FC
- 55GTR3000-2
- 55GTR3000
- DE550M3N4AU-YA4
- DE416T1N4AU-PA4
- 24GSD3000UA
- 24GSD3000SA
- 32GSD3000FB
- 22GSD3000F

2. Setup: Battery Installation

The remote control operates on two (2) 1.5V AAA batteries (not included). Follow these steps to install the batteries:

1. Locate the battery compartment on the back of the remote control.
2. Press down on the latch and slide the battery cover downwards to open it.
3. Insert two (2) AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.



Figure 2.1: Rear view of the remote control with the battery cover removed, illustrating the battery insertion points.

Once batteries are installed, the remote control is ready for immediate use with your compatible Polaroid TV.

3. Operating Instructions

This section details the primary functions of the remote control buttons. Refer to the button layout diagram for visual reference.



Figure 3.1: Front view of the remote control, displaying the complete button layout.

Key Functions:

- **POWER** (Red Button): Turns the TV on or off.
- **SOURCE**: Selects input sources (e.g., HDMI, AV).
- **MUTE** (Green Button): Mutes or unmutes the TV audio.
- **Number Buttons (0-9)**: Directly selects TV channels.
- **DISPLAY**: Shows on-screen information.
- **EPG**: Accesses the Electronic Program Guide.
- **SWAP**: Switches between the current and previous channel.
- **MENU**: Opens the TV's main menu.
- **EXIT**: Closes menus or on-screen displays.
- **Navigation Buttons (Up, Down, Left, Right)**: Navigates through menus and options.
- **ENTER**: Confirms selections in menus.
- **VOL +/-**: Adjusts the volume level.
- **CH +/-**: Changes TV channels.
- **P.MODE**: Selects picture modes.
- **S.MODE**: Selects sound modes.
- **SLEEP**: Sets the sleep timer.
- **ASPECT**: Changes the screen aspect ratio.
- **CC**: Activates or deactivates Closed Captions.
- **MTS**: Selects Multi-channel Television Sound.
- **ADD/ERASE**: Manages favorite channels.
- **FAV.**: Accesses favorite channels list.
- **GOTO**: Jumps to a specific time in media playback.
- **REPEAT**: Repeats media playback.
- **Media Control Buttons (Play, Pause, Stop, Rewind, Fast Forward, Previous, Next)**: Controls media playback functions.

Note: Some buttons' functions may vary slightly depending on your specific Polaroid TV model. In rare cases, a button's label might not perfectly match its function on certain TV models. Please refer to your TV's original manual for specific button functionalities if discrepancies occur.

4. Maintenance

Proper care ensures the longevity and optimal performance of your remote control.

- **Cleaning:** Wipe the remote control with a soft, dry cloth. For stubborn dirt, lightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's responsiveness decreases or it stops functioning. Always replace both batteries at the same time with new ones of the same type (AAA).
- **Storage:** Store the remote control in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity. If the remote will not be used for an extended period, remove the batteries to prevent leakage.
- **Avoid Drops:** Protect the remote from physical impact, as drops can damage internal components.

5. Troubleshooting

If you encounter issues with your remote control, try the following solutions:

- **Remote Not Responding:**
  - Ensure the batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new 1.5V AAA alkaline batteries.
  - Check for any obstructions between the remote control and the TV's infrared sensor.
  - Ensure you are within the effective range and pointing the remote directly at the TV.
- **Some Buttons Not Working as Labeled:**
  - This remote is a replacement and may have slightly different button assignments for certain advanced functions depending on the specific TV model.
  - Familiarize yourself with the remote's behavior for your TV model. For example, a "Source" button might bring up channel information, or a "Channel" button might open the menu, as noted by some users.
  - Most primary functions (Power, Volume, Channel, Number buttons) should operate as expected.
- **Intermittent Operation:**
  - This could indicate low battery power. Replace the batteries.
  - Ensure the remote's infrared emitter is clean and not obstructed.

6. Specifications

Feature	Detail
Brand	XVEFAT
Compatible Devices	Polaroid Televisions (various models listed in Section 1)
Connectivity Technology	Infrared (IR)
Power Supply	2 x 1.5V AAA Batteries
Special Feature	Ergonomic design, No programming required
Color	Black
Model Numbers (Primary)	DE550M3N4AU-YA4, DE416T1N4AU-PA4

7. Warranty and Support

For warranty information or technical support regarding your XVEFAT replacement remote control, please contact the seller directly through the platform where the purchase was made. Keep your purchase receipt or order number handy for faster assistance.
This product is designed to function as a direct replacement and typically does not require extensive technical support beyond basic setup and troubleshooting as outlined in this manual.

© 2026 XVEFAT. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0881CD459

More documents and user manuals: **https://manuals.plus/**