Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Yunir RM-D720

Yunir RM-D720 Replacement Remote Control User Manual

Model: RM-D720

1. Introduction

This manual provides instructions for the Yunir RM-D720 replacement remote control. Designed to be easy to grip, small, and compact, this remote is a dedicated replacement that covers nearly all functions of your original remote control. It is ideal for replacing lost, damaged, or non-functional original remotes.

Key Features:

- Durable ABS material for long service life.
- Extended transmission distance, up to 10 meters (32.8 feet) for stable performance.
- No programming or setup required; simply insert batteries and use.
- Dedicated menu navigation buttons and direct channel access for digital TV.

2. Setup

2.1 Installing Batteries

The RM-D720 remote control requires two (2) AA batteries (not included). Follow these steps to install them:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards and remove it.
3. Insert two AA batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



Figure 2.1: Back view of the remote control with the battery compartment.

2.2 Compatibility

This remote control is compatible with various digital TV models. It is designed to work with the following models:

- N2QAYB000239
- N2QAYB000238
- N2QAYB000222
- EUR7651030A
- EUR 7651120/71110/76280030
- EUR7737250
- TX32LXD70
- EUR765108A
- TH42PX700B
- TH42PX70B

TH42PX70

No programming or complex setup is required. Once batteries are installed, the remote is ready for use with compatible devices.

3. Operating Instructions

Point the remote control directly at the infrared receiver on your television or compatible device. Ensure there are no obstructions between the remote and the device.



Figure 3.1: Front view of the RM-D720 remote control.

3.1 Basic Functions

- **POWER (Red Button):** Turns the TV or device on/off.
- **VOL (+/-):** Increases or decreases the volume.
- **CH (Up/Down Arrows):** Changes channels up or down.

- **MUTE:** Mutes or unmutes the sound.
- **Number Buttons (0-9):** Directly select channels.

3.2 Navigation and Menu Controls

- **MENU:** Opens the TV's main menu.
- **GUIDE:** Displays the electronic program guide.
- **INFO:** Shows information about the current program.
- **Arrow Buttons (Up, Down, Left, Right):** Navigate through menus and options.
- **OK:** Confirms selections in menus.
- **RETURN:** Goes back to the previous screen or menu.
- **EXIT:** Exits the current menu or function.

3.3 Input and Special Functions

- **INPUT/TV/AV:** Selects the input source (e.g., HDMI, AV, TV tuner).
- **ASPECT:** Changes the screen aspect ratio.
- **VIERA Link:** Activates Viera Link functions (if supported by your TV).
- **OPTION:** Accesses additional options for the current function.
- **TEXT:** Displays teletext.
- **STTL (Subtitle):** Toggles subtitles on/off.
- **INDEX/HOLD:** Teletext functions.
- **VCR/DVD Controls (PLAY, PAUSE, STOP, REW, FF, REC):** Controls connected VCR or DVD players.

4. Maintenance

4.1 Battery Replacement

When the remote control's range decreases or buttons become unresponsive, it is time to replace the batteries. The remote retains its codes even when batteries are changed.

1. Remove the old AA batteries from the compartment.
2. Insert two new AA batteries, observing the correct polarity (+/-).
3. Replace the battery compartment cover.

4.2 Cleaning

To clean the remote control, use a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild cleaning solution. Do not use abrasive cleaners or immerse the remote in liquid.

4.3 Storage

Store the remote control in a dry place, away from direct sunlight and extreme temperatures. If the remote will not be used for an extended period, it is recommended to remove the batteries to prevent leakage.

5. Troubleshooting

5.1 Remote Not Responding

- **Check Batteries:** Ensure batteries are correctly installed with the correct polarity and are not depleted. Replace them if necessary.

- **Line of Sight:** Make sure there are no obstructions between the remote control and the TV's infrared receiver.
- **Remote Orientation:** Ensure you are pointing the remote directly at the TV.

5.2 Limited Range

- **Replace Batteries:** Weak batteries can reduce the remote's effective range.
- **Interference:** Strong light sources (like direct sunlight or fluorescent lights) can interfere with the infrared signal. Try to minimize such interference.
- **Distance:** While the remote has a range of up to 10 meters, optimal performance is typically closer.

6. Specifications

Model	RM-D720
Brand	Yunir
Material	ABS
Color	Black
Connectivity Technology	Infrared
Compatible Devices	Television
Power Supply	2 x AA Batteries (not included)
Transmission Distance	Up to 8 meters (26.2 feet) / Max 10 meters (32.8 feet)
Number of Buttons	30
Product Dimensions	19 x 5 x 2.3 cm (7.48 x 1.97 x 0.9 inches)

7. Warranty and Support

Specific warranty information for this product is not available in the provided details. For support or warranty inquiries, please refer to the retailer or manufacturer's contact information provided at the time of purchase.

© 2023 Yunir. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08869RGNK

More documents and user manuals: **https://manuals.plus/**