Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

XVEFAT NS-RCRUS-16

XVEFAT NS-RCRUS-16 Remote Control User Manual

Model: NS-RCRUS-16

1. Introduction

This manual provides comprehensive instructions for the XVEFAT NS-RCRUS-16 remote control. It covers setup, operation, maintenance, and troubleshooting to ensure optimal performance with your compatible Insignia TV models. Please read this manual carefully before using the remote control.

2. Setup: Battery Installation

The NS-RCRUS-16 remote control requires two (2) AAA 1.5V alkaline batteries for operation. Batteries are not included with the remote control.

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch (if present) and lift to open the compartment.
3. Insert two AAA 1.5V alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



Figure 2.1: Battery compartment of the NS-RCRUS-16 remote control. This image shows the back of the remote with the cover removed, revealing two slots for AAA batteries and their polarity markings.

Once batteries are installed, the remote control is ready for use. No programming or pairing is required for compatible Insignia TV models.

3. Operating Instructions

The NS-RCRUS-16 remote control is designed for direct use with various Insignia TV models. Simply point the remote control towards your television and press the desired button.

3.1. Compatible TV Models

This remote control is compatible with the following Insignia TV models:

- NS-39DR510NA17
- NS-55DR420NA16

- NS-40DR420NA16
- NS-48DR420NA16
- NS-32DR420NA16

3.2. Button Functions

Refer to the image below for a visual guide to the remote control's buttons and their general functions:



Figure 3.1: Front view of the NS-RCRUS-16 remote control. This image displays the layout of all buttons, including power, navigation, volume, and dedicated streaming service buttons.

- **Power Button ( )**: Turns the TV on or off.

- **Back Button (←)**: Returns to the previous screen or menu.
- **Home Button (⌂)**: Navigates to the TV's home screen.
- **Directional Pad (Up, Down, Left, Right)**: Navigates through menus and selections.
- **OK Button**: Confirms a selection.
- **Volume Up/Down (/)**: Adjusts the television's volume.
- **Mute Button ( )**: Mutes or unmutes the television's audio.
- **Playback Controls (Rewind, Play/Pause, Fast Forward)**: Controls media playback.
- **Dedicated App Buttons (e.g., Netflix, Sling)** Provides direct access to specified streaming applications.



Figure 3.2: Angled view of the NS-RCRUS-16 remote control. This image shows the side profile, emphasizing the placement of the volume and mute buttons.

4. Maintenance

4.1. Battery Replacement

Replace batteries when the remote control's response becomes sluggish or stops functioning. Always replace both batteries simultaneously with new AAA 1.5V alkaline batteries. Do not mix old and new batteries, or different types of batteries.

4.2. Cleaning

To clean the remote control, gently wipe its surface with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the remote control.

5. Troubleshooting

- **Remote Control Not Responding:**
  - Ensure batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new AAA 1.5V alkaline batteries.
  - Ensure there are no obstructions between the remote control and the TV's infrared sensor.
  - Confirm the remote control is pointed directly at the TV.
- **Intermittent Functionality:**
  - This may indicate low battery power. Replace batteries.
  - Check for strong light sources (e.g., direct sunlight, fluorescent lights) that might interfere with the infrared signal.

6. Specifications

Feature	Detail
Model	NS-RCRUS-16
Brand	XVEFAT
Power Supply	2 x 1.5V AAA Alkaline Batteries
Connectivity Technology	Infrared
Compatible Devices	Insignia Televisions (Specific models listed in Section 3.1)
Special Feature	Ergonomic Design

7. Warranty and Support

For warranty information and customer support regarding your XVEFAT NS-RCRUS-16 remote control, please refer to the documentation provided at the time of purchase or contact the seller directly. Specific warranty terms may vary.

Manufacturer: XVEFAT

© 2023 XVEFAT. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B088BPFL68

More documents and user manuals: **https://manuals.plus/**