Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

XVEFAT ELEFW231 ELEFW40C ELEFW601 ELEFW605 ELEFW606

XVEFAT Remote Control User Manual

For Element TV Models: ELEFW231, ELEFW40C, ELEFW601, ELEFW605, ELEFW606

Introduction

This manual provides instructions for the setup, operation, and maintenance of your new XVEFAT replacement remote control for Element LED LCD TVs. Please read this manual carefully before using the remote control.

Setup

1. Battery Installation

The remote control requires two (2) AAA alkaline batteries (not included) for operation.

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards to open it.
3. Insert two new 1.5V AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



Image: Front view of the XVEFAT remote control. This image shows the layout of all buttons, including power, number keys, navigation, volume, and channel controls.

2. Initial Use

This remote control is a direct replacement and does not require any programming or pairing. Once batteries are installed, it is ready for immediate use with compatible Element TV models.

- Point the remote control directly at your Element TV.
- Press the **POWER** button to turn on your TV.

Operating Instructions

Familiarize yourself with the remote control's buttons and their functions:

Button	Function
POWER	Turns the TV on or off.
MUTE	Mutes or unmutes the TV sound.
0-9 (Number Buttons)	Directly select TV channels.
SOURCE	Selects input sources (e.g., HDMI, AV).
VOL +/-	Adjusts the volume level.
CH +/-	Changes TV channels.
MENU	Accesses the TV's main menu.
OK	Confirms selections in menus.
EXIT	Exits the current menu or function.
INFO	Displays channel or program information.
SLEEP	Sets the sleep timer for the TV.
ASPECT	Changes the screen aspect ratio.
FREEZE	Pauses the current image on screen.
CH LIST	Displays the channel list.
AUTO	Initiates auto-tuning or auto-adjustment.
P.MODE	Cycles through picture modes.
S.MODE	Cycles through sound modes.
MTS	Selects Multi-channel Television Sound options.
ADD/ERASE	Adds or erases channels/items.
FAV	Accesses favorite channels.
REPEAT	Repeats playback (if applicable).
USB	Switches to USB input mode.
CC	Activates or deactivates Closed Captions.

Button	Function
V-CHIP	Accesses V-Chip parental control settings.
Playback Controls (Play, Pause, Stop, Rewind, Fast Forward, Skip)	Controls media playback functions.



Image: Angled view of the XVEFAT remote control, highlighting the ergonomic design and button placement.

Maintenance

Battery Replacement

Replace batteries when the remote control becomes unresponsive or its range decreases. Always replace both batteries at the same time with new 1.5V AAA alkaline batteries. Do not mix old and new batteries, or different types of batteries.

Cleaning

To clean the remote control, wipe it with a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as these can damage the remote's surface or internal components.

Storage

If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage.

Troubleshooting

Remote Control Not Working

- **Check Batteries:** Ensure batteries are inserted correctly with the correct polarity (+/-). Replace with fresh AAA alkaline batteries.
- **Line of Sight:** Make sure there are no obstructions between the remote control and the TV's infrared sensor.
- **Remote Sensor:** Ensure the TV's remote sensor is not blocked or dirty.
- **TV Compatibility:** Verify that your TV model is listed as compatible with this remote control.

Buttons Unresponsive

- **Battery Check:** Low batteries can cause intermittent button response. Replace them.
- **Stuck Buttons:** Ensure no buttons are physically stuck down.

Specifications

- **Brand:** XVEFAT
- **Model Compatibility:** Element TV models ELEFW231, ELEFW40C, ELEFW601, ELEFW605, ELEFW606
- **Power Supply:** 2 x 1.5V AAA Alkaline Batteries
- **Connectivity Technology:** Infrared (IR)
- **Color:** Black
- **Special Feature:** Ergonomic design

Warranty and Support

Specific warranty information for this product is not provided in the available documentation. For any issues or support inquiries, please refer to the seller or retailer from whom you purchased the remote control.
For general troubleshooting or further assistance, please consult the troubleshooting section of this manual or contact the product manufacturer if contact details are available on the product packaging.

© 2023 XVEFAT. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B088DGQTFH

More documents and user manuals: **https://manuals.plus/**