Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

XVEFAT For 37MF301B/F7 26MF301B/F7

XVEFAT Replacement Remote Control Instruction Manual

For Magnavox TV Models

1. Product Overview

This XVEFAT replacement remote control is designed to operate various Magnavox TV models without the need for programming or pairing. It provides full functionality for your television, allowing you to control power, volume, channels, and other features.

Compatible Magnavox TV Models:

- 40MF401B
- 32MF301B
- 32MF301B/F7
- 40MF401B/F7
- 19MF301D/F7
- 22ME601B/F7
- 37MF301B/F7
- 26MF301B/F7
- 19ME301B/F7

2. Initial Setup

Setting up your new remote control is a simple process that requires no complex programming. Follow these steps to begin using your remote.

Battery Installation:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or outwards to open it.
3. Insert two (2) new 1.5V AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals align

correctly with the markings inside the compartment.

4. Slide the battery compartment cover back into place until it clicks securely.

No programming or pairing is required. Once batteries are installed, the remote is ready for immediate use with compatible Magnavox TV models.



Image 1: Front view of the XVEFAT replacement remote control. This image displays the layout of all buttons, including power, source, navigation, channel, volume, and number keys.

3. Operating Instructions

This section outlines the basic functions of the remote control buttons.

Key Button Functions:

- **POWER (red circle with line)**: Turns the TV on or off.
- **SOURCE**: Selects input sources (e.g., HDMI 1, AV).
- **SAP/AUDIO**: Changes the audio track or SAP (Secondary Audio Program).
- **SLEEP**: Sets a timer for the TV to turn off automatically.
- **FORMAT**: Adjusts the screen aspect ratio.
- **MODE**: Cycles through different picture or sound modes.
- **TITLE**: Accesses disc title menu (if applicable).
- **DISC MENU**: Accesses disc menu (if applicable).
- **FREEZE**: Pauses the current image on screen.
- **SMART MENU**: Accesses smart features or quick settings.
- **MUTE**: Mutes or unmutes the TV sound.
- **Navigation Pad (Up, Down, Left, Right, OK)**: Navigates through menus and confirms selections.
- **BACK**: Returns to the previous menu or screen.
- **INFO**: Displays information about the current program or input.
- **PLAY, STOP, PAUSE, REV, FWD, SKIP**: Controls media playback functions.
- **VOL +/-**: Increases or decreases the volume.
- **CH +/-**: Changes the channel up or down.
- **ECO**: Activates or deactivates energy-saving mode.
- **Number Buttons (0-9)**: Directly enters channel numbers.
- **PREV CH**: Returns to the previously viewed channel.
- **CLEAR**: Clears entered numbers or selections.
- **+10**: For entering channels above 99 or specific functions.
- **EJECT**: Ejects disc (if applicable).
- **TELETEXT**: Accesses teletext services (if available).
- **FUN-LINK**: Activates Magnavox Fun-Link (HDMI-CEC) features.
- **OPTIONS**: Accesses additional options or settings.

4. Care and Maintenance

Proper care will extend the life of your remote control.

- **Cleaning**: Use a soft, dry cloth to clean the remote. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement**: Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones.
- **Storage**: If the remote will not be used for an extended period, remove the batteries to prevent leakage and damage. Store in a cool, dry place.
- **Avoid Damage**: Do not drop the remote, expose it to extreme temperatures, or immerse it in water.

5. Troubleshooting

If you encounter issues with your remote control, refer to the following common problems and solutions.

- **Remote is not responding:**
  - Ensure the batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new 1.5V AAA alkaline batteries.
  - Check for any obstructions between the remote control and the TV's infrared sensor.
  - Ensure you are within the effective range and pointing the remote directly at the TV.
- **Some buttons are not working:**
  - Clean the remote control surface and buttons to remove any dirt or debris that might be interfering with button presses.
  - If only specific buttons are unresponsive, the remote may be damaged and require replacement.
- **TV is not turning on/off:**
  - Verify that the TV is plugged into a working power outlet.
  - Confirm that the remote's batteries are fresh and correctly installed.

6. Product Specifications

Feature	Specification
Brand	XVEFAT
Compatible Devices	Magnavox Televisions
Connectivity Technology	Infrared (IR)
Power Supply	2 x 1.5V AAA Alkaline Batteries
Number of Buttons	25
Special Feature	Ergonomic design

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B088DMHJ2S

More documents and user manuals: **https://manuals.plus/**