Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

XVEFAT HSG1113 HSG1139 HSG1116 HSG1076

XVEFAT Replacement Remote Control User Manual

For HANNSPREE LCD TV HDTV Models: SJ28DMBB, HSG1142, HSG1117, HSG1074, HSG1113, HSG1139, HSG1116, HSG1076

1. Introduction

This manual provides instructions for the XVEFAT replacement remote control, designed for use with various HANNSPREE LCD TV and HDTV models. This remote control requires no programming or pairing; simply insert batteries, and it is ready for operation.
Please read this manual thoroughly to ensure proper setup and operation of your new remote control.

2. Setup: Battery Installation

The remote control operates on two (2) 1.5V AA Alkaline batteries (not included). Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Press down on the tab and slide the cover downwards to open the compartment.
3. Insert two (2) AA Alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



Figure 2.1: Battery compartment with cover removed, showing correct battery orientation.

This image displays the rear view of the remote control. The battery cover is detached, revealing two empty slots for AA batteries. The positive and negative terminals are clearly marked within the compartment to guide correct battery insertion.

Important: Always replace both batteries at the same time. Do not mix old and new batteries, or different types of batteries. Remove batteries if the remote control will not be used for an extended period.

3. Operating Instructions

Once batteries are installed, the remote control is ready for immediate use with compatible HANNSPREE LCD TV and HDTV models. Point the remote control directly at the TV's infrared receiver.



Figure 3.1: Front view of the remote control with button layout.

This image shows the complete front panel of the XVEFAT replacement remote control. It features a standard layout including power, input, number keys, navigation buttons (up, down, left, right, OK), volume and channel controls, menu, info, and various function buttons for TV operation.

Key Functions:

- **POWER (Green Button):** Turns the TV on or off.
- **INPUT:** Selects the input source (HDMI, AV, Component, etc.).
- **Number Buttons (0-9):** Directly selects TV channels.
- **VOL +/-:** Adjusts the volume level.
- **CH P/P:** Changes TV channels up or down.
- **MUTE:** Mutes or unmutes the TV audio.

- **MENU:** Accesses the TV's main menu.
- **Navigation Buttons (Up/Down/Left/Right):** Navigates through menu options.
- **OK:** Confirms selections in menus.
- **INFO:** Displays information about the current program or input.
- **EXIT:** Exits the current menu or function.
- **EPG:** Accesses the Electronic Program Guide.
- **TEXT:** Activates or deactivates Teletext.
- **Color Buttons (Red, Green, Yellow, Blue):** Used for specific functions within menus or interactive services, as indicated on the TV screen.

4. Maintenance

Battery Replacement:

When the remote control's range decreases or it becomes unresponsive, it is time to replace the batteries. Refer to Section 2 for detailed battery installation instructions. Always use new AA Alkaline batteries.

Cleaning:

To clean the remote control, gently wipe its surface with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed by a dry cloth. Do not use abrasive cleaners, solvents, or chemical sprays, as these can damage the remote control's finish or internal components.

5. Troubleshooting

Problem	Possible Cause	Solution
Remote control is not working.	Batteries are dead or incorrectly inserted. Obstruction between remote and TV. Remote control is too far from the TV.	Replace batteries with new AA Alkaline batteries, ensuring correct polarity. Remove any objects blocking the line of sight between the remote and the TV. Move closer to the TV.
Some buttons are unresponsive.	Low battery power. Dirt or debris under the button.	Replace batteries. Clean the remote control (refer to Maintenance section).
Remote control does not control the TV.	Remote is not compatible with the TV model.	Verify your TV model is listed in the compatible models section of this manual.

6. Specifications

- **Brand:** XVEFAT
- **Model Compatibility:** HANNSPREE LCD TV HDTV models SJ28DMBB, HSG1142, HSG1117, HSG1074, HSG1113, HSG1139, HSG1116, HSG1076
- **Power Supply:** 2 x 1.5V AA Alkaline Battery
- **Connectivity Technology:** Infrared (IR)
- **Controller Type:** Button Control

- **Special Feature:** Ergonomic design
- **Compatible Devices:** Television

7. Warranty and Support

This product is a replacement remote control. Specific warranty information is not provided in the product data. For details regarding returns or replacements, please refer to the seller's return policy or contact the seller directly through your purchase platform.
For technical support or further inquiries, please contact the manufacturer or seller of the remote control.

© 2023 XVEFAT. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B088DT7173

More documents and user manuals: **https://manuals.plus/**