Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

XVEFAT ONC17TV001

XVEFAT Remote Control for ONN TV Model ONC17TV001

User Instruction Manual

1. Introduction

This manual provides comprehensive instructions for the XVEFAT remote control, designed as a replacement or secondary remote for ONN TV model ONC17TV001. Please read this manual carefully to ensure proper use and to maximize the lifespan of your remote control.



Figure 1: XVEFAT Remote Control (Angled View)

This image displays the XVEFAT remote control from an angled perspective, highlighting its overall shape and the arrangement of its buttons. The remote is black with gray and red accents on the buttons.

2. Setup

2.1 Battery Installation

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch to open it.
3. Insert two AAA batteries (not included), ensuring the positive (+) and negative (-) terminals align correctly with the

markings inside the compartment.

4. Replace the battery compartment cover by sliding it back into place until it clicks securely.

Note: Always use new batteries and replace both batteries at the same time. Do not mix old and new batteries or different types of batteries.

2.2 Initial Use

This remote control is designed to work directly with ONN TV model ONC17TV001 without any programming. Simply point the remote control towards your television and press the desired function button.

3. Operating Instructions

The XVEFAT remote control features a standard layout for easy navigation and control of your ONN TV. Below is a description of the main buttons and their functions.



Figure 2: XVEFAT Remote Control (Front View)

This image provides a clear, direct front view of the XVEFAT remote control, allowing for easy identification of each button and its corresponding label.

3.1 Button Functions

- **Power (⏻)**: Turns the TV on or off.
- **INPUT**: Selects the video input source (e.g., HDMI 1, AV, Component).
- **SLEEP TIMER**: Sets a timer for the TV to automatically turn off.
- **SAP/MTS**: Switches between audio programs (e.g., Stereo, SAP/MTS).
- **CC (Closed Caption)**: Toggles closed captions on or off.
- **TTS (Text-to-Speech)**: Activates or deactivates the Text-to-Speech function.
- **INFO**: Displays on-screen information about the current program or input.
- **MENU**: Opens the TV's main menu for settings and options.
- **Navigation Buttons (Up, Down, Left, Right)**: Navigates through menus and options.
- **OK**: Confirms selections in menus.
- **BACK**: Returns to the previous menu or screen.
- **EXIT**: Exits the current menu or function.
- **VOL +/-**: Adjusts the volume level.
- **MUTE**: Mutes or unmutes the TV audio.
- **CH +/-**: Changes the TV channel.
- **Number Pad (0-9)**: Directly enters channel numbers.
- **. (Dash)**: Used for entering sub-channels (e.g., 7.1).
- **ENTER**: Confirms channel entry or other numerical inputs.

4. Maintenance

4.1 Cleaning

To clean the remote control, gently wipe it with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water. Do not use harsh chemicals, abrasive cleaners, or solvents, as these can damage the remote's surface or internal components.

4.2 Battery Replacement

Replace batteries when the remote control's response becomes sluggish or stops working. Refer to Section 2.1 for battery installation instructions. Always dispose of used batteries responsibly according to local regulations.

4.3 Storage

If the remote control will not be used for an extended period, remove the batteries to prevent leakage, which can cause damage to the remote. Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.

5. Troubleshooting

- **Remote not responding:**
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace the batteries with new ones.
  - Ensure there are no obstructions between the remote control and the TV's infrared sensor.
  - Make sure you are within the effective operating range and pointing the remote directly at the TV.
- **Some buttons not working:**
  - This may indicate low battery power; try replacing the batteries.

- Ensure the remote is clean and there is no debris lodged under the buttons.

6. Specifications

Feature	Detail
Brand	XVEFAT
Compatible Devices	Television (ONN TV ONC17TV001)
Connectivity Technology	Infrared
Controller Type	Button Control
Special Feature	Ergonomic
Power Source	2 x AAA Batteries (not included)

7. Warranty and Support

Warranty information for this product is not provided within this manual. For details regarding warranty coverage, technical support, or replacement parts, please contact the manufacturer, XVEFAT, or your point of purchase. Keep your purchase receipt as proof of purchase.

© 2023 XVEFAT. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B088F1Z6YB

More documents and user manuals: **https://manuals.plus/**