Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

XVEFAT YC-53-3

XVEFAT YC-53-3 Remote Control User Manual

Model: YC-53-3 | Brand: XVEFAT

Introduction

This manual provides instructions for the XVEFAT YC-53-3 remote control, designed for use with various Sceptre TV models. Please read this manual carefully before using the remote control to ensure proper operation and to maximize its lifespan.

Package Contents

- 1X XVEFAT YC-53-3 Remote Control

Compatible Sceptre TV Models

This remote control is compatible with the following Sceptre TV models:

- E195BV-SHDE
- E195BV-SHDC
- E165BV-HD
- X425BV-FHD3
- X425BV-FHD
- E195BVSHDE
- E165BVHD
- X425BVFHD
- X425BVFHD3
- E195BVSHDC

Setup

Installing Batteries

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards to open it.

3. Insert two (2) 1.5V AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



Image: Back of the remote control with the battery compartment open, illustrating correct battery insertion.

First Use

No programming or pairing is required for this remote control. Once batteries are correctly installed, the remote is ready for immediate use with compatible Sceptre TV models.

Operating Instructions

Point the remote control directly at the infrared sensor on your Sceptre TV. Ensure there are no obstructions between the remote and the TV.



Image: Angled view of the remote control, highlighting the button layout.

Key Functions

Button	Function
Power	Turns the TV on or off.
Source	Selects input sources (HDMI, AV, Component, etc.).
Mute	Mutes or unmutes the TV audio.

Button	Function
0-9 (Number Buttons)	Direct channel selection.
VOL +/-	Adjusts the volume level.
CH +/-	Changes TV channels.
Menu	Opens the TV's main menu.
ENTER	Confirms selections in menus.
Navigation Arrows	Navigates through menu options.
Exit	Exits the current menu or function.
Guide	Displays the electronic program guide (if available).
Info	Displays information about the current program or input.
Aspect	Adjusts the screen aspect ratio.
Sleep	Sets the sleep timer.
Fav / **Fav+**	Accesses or cycles through favorite channels.
Add/Del	Adds or deletes channels from favorites.
Picture	Accesses picture settings.
Sound	Accesses sound settings.
TV	Switches to TV mode.
USB	Switches to USB input mode.
S.Source	Selects secondary input sources.
S.mode	Cycles through sound modes.
S.Vol- / **S.Vol+**	Adjusts secondary volume (if applicable).
A, B, C, D (Color Buttons)	Functions vary depending on the TV menu or application.



Image: Front view of the remote control, providing a clear overview of all buttons.

Maintenance

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote control's response becomes sluggish or stops working. Always replace both batteries at the same time with new AAA alkaline batteries.
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage.
- **Avoid Exposure:** Do not expose the remote control to direct sunlight, heat sources, or moisture.

Troubleshooting

- **Remote not working:**
  - Ensure batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new AAA alkaline batteries.
  - Check if there are any obstructions between the remote control and the TV's infrared sensor.
  - Ensure the remote control is pointed directly at the TV's infrared sensor.
- **Intermittent response:**
  - Batteries may be low; replace them.
  - Ensure you are within the effective range of the TV's infrared sensor.
- **Specific buttons not working:**
  - This remote is a direct replacement and does not require programming. If a button does not function, ensure it is applicable to your specific Sceptre TV model's features.
  - Clean the remote control to ensure no debris is obstructing button presses.

Specifications

- **Model:** YC-53-3
- **Brand:** XVEFAT
- **Power Supply:** 2 x 1.5V AAA Alkaline Battery
- **Connectivity Technology:** Infrared
- **Compatible Devices:** Sceptre Televisions (Specific models listed above)
- **Special Feature:** Ergonomic design

Warranty and Support

For warranty information or technical support, please refer to the documentation provided with your purchase or contact the retailer. Keep your purchase receipt for warranty claims.

© 2023 XVEFAT. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B088FVK6Y2

More documents and user manuals: **https://manuals.plus/**