Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

XVEFAT RM-D761

XVEFAT RM-D761 Remote Control User Manual

Model: RM-D761 | Brand: XVEFAT

1. Introduction

This manual provides instructions for the XVEFAT RM-D761 remote control, designed for use with various Pioneer DVD player models. This remote control requires no programming or pairing; simply install batteries to begin operation.

2. Package Contents

The package includes the following item:

- 1X RM-D761 Remote Control

3. Setup

3.1 Battery Installation

The RM-D761 remote control requires two (2) 1.5V AA alkaline batteries for operation. Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch (if present) to open the compartment.
3. Insert two (2) AA alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into position until it clicks securely.



Figure 1: Battery compartment of the RM-D761 remote control. Insert two AA batteries according to polarity markings.

Once batteries are installed, the remote is ready for use with compatible Pioneer DVD players without any additional programming.

4. Compatibility

The XVEFAT RM-D761 remote control is compatible with the following Pioneer DVD Player models:

- DV-300-K, DV-300
- DV-393-S, DV-393-K
- DV-270-S, DV-373-K, DV-373-S, DV-271-S, DV-280-S, DV-285-S
- DV-263, DV-260
- DV-463, DV-363-K, DV-363

- DV-251, DV-353, DV-250
- DV-266-S, DV-366-K, DV-366-S
- DV-466-K, DV-466-S
- DV-353-K, DV-353-S
- DV-2650, DV-360, DV-464
- DV-275, DV-275-S, DV-270, DV-271

5. Operating Instructions

This section outlines the primary functions of the buttons on your RM-D761 remote control.



Figure 2: Front view of the RM-D761 remote control with button layout.

5.1 Power and Disc Tray Control

- **STANDBY/ON (Power Symbol):** Turns the DVD player on or off (standby mode).
- **OPEN/CLOSE (Up Arrow Symbol):** Opens or closes the DVD player's disc tray.

5.2 Numeric and Function Buttons

- **0-9 (Numeric Buttons):** Used for direct track selection or entering numerical values.
- **CLEAR:** Clears the current selection or input.
- **ENTER:** Confirms a selection or input.
- **AUDIO:** Cycles through available audio tracks or languages.
- **SUBTITLE:** Cycles through available subtitle languages.
- **ANGLE:** Changes the viewing angle on compatible DVDs.

5.3 Navigation and Menu Control

- **TOP MENU:** Accesses the main menu of the DVD.
- **MENU:** Accesses the disc's title menu or chapter menu.
- **Directional Arrows (Up, Down, Left, Right):** Navigates through menus and options.
- **ENTER (Center of Navigation):** Selects the highlighted menu item.
- **HOME MENU:** Returns to the player's home menu.
- **RETURN:** Goes back to the previous menu or screen.

5.4 Playback Control

- **Previous Track (Double Left Arrow):** Skips to the beginning of the previous track/chapter.
- **Fast Rewind (Double Left Arrow with Line):** Rewinds playback quickly.
- **Play (Triangle):** Starts or resumes playback.
- **Fast Forward (Double Right Arrow with Line):** Fast forwards playback quickly.
- **Next Track (Double Right Arrow):** Skips to the beginning of the next track/chapter.
- **Stop (Square):** Stops playback.
- **Pause (Two Vertical Lines):** Pauses playback.

5.5 Additional Functions

- **PLAY MODE:** Adjusts playback modes (e.g., repeat, shuffle).
- **SURROUND:** Activates or adjusts surround sound settings.
- **ZOOM:** Zooms in or out on the video image.
- **DISPLAY:** Shows on-screen display information (e.g., elapsed time, chapter).

6. Troubleshooting

If your RM-D761 remote control is not functioning as expected, please refer to the following common issues and solutions:

- **Remote not responding:**
  - Ensure batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new 1.5V AA alkaline batteries.
  - Check for any obstructions between the remote control and the DVD player's infrared sensor.
  - Ensure you are within the effective range and line of sight of the DVD player.
- **Specific buttons not working:**

- This may indicate a faulty button or a specific function not supported by your DVD player model.
- Clean the remote control surface, especially around the buttons, to remove any debris.

7. Specifications

Model	RM-D761
Brand	XVEFAT
Compatible Devices	Pioneer DVD Players (various models, see Compatibility section)
Connectivity Technology	Infrared (IR)
Controller Type	Button Control
Power Supply	2 x 1.5V AA Alkaline Batteries

8. Warranty and Support

For information regarding warranty coverage or technical support, please refer to the documentation provided with your purchase or contact the retailer. As this is a replacement remote, specific warranty terms may vary.

© 2023 XVEFAT. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B088HGJ68Z

More documents and user manuals: **https://manuals.plus/**